

**CEN**

**CWA 15748-5**

**WORKSHOP**

July 2008

**AGREEMENT**

---

ICS 35.240.50

English version

**Extensions for Financial Services (XFS) interface specification -  
Release 3.10 - Part 5: Cash Dispenser Device Class Interface -  
Programmer's Reference**

This CEN Workshop Agreement has been drafted and approved by a Workshop of representatives of interested parties, the constitution of which is indicated in the foreword of this Workshop Agreement.

The formal process followed by the Workshop in the development of this Workshop Agreement has been endorsed by the National Members of CEN but neither the National Members of CEN nor the CEN Management Centre can be held accountable for the technical content of this CEN Workshop Agreement or possible conflicts with standards or legislation.

This CEN Workshop Agreement can in no way be held as being an official standard developed by CEN and its Members.

This CEN Workshop Agreement is publicly available as a reference document from the CEN Members National Standard Bodies.

CEN members are the national standards bodies of Austria, Belgium, Bulgaria, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland and United Kingdom.



EUROPEAN COMMITTEE FOR STANDARDIZATION  
COMITÉ EUROPÉEN DE NORMALISATION  
EUROPÄISCHES KOMITEE FÜR NORMUNG

**Management Centre: rue de Stassart, 36 B-1050 Brussels**

---

© 2008 CEN All rights of exploitation in any form and by any means reserved worldwide for CEN national Members.

Ref. No.:CWA 15748-5:2008 D/E/F

## Table of Contents

---

<b>Foreword .....</b>	<b>4</b>
<b>1. Introduction.....</b>	<b>7</b>
1.1 Background to Release 3.10 .....	7
1.2 XFS Service-Specific Programming.....	7
<b>2. Cash Dispensers .....</b>	<b>8</b>
<b>3. References .....</b>	<b>9</b>
<b>4. Info Commands .....</b>	<b>10</b>
4.1 WFS_INF_CDM_STATUS.....	10
4.2 WFS_INF_CDM_CAPABILITIES .....	14
4.3 WFS_INF_CDM_CASH_UNIT_INFO.....	18
4.4 WFS_INF_CDM_TELLER_INFO .....	25
4.5 WFS_INF_CDM_CURRENCY_EXP .....	27
4.6 WFS_INF_CDM_MIX_TYPES .....	28
4.7 WFS_INF_CDM_MIX_TABLE.....	29
4.8 WFS_INF_CDM_PRESENT_STATUS.....	30
<b>5. Execute Commands .....</b>	<b>32</b>
5.1 WFS_CMD_CDM_DENOMINATE .....	32
5.2 WFS_CMD_CDM_DISPENSE .....	35
5.3 WFS_CMD_CDM_COUNT .....	38
5.4 WFS_CMD_CDM_PRESENT.....	41
5.5 WFS_CMD_CDM_REJECT .....	42
5.6 WFS_CMD_CDM_RETRACT .....	43
5.7 WFS_CMD_CDM_OPEN_SHUTTER .....	45
5.8 WFS_CMD_CDM_CLOSE_SHUTTER.....	46
5.9 WFS_CMD_CDM_SET_TELLER_INFO.....	47
5.10 WFS_CMD_CDM_SET_CASH_UNIT_INFO .....	48
5.11 WFS_CMD_CDM_START_EXCHANGE .....	50
5.12 WFS_CMD_CDM_END_EXCHANGE.....	52
5.13 WFS_CMD_CDM_OPEN_SAFE_DOOR.....	53
5.14 WFS_CMD_CDM_CALIBRATE_CASH_UNIT .....	54
5.15 WFS_CMD_CDM_SET_MIX_TABLE .....	56
5.16 WFS_CMD_CDM_RESET.....	57
5.17 WFS_CMD_CDM_TEST_CASH_UNITS .....	59
5.18 WFS_CMD_CDM_SET_GUIDANCE_LIGHT .....	61
5.19 WFS_CMD_CDM_POWER_SAVE_CONTROL .....	62
5.20 WFS_CMD_CDM_PREPARE_DISPENSE.....	63

<b>6.</b>	<b>Events</b> .....	<b>64</b>
6.1	WFS_SRVE_CDM_SAFEDOOROPEN .....	64
6.2	WFS_SRVE_CDM_SAFEDOORCLOSED.....	65
6.3	WFS_USRE_CDM_CASHUNITTHRESHOLD.....	66
6.4	WFS_SRVE_CDM_CASHUNITINFOCHANGED .....	67
6.5	WFS_SRVE_CDM_TELLERINFOCHANGED .....	68
6.6	WFS_EXEE_CDM_DELAYEDDISPENSE.....	69
6.7	WFS_EXEE_CDM_STARTDISPENSE .....	70
6.8	WFS_EXEE_CDM_CASHUNITERROR.....	71
6.9	WFS_SRVE_CDM_ITEMSTAKEN.....	72
6.10	WFS_SRVE_CDM_COUNTS_CHANGED.....	73
6.11	WFS_EXEE_CDM_PARTIALDISPENSE .....	74
6.12	WFS_EXEE_CDM_SUBDISPENSEOK .....	75
6.13	WFS_EXEE_CDM_INCOMPLETEDISPENSE .....	76
6.14	WFS_EXEE_CDM_NOTEERROR .....	77
6.15	WFS_SRVE_CDM_ITEMSPRESENTED .....	78
6.16	WFS_SRVE_CDM_MEDIADETECTED .....	79
6.17	WFS_EXEE_CDM_INPUT_P6.....	80
6.18	WFS_SRVE_CDM_DEVICEPOSITION .....	81
6.19	WFS_SRVE_CDM_POWER_SAVE_CHANGE.....	82
<b>7.</b>	<b>Sub-Dispensing Command Flow</b> .....	<b>83</b>
<b>8.</b>	<b>Rules for Cash Unit Exchange</b> .....	<b>86</b>
<b>9.</b>	<b>C - Header file</b> .....	<b>87</b>

## Foreword

---

This CWA is revision 3.10 of the XFS interface specification.

The CEN/ISSS XFS Workshop gathers suppliers as well as banks and other financial service companies. A list of companies participating in this Workshop and in support of this CWA is available from the CEN/ISSS Secretariat.

This CWA was formally approved by the XFS Workshop meeting on 2007-11-29. The specification is continuously reviewed and commented in the CEN/ISSS Workshop on XFS. It is therefore expected that an update of the specification will be published in due time as a CWA, superseding this revision 3.10.

The CWA is published as a multi-part document, consisting of:

Part 1: Application Programming Interface (API) - Service Provider Interface (SPI) - Programmer's Reference

Part 2: Service Classes Definition - Programmer's Reference

Part 3: Printer and Scanning Device Class Interface - Programmer's Reference

Part 4: Identification Card Device Class Interface - Programmer's Reference

Part 5: Cash Dispenser Device Class Interface - Programmer's Reference

Part 6: PIN Keypad Device Class Interface - Programmer's Reference

Part 7: Check Reader/Scanner Device Class Interface - Programmer's Reference

Part 8: Depository Device Class Interface - Programmer's Reference

Part 9: Text Terminal Unit Device Class Interface - Programmer's Reference

Part 10: Sensors and Indicators Unit Device Class Interface - Programmer's Reference

Part 11: Vendor Dependent Mode Device Class Interface - Programmer's Reference

Part 12: Camera Device Class Interface - Programmer's Reference

Part 13: Alarm Device Class Interface - Programmer's Reference

Part 14: Card Embossing Unit Device Class Interface - Programmer's Reference

Part 15: Cash-In Module Device Class Interface - Programmer's Reference

Part 16: Card Dispenser Device Class Interface - Programmer's Reference

Part 17: Barcode Reader Device Class Interface - Programmer's Reference

Part 18: Item Processing Module Device Class Interface - Programmer's Reference

Parts 19 - 28: Reserved for future use.

Parts 29 through 47 constitute an optional addendum to this CWA. They define the integration between the SNMP standard and the set of status and statistical information exported by the Service Providers.

Part 29: XFS MIB Architecture and SNMP Extensions - Programmer's Reference

Part 30: XFS MIB Device Specific Definitions - Printer Device Class

Part 31: XFS MIB Device Specific Definitions - Identification Card Device Class

Part 32: XFS MIB Device Specific Definitions - Cash Dispenser Device Class

Part 33: XFS MIB Device Specific Definitions - PIN Keypad Device Class

Part 34: XFS MIB Device Specific Definitions - Check Reader/Scanner Device Class

Part 35: XFS MIB Device Specific Definitions - Depository Device Class

Part 36: XFS MIB Device Specific Definitions - Text Terminal Unit Device Class

Part 37: XFS MIB Device Specific Definitions - Sensors and Indicators Unit Device Class

Part 38: XFS MIB Device Specific Definitions - Camera Device Class

Part 39: XFS MIB Device Specific Definitions - Alarm Device Class

Part 40: XFS MIB Device Specific Definitions - Card Embossing Unit Class

Part 41: XFS MIB Device Specific Definitions - Cash-In Module Device Class

Part 42: Reserved for future use.

Part 43: XFS MIB Device Specific Definitions - Vendor Dependent Mode Device Class

Part 44: XFS MIB Application Management

Part 45: XFS MIB Device Specific Definitions - Card Dispenser Device Class

Part 46: XFS MIB Device Specific Definitions - Barcode Reader Device Class

Part 47: XFS MIB Device Specific Definitions - Item Processing Module Device Class

Parts 48 - 60 are reserved for future use.

Part 61: Application Programming Interface (API) - Service Provider Interface (SPI) - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 62: Printer Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 63: Identification Card Device Class Interface - Migration from Version 3.02 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 64: Cash Dispenser Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 65: PIN Keypad Device Class Interface - Migration from Version 3.03 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 66: Check Reader/Scanner Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 67: Depository Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 68: Text Terminal Unit Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 69: Sensors and Indicators Unit Device Class Interface - Migration from Version 3.01 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 70: Vendor Dependent Mode Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 71: Camera Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 72: Alarm Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 73: Card Embossing Unit Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 74: Cash-In Module Device Class Interface - Migration from Version 3.02 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

In addition to these Programmer's Reference specifications, the reader of this CWA is also referred to a complementary document, called Release Notes. The Release Notes contain clarifications and explanations on the CWA specifications, which are not requiring functional changes. The current version of the Release Notes is available online from <http://www.cen.eu/iss/Workshop/XFS>.

The information in this document represents the Workshop's current views on the issues discussed as of the date of publication. It is furnished for informational purposes only and is subject to change without notice. CEN/ISSS makes no warranty, express or implied, with respect to this document.

This CEN Workshop Agreement is publicly available as a reference document from the National Members of CEN : AENOR, AFNOR, ASRO, BDS, BSI, CSNI, CYS, DIN, DS, ELOT, EVS, IBN, IPQ, IST, LVS, LST, MSA, MSZT, NEN, NSAI, ON, PKN, SEE, SIS, SIST, SFS, SN, SNV, SUTN and UNI.

Comments or suggestions from the users of the CEN Workshop Agreement are welcome and should be addressed to the CEN Management Centre.

Revision History:

3.0	October 18, 2000	Addition of the reset command. Cash Units Manipulated enhancement. Count Command Addition, Coin Dispense Clarification Addition of rejected/retracted notes counter Addition of retract area structure Clarify handling of coins and bills, introduction of the term item instead of bill, clarification for mix tables, clarification for TEST_CASH_UNITS Other CDM error codes. For a detailed description see CWA 14050-19 CDM Migration from Version 2.0 to Version 3.0.
3.10	November 29, 2007	For a description of changes see CWA 15748-64: 2007 CDM Migration from Version 3.0 (see CWA 14050) to Version 3.10.

---

# 1. Introduction

---

## 1.1 Background to Release 3.10

---

The CEN/ISSS XFS Workshop aims to promote a clear and unambiguous specification defining a multi-vendor software interface to financial peripheral devices. The XFS (eXtensions for Financial Services) specifications are developed within the CEN/ISSS (European Committee for Standardization/Information Society Standardization System) Workshop environment. CEN/ISSS Workshops aim to arrive at a European consensus on an issue that can be published as a CEN Workshop Agreement (CWA).

The CEN/ISSS XFS Workshop encourages the participation of both banks and vendors in the deliberations required to create an industry standard. The CEN/ISSS XFS Workshop achieves its goals by focused sub-groups working electronically and meeting quarterly.

Release 3.10 of the XFS specification is based on a C API and is delivered with the continued promise for the protection of technical investment for existing applications. This release of the XFS specification has been prompted by a series of factors.

There has been a technical imperative to extend the scope of the existing specification to include new devices, such as the Barcode Reader, Card Dispenser and Item Processing Module.

Similarly, there has also been pressure, through implementation experience and additional requirements, to extend the functionality and capabilities of the existing devices covered by the specification.

## 1.2 XFS Service-Specific Programming

---

The service classes are defined by their service-specific commands and the associated data structures, error codes, messages, etc. These commands are used to request functions that are specific to one or more classes of Service Providers, but not all of them, and therefore are not included in the common API for basic or administration functions.

When a service-specific command is common among two or more classes of Service Providers, the syntax of the command is as similar as possible across all services, since a major objective of XFS is to standardize function codes and structures for the broadest variety of services. For example, using the **WFSExecute** function, the commands to read data from various services are as similar as possible to each other in their syntax and data structures.

In general, the specific command set for a service class is defined as a superset of the specific capabilities likely to be provided by the developers of the services of that class; thus any particular device will normally support only a subset of the defined command set.

There are three cases in which a Service Provider may receive a service-specific command that it does not support:

The requested capability is defined for the class of Service Providers by the XFS specification, the particular vendor implementation of that service does not support it, and the unsupported capability is *not* considered to be fundamental to the service. In this case, the Service Provider returns a successful completion, but does no operation. An example would be a request from an application to turn on a control indicator on a passbook printer; the Service Provider recognizes the command, but since the passbook printer it is managing does not include that indicator, the Service Provider does no operation and returns a successful completion to the application.

The requested capability is defined for the class of Service Providers by the XFS specification, the particular vendor implementation of that service does not support it, and the unsupported capability *is* considered to be fundamental to the service. In this case, a `WFS_ERR_UNSUPP_COMMAND` error is returned to the calling application. An example would be a request from an application to a cash dispenser to dispense coins; the Service Provider recognizes the command but, since the cash dispenser it is managing dispenses only notes, returns this error.

The requested capability is *not* defined for the class of Service Providers by the XFS specification. In this case, a `WFS_ERR_INVALID_COMMAND` error is returned to the calling application.

This design allows implementation of applications that can be used with a range of services that provide differing subsets of the functionalities that are defined for their service class. Applications may use the **WFSGetInfo** and **WFSAsyncGetInfo** commands to inquire about the capabilities of the service they are about to use, and modify their behavior accordingly, or they may use functions and then deal with `WFS_ERR_UNSUPP_COMMAND` error returns to make decisions as to how to use the service.

## 2. Cash Dispensers

---

This specification describes the functionality of a XFS compliant Cash Dispenser Module (CDM) Service Provider. It defines the service-specific commands that can be issued to the Service Provider using the **WFSGetInfo**, **WFSAsyncGetInfo**, **WFSExecute** and **WFSAsyncExecute** functions.

Persistent values are maintained through power failures, open sessions, close session and system resets.

This specification covers the dispensing of items. An “item” is defined as any media that can be dispensed and includes coupons, documents, bills and coins. However, if coins and bills are both to be dispensed separate Service Providers must be implemented for each.

All currency parameters in this specification are expressed as a quantity of minimum dispense units, as defined in the description of the `WFS_INF_CDM_CURRENCY_EXP` command (see Section 4.5).

There are two types of CDM: Self-Service CDM and Teller CDM. A Self-Service CDM operates in an automated environment, while a Teller CDM has an operator present. The functionality provided by the following commands is only applicable to a Teller CDM:

`WFS_CMD_CDM_SET_TELLER_INFO`

`WFS_INF_CDM_TELLER_INFO`

It is possible for the CDM to be part of a compound device with the Cash-In Module (CIM). This CIM/CDM combination is referred to throughout this specification as a “Cash Recycler”. For details of the CIM interface see Ref. 3.

If the device is a Cash Recycler then, if cash unit exchanges are required on both interfaces, the exchanges cannot be performed concurrently. An exchange on one interface must be complete (the `WFS_CMD_CDM_END_EXCHANGE` must have completed) before an exchange can start on the other interface. The `WFS_ERR_CDM_EXCHANGEACTIVE` error code will be returned if the correct sequence is not adhered to.

The CIM interface can be used for all exchange operations on recycle devices, and the CIM interface should be used if the device has recycle units of multiple currencies and/or denominations (including multiple note identifiers associated with the same denomination).

The event `WFS_SRVE_CDM_COUNTS_CHANGED` will be posted if an operation on the CIM interface affects the cash unit counts which are available through the CDM interface.

The following commands on the CIM interface may affect the CDM counts:

`WFS_CMD_CIM_CASH_IN`  
`WFS_CMD_CIM_CASH_IN_ROLLBACK`  
`WFS_CMD_CIM_RETRACT`  
`WFS_CMD_CIM_SET_CASH_IN_UNIT_INFO`  
`WFS_CMD_CIM_END_EXCHANGE`  
`WFS_CMD_CIM_RESET`



### 3. References

---

---

- |   |
|---|
| 1. XFS Application Programming Interface (API)/Service Provider Interface ( SPI), Programmer's Reference, Revision 3.10 |
| 2. ISO 4217 at <a href="http://www.iso.org">http://www.iso.org</a>  |
| 3. XFS Cash-In Module Device Class Interface, Programmer's Reference, Revision 3.10                                     |

## 4. Info Commands

### 4.1 WFS\_INF\_CDM\_STATUS

**Description** This command is used to obtain the status of the CDM. It may also return vendor-specific status information.

**Input Param** None.

**Output Param** LPWFSCDMSTATUS lpStatus;

```
typedef struct _wfs_cdm_status
{
    WORD                fwDevice;
    WORD                fwSafeDoor;
    WORD                fwDispenser;
    WORD                fwIntermediateStacker;
    LPWFSCDMOUTPOS     *lppPositions;
    LPSTR               lpszExtra;
    DWORD               dwGuidLights[WFS_CDM_GUIDLIGHTS_SIZE];
    WORD                wDevicePosition;
    USHORT              usPowerSaveRecoveryTime;
} WFS_CDM_STATUS, *LPWFSCDM_STATUS;
```

#### *fwDevice*

Supplies the state of the CDM. However, an *fwDevice* status of WFS\_CDM\_DEVONLINE does not necessarily imply that dispensing can take place: the value of the *fwDispenser* field must be taken into account and - for some vendors - the state of the safe door (*fwSafeDoor*) may also be relevant. The state of the CDM will have one of the following values:

Value	Meaning
WFS_CDM_DEVONLINE	The device is online. This is returned when the dispenser is present and operational.
WFS_CDM_DEVOFFLINE	The device is offline (e.g. the operator has taken the device offline by turning a switch or pulling out the device).
WFS_CDM_DEVPOWEROFF	The device is powered off or physically not connected.
WFS_CDM_DEVNODEVICE	The device is not intended to be there, e.g. this type of self service machine does not contain such a device or it is internally not configured.
WFS_CDM_DEVHWERROR	The device is inoperable due to a hardware error.
WFS_CDM_DEVUSERERROR	The device is present but a person is preventing proper device operation.
WFS_CDM_DEVBUSY	The device is busy and unable to process an execute command at this time.
WFS_CDM_DEVFRAUDATTEMPT	The device is present but has detected a fraud attempt.

#### *fwSafeDoor*

Supplies the state of the safe door as one of the following values:

Value	Meaning
WFS_CDM_DOORNOTSUPPORTED	Physical device has no safe door or door state reporting is not supported.
WFS_CDM_DOOROPEN	Safe door is open.
WFS_CDM_DOORCLOSED	Safe door is closed.
WFS_CDM_DOORUNKNOWN	Due to a hardware error or other condition, the state of the door cannot be determined.

#### *fwDispenser*

Supplies the state of the dispenser's logical cash units as one of the following values:

Value	Meaning
WFS_CDM_DISPOK	All cash units present are in a good state.
WFS_CDM_DISPCUSTATE	The dispenser is operational, but one or more of the cash units is in a low, empty or inoperative condition. Items can still be dispensed from at least one of the cash units.
WFS_CDM_DISPCUSTOP	Due to a cash unit failure dispensing is impossible. The dispenser is operational, but no items can be dispensed because all of the cash units are in an empty or inoperative condition. This state also occurs when a reject/retract cash unit is full or no reject/retract cash unit is present, or an application lock is set on every cash unit.
WFS_CDM_DISPCUUNKNOWN	Due to a hardware error or other condition, the state of the cash units cannot be determined.

*fwIntermediateStacker*

Supplies the state of the intermediate stacker. These bills are typically present on the intermediate stacker as a result of a retract operation or because a dispense has been performed without a subsequent present. Possible values for this field are:

Value	Meaning
WFS_CDM_ISEMPY	The intermediate stacker is empty.
WFS_CDM_ISNOTEMPTY	The intermediate stacker is not empty. The items have not been in customer access.
WFS_CDM_ISNOTEMPTYCUST	The intermediate stacker is not empty. The items have been in customer access. If the device is a recycler then the items on the intermediate stacker may be there as a result of a previous Cash-In operation.
WFS_CDM_ISNOTEMPTYUNK	The intermediate stacker is not empty. It is not known if the items have been in customer access.
WFS_CDM_ISUNKNOWN	Due to a hardware error or other condition, the state of the intermediate stacker cannot be determined.
WFS_CDM_ISNOTSUPPORTED	The physical device has no intermediate stacker.

*lppPositions*

Pointer to a NULL-terminated array of pointers to WFSCDMOUTPOS structures. There is one structure for each position to which items can be dispensed or presented:

```
typedef struct _wfs_cdm_position
{
    WORD                fwPosition;
    WORD                fwShutter;
    WORD                fwPositionStatus;
    WORD                fwTransport;
    WORD                fwTransportStatus;
} WFSCDMOUTPOS, *LPWFSCDMOUTPOS;
```

*fwPosition*

Supplies the output position as one of the following values:

Value	Meaning
WFS_CDM_POSLEFT	Left output position.
WFS_CDM_POSRIGHT	Right output position.
WFS_CDM_POSCENTER	Center output position.
WFS_CDM_POSTOP	Top output position.
WFS_CDM_POSBOTTOM	Bottom output position.
WFS_CDM_POSFRONT	Front output position.
WFS_CDM_POSREAR	Rear output position.

*fwShutter*

Supplies the state of the shutter as one of the following values:

Value	Meaning
WFS_CDM_SHTCLOSED	The shutter is closed.
WFS_CDM_SHTOPEN	The shutter is opened.
WFS_CDM_SHTJAMMED	The shutter is jammed.
WFS_CDM_SHTUNKNOWN	Due to a hardware error or other condition, the state of the shutter cannot be determined.
WFS_CDM_SHTNOTSUPPORTED	The physical device has no shutter or shutter state reporting is not supported.

*fwPositionStatus*

Returns information regarding items which may be at the output position. If the device is a recycler it is possible that the output position will not be empty due to a previous Cash-In operation. The possible values of this field are:

Value	Meaning
WFS_CDM_PSEMPY	The output position is empty.
WFS_CDM_PSNOTEMPTY	The output position is not empty.
WFS_CDM_PSUNKNOWN	Due to a hardware error or other condition, the state of the output position cannot be determined.
WFS_CDM_PSNOTSUPPORTED	The device is not capable of reporting whether or not items are at the output position.

*fwTransport*

Supplies the state of the transport mechanism as one of the following values:

Value	Meaning
WFS_CDM_TPOK	The transport is in a good state.
WFS_CDM_TPINOP	The transport is inoperative due to a hardware failure or media jam.
WFS_CDM_TPUNKNOWN	Due to a hardware error or other condition the state of the transport cannot be determined.
WFS_CDM_TPNOTSUPPORTED	The physical device has no transport or transport state reporting is not supported.

*fwTransportStatus*

Returns information regarding items which may be on the transport. If the device is a recycler device it is possible that the transport will not be empty due to a previous Cash-In operation. The possible values of this field are:

Value	Meaning
WFS_CDM_TPSTATEMPTY	The transport is empty.
WFS_CDM_TPSTATNOTEMPTY	The transport is not empty.
WFS_CDM_TPSTATNOTEMPTYCUST	Items which a customer has had access to are on the transport.
WFS_CDM_TPSTATNOTEMPTY_UNK	Due to a hardware error or other condition it is not known whether there are items on the transport.
WFS_CDM_TPSTATNOTSUPPORTED	The device is not capable of reporting whether items are on the transport.

*lpszExtra*

Pointer to a list of vendor-specific, or any other extended, information. The information is returned as a series of "key=value" strings so that it is easily extensible by Service Providers. Each string is null-terminated, with the final string terminating with two null characters. An empty list may be indicated by either a NULL pointer or a pointer to two consecutive null characters.

*dwGuidLights [...]*

Specifies the state of the guidance light indicators. The elements of this array can be accessed by using the predefined index values specified for the *dwGuidLights* field in the capabilities. Vendor specific guidance lights are defined starting from the end of the array. The maximum guidance light index is `WFS_CDM_GUIDLIGHTS_MAX`.

Specifies the state of the guidance light indicator as `WFS_CDM_GUIDANCE_NOT_AVAILABLE`, `WFS_CDM_GUIDANCE_OFF` or a combination of the following flags consisting of one type B, and optionally one type C.

Value	Meaning	Type
<code>WFS_CDM_GUIDANCE_NOT_AVAILABLE</code>	The status is not available.	A
<code>WFS_CDM_GUIDANCE_OFF</code>	The light is turned off.	A
<code>WFS_CDM_GUIDANCE_SLOW_FLASH</code>	The light is blinking slowly.	B
<code>WFS_CDM_GUIDANCE_MEDIUM_FLASH</code>	The light is blinking medium frequency.	B
<code>WFS_CDM_GUIDANCE_QUICK_FLASH</code>	The light is blinking quickly.	B
<code>WFS_CDM_GUIDANCE_CONTINUOUS</code>	The light is turned on continuous (steady).	B
<code>WFS_CDM_GUIDANCE_RED</code>	The light is red.	C
<code>WFS_CDM_GUIDANCE_GREEN</code>	The light is green.	C
<code>WFS_CDM_GUIDANCE_YELLOW</code>	The light is yellow.	C
<code>WFS_CDM_GUIDANCE_BLUE</code>	The light is blue.	C
<code>WFS_CDM_GUIDANCE_CYAN</code>	The light is cyan.	C
<code>WFS_CDM_GUIDANCE_MAGENTA</code>	The light is magenta.	C
<code>WFS_CDM_GUIDANCE_WHITE</code>	The light is white.	C

*wDevicePosition*

Specifies the device position. The device position value is independent of the *fwDevice* value, e.g. when the device position is reported as `WFS_CDM_DEVICENOTINPOSITION`, *fwDevice* can have any of the values defined above (including `WFS_CDM_DEVONLINE` or `WFS_CDM_DEVOFFLINE`). If the device is not in its normal operating position (i.e. `WFS_CDM_DEVICEINPOSITION`) then media may not be presented through the normal customer interface. This value is one of the following values:

Value	Meaning
<code>WFS_CDM_DEVICEINPOSITION</code>	The device is in its normal operating position, or is fixed in place and cannot be moved.
<code>WFS_CDM_DEVICENOTINPOSITION</code>	The device has been removed from its normal operating position.
<code>WFS_CDM_DEVICEPOSUNKNOWN</code>	Due to a hardware error or other condition, the position of the device cannot be determined.
<code>WFS_CDM_DEVICEPOSNOTSUPP</code>	The physical device does not have the capability of detecting the position.

*usPowerSaveRecoveryTime*

Specifies the actual number of seconds required by the device to resume its normal operational state from the current power saving mode. This value is zero if either the power saving mode has not been activated or no power save control is supported.

**Error Codes** Only the generic error codes defined in [Ref. 1] can be generated by this command.

**Comments** Applications which rely on the *lpszExtra* parameter may not be device or vendor-independent. In the case where communication with the device has been lost, the *fwDevice* field will report `WFS_CDM_DEVPOWEROFF` when the device has been removed or `WFS_CDM_DEVHWERROR` if the communications are unexpectedly lost. All other fields should contain a value based on the following rules and priority:

1. Report the value as unknown.
2. Report the value as a general h/w error.
3. Report the value as the last known value.

## 4.2 WFS\_INF\_CDM\_CAPABILITIES

**Description** This command retrieves the capabilities of the CDM. It may also return vendor specific capability information. The intermediate stacker and the transport are treated as separate areas. Some devices may have the capability to move items from the cash units to the intermediate stacker while there are items on the transport. Similarly some devices may be able to retract items to the transport or the cash units while there are items on the intermediate stacker.

**Input Param** None.

**Output Param** LPWFSCDMCAPS lpCaps;

```
typedef struct _wfs_cdm_caps
{
    WORD                wClass;
    WORD                fwType;
    WORD                wMaxDispenseItems;
    BOOL                bCompound;
    BOOL                bShutter;
    BOOL                bShutterControl;
    WORD                fwRetractAreas;
    WORD                fwRetractTransportActions;
    WORD                fwRetractStackerActions;
    BOOL                bSafeDoor;
    BOOL                bCashBox;
    BOOL                bIntermediateStacker;
    BOOL                bItemsTakenSensor;
    WORD                fwPositions;
    WORD                fwMoveItems;
    WORD                fwExchangeType;
    LPSTR               lpszExtra;
    DWORD               dwGuidLights[WFS_CDM_GUIDLIGHTS_SIZE];
    BOOL                bPowerSaveControl;
    BOOL                bPrepareDispense;
} WFS_CDMCAPS, *LPWFSCDMCAPS;
```

*wClass*

Specifies the logical service class as WFS\_SERVICE\_CLASS\_CDM.

*fwType*

Supplies the type of CDM as one of the following values:

Value	Meaning
WFS_CDM_TELLERBILL	The CDM is a Teller Bill Dispenser.
WFS_CDM_SELFSERVICEBILL	The CDM is a Self Service Bill Dispenser.
WFS_CDM_TELLERCOIN	The CDM is a Teller Coin Dispenser.
WFS_CDM_SELFSERVICECOIN	The CDM is a Self Service Coin Dispenser.

*wMaxDispenseItems*

Supplies the maximum number of items that can be dispensed in a single dispense operation. If no limit applies this value will be zero - in this case, if an attempt is made to dispense more items than the hardware limitations will allow, the Service Provider will implement the dispense as a series of sub-dispense operations [see section Sub-Dispensing Command Flow].

*bCompound*

Specifies whether the CDM is part of a compound device. If the CDM is part of a compound device with a CIM then this combination can be referred to as a recycler. In this case, no information on Cash-In cash units will be supplied via the CDM interface. The CDM interface will however supply information on shared retract or reject cash units and recycler cash units.

*bShutter*

Specifies whether or not the commands WFS\_CMD\_CDM\_OPEN\_SHUTTER and WFS\_CMD\_CDM\_CLOSE\_SHUTTER are supported.

*bShutterControl*

If set to TRUE the shutter is controlled implicitly by the Service Provider. If set to FALSE the shutter must be controlled explicitly by the application using the WFS\_CMD\_CDM\_OPEN\_SHUTTER and the WFS\_CMD\_CDM\_CLOSE\_SHUTTER commands. This field is always set to TRUE if the device has no shutter. This field applies to all shutters and all output positions.

*fwRetractAreas*

Specifies the area to which items may be retracted as a combination of the following flags:

Value	Meaning
WFS_CDM_RA_RETRACT	The items may be retracted to the retract cash unit.
WFS_CDM_RA_TRANSPORT	The items may be retracted to the transport.
WFS_CDM_RA_STACKER	The items may be retracted to the intermediate stacker.
WFS_CDM_RA_REJECT	The items may be retracted to the reject cash unit.
WFS_CDM_RA_ITEMCASSETTE	The items may be retracted to the item cassettes, i.e. cassettes that can be dispensed from.
WFS_CDM_RA_NOTSUPP	The CDM does not have the ability to retract.

*fwRetractTransportActions*

Specifies the actions which may be performed on items which have been retracted to the transport. If the device does not have a retract capability this value will be WFS\_CDM\_NOTSUPP. This field will be a combination of the following flags:

Value	Meaning
WFS_CDM_PRESENT	The items may be presented.
WFS_CDM_RETRACT	The items may be retracted to a retract cash unit.
WFS_CDM_REJECT	The items may be rejected to a reject bin.
WFS_CDM_ITEMCASSETTE	The items may be retracted to the item cassettes, i.e. cassettes that can be dispensed from.
WFS_CDM_NOTSUPP	The CDM does not have the ability to retract from the transport.

*fwRetractStackerActions*

Specifies the actions which may be performed on items which have been retracted to the stacker. If the device does not have a retract capability this value will be WFS\_CDM\_NOTSUPP. Otherwise it will be a combination of the following flags:

Value	Meaning
WFS_CDM_PRESENT	The items may be presented.
WFS_CDM_RETRACT	The items may be retracted to a retract cash unit.
WFS_CDM_REJECT	The items may be rejected to a reject bin.
WFS_CDM_ITEMCASSETTE	The items may be retracted to the item cassettes, i.e. cassettes that can be dispensed from.
WFS_CDM_NOTSUPP	The CDM does not have the ability to retract from the stacker.

*bSafedoor*

Specifies whether or not the WFS\_CMD\_CDM\_OPEN\_SAFE\_DOOR command is supported.

*bCashBox*

This field is only applicable to CDM types WFS\_CDM\_TELLERBILL and WFS\_CDM\_TELLERCOIN. It specifies whether or not tellers have been assigned a Cash Box.

*bIntermediateStacker*

Specifies whether or not the CDM supports stacking items to an intermediate position before the items are moved to the exit position. If this value is TRUE, the parameter *bPresent* of the WFS\_CMD\_CDM\_DISPENSE command can be set to FALSE [see Section WFS\_CMD\_CDM\_DISPENSE].

*bItemsTakenSensor*

Specifies whether the CDM can detect when items at the exit position are taken by the user. If set to TRUE the Service Provider generates an accompanying WFS\_SRVE\_CDM\_ITEMS\_TAKEN event. If set to FALSE this event is not generated. This field applies to all output positions.

*fwPositions*

Specifies the CDM output positions which are available as a combination of the following flags:

Value	Meaning
WFS_CDM_POSLEFT	The CDM has a left output position.
WFS_CDM_POSRIGHT	The CDM has a right output position.
WFS_CDM_POSCENTER	The CDM has a center output position.
WFS_CDM_POSTOP	The CDM has a top output position.
WFS_CDM_POSBOTTOM	The CDM has a bottom output position.
WFS_CDM_POSFRONT	The CDM has a front output position.
WFS_CDM_POSREAR	The CDM has a rear output position.

*fwMoveItems*

Specifies the CDM move item options which are available as a combination of the following flags:

Value	Meaning
WFS_CDM_FROMCU	The CDM can move items from the cash units to the intermediate stacker while there are items on the transport.
WFS_CDM_TOCU	The CDM can retract items to the cash units while there are items on the intermediate stacker.
WFS_CDM_TOTRANSPORT	The CDM can retract items to the transport while there are items on the intermediate stacker.

*fwExchangeType*

Specifies the type of cash unit exchange operations supported by the CDM as a combination of the following flags:

Value	Meaning
WFS_CDM_EXBYHAND	The CDM supports manual replenishment either by filling the cash unit by hand or by replacing the cash unit.
WFS_CDM_EXTOCASSETTES	The CDM supports moving items from the replenishment cash unit to another cash unit.

*lpszExtra*

Pointer to a list of vendor-specific, or any other extended, information. The information is returned as a series of "key=value" strings so that it is easily extensible by Service Providers. Each string is null-terminated, with the final string terminating with two null characters. An empty list may be indicated by either a NULL pointer or a pointer to two consecutive null characters.

*dwGuidLights [...]*

Specifies which guidance lights are available. A number of guidance light positions are defined below. Vendor specific guidance lights are defined starting from the end of the array. The maximum guidance light index is WFS\_CDM\_GUIDLIGHTS\_MAX.



The elements of this array are specified as a combination of the following flags and indicate all of the possible flash rates (type B) and colors (type C) that the guidance light indicator is capable of handling. If the guidance light indicator only supports one color then no value of type C is returned. A value of WFS\_CDM\_GUIDANCE\_NOT\_AVAILABLE indicates that the device has no guidance light indicator or the device controls the light directly with no application control possible.

Value	Meaning	Type
WFS_CDM_GUIDANCE_NOT_AVAILABLE	There is no guidance light control available at this position.	A
WFS_CDM_GUIDANCE_OFF	The light can be off.	B
WFS_CDM_GUIDANCE_SLOW_FLASH	The light can blink slowly.	B
WFS_CDM_GUIDANCE_MEDIUM_FLASH	The light can blink medium frequency.	B
WFS_CDM_GUIDANCE_QUICK_FLASH	The light can blink quickly.	B
WFS_CDM_GUIDANCE_CONTINUOUS	The light can be continuous (steady).	B
WFS_CDM_GUIDANCE_RED	The light can be red.	C
WFS_CDM_GUIDANCE_GREEN	The light can be green.	C
WFS_CDM_GUIDANCE_YELLOW	The light can be yellow.	C
WFS_CDM_GUIDANCE_BLUE	The light can be blue.	C
WFS_CDM_GUIDANCE_CYAN	The light can be cyan.	C
WFS_CDM_GUIDANCE_MAGENTA	The light can be magenta.	C
WFS_CDM_GUIDANCE_WHITE	The light can be white.	C

Each array index represents an output position in the CDM. The elements are accessed using the following definitions for the index value:

Value	Meaning
WFS_CDM_GUIDANCE_POSOUTNULL	The default output position.
WFS_CDM_GUIDANCE_POSOUTLEFT	Left output position.
WFS_CDM_GUIDANCE_POSOUTRIGHT	Right output position.
WFS_CDM_GUIDANCE_POSOUTCENTER	Center output position.
WFS_CDM_GUIDANCE_POSOUTTOP	Top output position.
WFS_CDM_GUIDANCE_POSOUTBOTTOM	Bottom output position.
WFS_CDM_GUIDANCE_POSOUTFRONT	Front output position.
WFS_CDM_GUIDANCE_POSOUTREAR	Rear output position.

*bPowerSaveControl*

Specifies whether power saving control is available. This can either be TRUE if available or FALSE if not available.

*bPrepareDispense*

On some hardware it can take a significant amount of time for the dispenser to get ready to dispense media. On this type of hardware the WFS\_CMD\_CDM\_PREPARE\_DISPENSE command can be used to improve transaction performance. This flag indicates if the hardware requires the application to use the WFS\_CMD\_CDM\_PREPARE\_DISPENSE command to maximize transaction performance. If this flag is TRUE then the WFS\_CMD\_CDM\_PREPARE\_DISPENSE command is supported and can be used to improve transaction performance. If this flag is FALSE then the WFS\_CMD\_CDM\_PREPARE\_DISPENSE is not supported.

**Error Codes** Only the generic error codes defined in [Ref. 1] can be generated by this command.

**Comments** Applications which rely on the *lpszExtra* parameter may not be device or vendor-independent.

## 4.3 WFS\_INF\_CDM\_CASH\_UNIT\_INFO

---

**Description** This command is used to obtain information regarding the status and contents of the cash units in the CDM.

Where a logical cash unit is configured but there is no corresponding physical cash unit currently present in the device, information about the missing cash unit will still be returned in the *lppList* field of the output parameter. The status of the cash unit will be reported as `WFS_CDM_STATCUMISSING`.

It is possible that one logical cash unit may be associated with more than one physical cash unit. In this case, the number of cash unit structures returned in *lpCashUnitInfo* will reflect the number of logical cash units in the CDM. That is, if a system contains four physical cash units but two of these are treated as one logical cash unit, *lpCashUnitInfo* will contain information about the three logical cash units and a *usCount* of 3. Information about the physical cash unit(s) associated with a logical cash unit is contained in the `WFSCDMCASHUNIT` structure representing the logical cash unit.

It is also possible that multiple logical cash units may be associated with one physical cash unit. This should only occur if the physical cash unit is capable of handling this situation, i.e. if it can store multiple denominations and report meaningful count and replenishment information for each denomination or if it can store retracted and rejected items as separate logical units and report meaningful count and replenishment information for each of them. In this case the information returned in *lpCashUnitInfo* will again reflect the number of logical cash units in the CDM.

### Logical Types

A cash unit may have a logical type. A logical type is based on the value of the following fields of the `WFSCDMCASHUNIT` structure:

*lpCashUnitName*  
*usType*  
*cCurrencyID*  
*ulValues*

A logical type of cash unit may be associated with more than one physical cash unit. The logical type is distinct from the logical number (*usNumber*), i.e. *usNumber* does not refer to the logical cassette type.

### Counts

Item counts are typically based on software counts and therefore may not represent the actual number of items in the cash unit. Persistent values are maintained through power failures, open sessions, close session and system resets. If a cash unit is shared between the CDM and CIM device class, then CDM operations will result in count changes in the CIM cash unit structure and vice versa. All counts are reported consistently on both interfaces at all times.

On cash units that dispense items, if *ulCount* (on logical and physical cash units) reaches zero it will not decrement further but will remain at zero. When *ulCount* reaches zero no further dispense or denominate operations will be possible using that cash unit, unless the Service Provider provides a configuration option to continue using cash units when *ulCount* reaches zero. The default setting for any such configuration parameter must be to stop using the cash unit when this value reaches zero. If the Service Provider is configured such that the cash unit can still be used when *ulCount* reaches zero then `WFS_CDM_STATCUEMPTY` should not be generated when *ulCount* reaches zero, rather it should be generated when all physical cash units associated with the logical cash unit are physically empty. On recyclers, the Service Provider should not be configured to keep using the cash unit when *ulCount* is zero if the value in *ulCount* is used by any part of the application, as it may not be accurate. However, if the Service Provider is configured to keep using the cash unit when *ulCount* reaches zero, then the number of notes in the cash unit can be determined relative to *ulInitialCount* using *ulDispensedCount*, *ulRetractedCount* and the CIM *ulCashInCount*, e.g.  $\text{Number of Notes} = \text{ulInitialCount} - \text{ulDispensedCount} + \text{ulRetractedCount} + \text{CIM::ulCashInCount}$ .

### Threshold Events

The threshold event `WFS_USRE_CDM_CASHUNITTHRESHOLD` can be triggered either by hardware sensors in the device or by the *ulCount* reaching the *ulMinimum* or *ulMaximum* value.

The application can check if the device has this capability by querying the *bHardwareSensors* field of the physical cash unit structure. If any of the physical cash units associated with the logical cash unit have this capability, then threshold events based on hardware sensors can be triggered.

In the situation where the cash unit is associated with multiple physical cash units, if the Service Provider has the capability, the WFS\_SRVE\_CDM\_CASHUNITINFOCHANGED event may be generated when any of the physical cash units reaches the threshold. When the final physical cash unit reaches the threshold, the WFS\_USRE\_CDM\_CASHUNITTHRESHOLD event will be generated.

### Exchanges

If a physical cash unit is inserted (including removal followed by a reinsertion) when the device is not in the exchange state the *usStatus* of the physical cash unit will be set to WFS\_CDM\_STATCUMANIP and the values of the physical cash unit prior to its' removal will be returned in any subsequent WFS\_INF\_CDM\_CASH\_UNIT\_INFO command. The physical cash unit will not be used in any operation. The application must perform an exchange operation specifying the new values for the physical cash unit in order to recover the situation.

On recycling and retract units the counts and status are consistently reported on both the CDM and CIM interfaces. When a value is changed through an exchange on one interface it is also changed on the other.

### Recyclers

The CDM interface does not report cash-in only cash units but does report cash units which are shared with the CIM, i.e. recycling cash units (WFS\_CDM\_TYPERECYCLING) and reject/retract cash units (WFS\_CDM\_TYPEREJECTCASSETTE / WFS\_CDM\_TYPERETRACTCASSETTE). The CIM interface reports all cash units of all types, including those that can only be used by commands on the CDM interface.

**Input Param** None.

**Output Param** LPWFSCDMCUINFO lpCashUnitInfo;

```
typedef struct _wfs_cdm_cu_info
{
    USHORT                usTellerID;
    USHORT                usCount;
    LPWFSCDMCASHUNIT     *lppList;
} WFS_CDMCUINFO, *LPWFSCDMCUINFO;
```

#### *usTellerID*

This field is not used in this command and is always zero.

#### *usCount*

Specifies the number of cash unit structures returned.

#### *lppList*

Pointer to an array of pointers to WFS\_CDMCASHUNIT structures:

```
typedef struct _wfs_cdm_cashunit
{
    USHORT                usNumber;
    USHORT                usType;
    LPSTR                 lpszCashUnitName;
    CHAR                  cUnitID[5];
    CHAR                  cCurrencyID[3];
    ULONG                 ulValues;
    ULONG                 ulInitialCount;
    ULONG                 ulCount;
    ULONG                 ulRejectCount;
    ULONG                 ulMinimum;
    ULONG                 ulMaximum;
    BOOL                  bAppLock;
    USHORT                usStatus;
    USHORT                usNumPhysicalCUs;
    LPWFSCDMPHCU         *lppPhysical;
    ULONG                 ulDispensedCount;
    ULONG                 ulPresentedCount;
    ULONG                 ulRetractedCount;
} WFS_CDM_CASHUNIT, *LPWFSCDM_CASHUNIT;
```

*usNumber*

Index number of the cash unit structure. Each structure has a unique logical number starting with a value of one (1) for the first structure, and incrementing by one for each subsequent structure.

*usType*

Type of cash unit. Possible values are:

Value	Meaning
WFS_CDM_TYPENA	Not applicable. Typically means cash unit is missing.
WFS_CDM_TYPEREJECTCASSETTE	Reject cash unit. This type will also indicate a combined reject/retract cash unit.
WFS_CDM_TYPEBILLCASSETTE	Cash unit containing bills.
WFS_CDM_TYPECOINCYLINDER	Coin cylinder.
WFS_CDM_TYPECOINDISPENSER	Coin dispenser as a whole unit.
WFS_CDM_TYPERETRACTCASSETTE	Retract cash unit.
WFS_CDM_TYPECOUPON	Cash unit containing coupons or advertising material.
WFS_CDM_TYPEREDOCUMENT	Cash unit containing documents.
WFS_CDM_TYPEREPCONTAINER	Replenishment container. A cash unit can be refilled from a replenishment container.
WFS_CDM_TYPERECYCLING	Recycling cash unit. This unit is only present when the device is a compound device with a CIM.

*lpszCashUnitName*

A name which helps to identify the logical type of the cash unit. This is especially useful in the case of cash units of type WFS\_CDM\_TYPEREDOCUMENT where different documents can have the same currency and value. For example, travelers checks and bank checks may have the same currency and value but still need to be identifiable as different types of document. Where this value is not relevant (e.g. in bill cash units) the pointer will be NULL. This value is persistent.

*cUnitID*

The Cash Unit Identifier.

*cCurrencyID*

A three character array storing the ISO format [Ref. 2] Currency ID. This value will be an array of three ASCII 0x20h characters for cash units which contain items of more than one currency type or items to which currency is not applicable. If the *usStatus* field for this cash unit is WFS\_CDM\_STATCUNOVAL it is the responsibility of the application to assign a value to this field. This value is persistent.

#### *ulValues*

Supplies the value of a single item in the cash unit. This value is expressed in minimum dispense units [see Section WFS\_INF\_CDM\_CURRENCY\_EXP]. If the *cCurrencyID* field for this cash unit is empty, then this field will contain zero. If the *usStatus* field for this cash unit is WFS\_CDM\_STATCUNOVAL it is the responsibility of the application to assign a value to this field. This value is persistent.

#### *ulInitialCount*

Initial number of items contained in the cash unit. This value is persistent.

#### *ulCount*

The meaning of this count depends on the type of cash unit. This value is persistent.

For all cash units except retract cash units (*usType* is not WFS\_CDM\_TYPERETRACTCASSETTE) this value specifies the number of items inside all the physical cash units associated with this cash unit.

For all dispensing cash units (*usType* is WFS\_CDM\_TYPEBILLCASSETTE, WFS\_CDM\_TYPECOINCYLINDER, WFS\_CDM\_TYPECOINDISPENSER, WFS\_CDM\_TYPECOUPON, WFS\_CDM\_TYPEREDOCUMENT or WFS\_CDM\_TYPERECYCLING), this value includes any items from the physical cash units not yet presented to the customer. This count is decremented when the items are either presented to the customer or rejected.

If the cash unit is usable from the CIM interface (*usType* is WFS\_CDM\_TYPERECYCLING, WFS\_CDM\_TYPERETRACTCASSETTE or WFS\_CDM\_TYPEREJECTCASSETTE) then this value will be incremented as a result of a Cash-In operation.

Note that for a reject cash unit (*usType* is WFS\_CDM\_TYPEREJECTCASSETTE), this value is unreliable, since the typical reason for dumping items to the reject cash unit is a suspected count failure.

For a retract cash unit (*usType* is WFS\_CDM\_TYPERETRACTCASSETTE) this value specifies the number of retract operations (CDM commands, CIM commands and error recoveries) which result in items entering the cash unit.

#### *ulRejectCount*

The number of items from this cash unit which are in the reject bin. This value may be unreliable, since the typical reason for dumping items to the reject cash unit is a suspected pick failure. For reject and retract cash units (*usType* is WFS\_CDM\_TYPEREJECTCASSETTE or WFS\_CDM\_TYPERETRACTCASSETTE) this parameter does not apply and will be reported as zero. This value is persistent.

#### *ulMinimum*

This field is not applicable to Retract and Reject Cash Units. For all other cash units, when *ulCount* reaches this value the threshold event WFS\_USRE\_CDM\_CASHUNITTHRESHOLD (WFS\_CDM\_STATCULOW) will be generated. If this value is non-zero then hardware sensors in the device do not trigger threshold events. If this value is zero then hardware sensors may trigger threshold events. This value is persistent.

#### *ulMaximum*

This field is only applicable to Retract and Reject Cash Units. When *ulCount* reaches this value the threshold event WFS\_USRE\_CDM\_CASHUNITTHRESHOLD (WFS\_CDM\_STATCUHIGH) will be generated. If this value is non-zero then hardware sensors in the device do not trigger threshold events. If this value is zero then hardware sensors may trigger threshold events. This value is persistent.

#### *bAppLock*

This field does not apply to reject or retract cash units. If this value is TRUE items cannot be dispensed from the cash unit. If this value is TRUE and the application attempts to dispense from the cash unit a WFS\_EXEE\_CDM\_CASHUNITERROR event will be generated and a WFS\_ERR\_CDM\_CASHUNITERROR code will be returned.

#### *usStatus*

Supplies the status of the cash unit as one of the following values:

Value	Meaning
WFS_CDM_STATCUOK	The cash unit is in a good state.
WFS_CDM_STATCUFULL	The cash unit is full. This value only applies to cash units where <i>usType</i> is WFS_CDM_TYPEREJECTCASSETTE or WFS_CDM_TYPERETRACTCASSETTE.
WFS_CDM_STATCUHIGH	The cash unit is almost full (i.e. reached or exceeded the threshold defined by <i>ulMaximum</i> ). This value only applies to cash units where <i>usType</i> is WFS_CDM_TYPEREJECTCASSETTE or WFS_CDM_TYPERETRACTCASSETTE.
WFS_CDM_STATCULOW	The cash unit is almost empty (i.e. reached or below the threshold defined by <i>ulMinimum</i> ). This value does not apply to cash units where <i>usType</i> is WFS_CDM_TYPEREJECTCASSETTE or WFS_CDM_TYPERETRACTCASSETTE.
WFS_CDM_STATCUEMPTY	The cash unit is empty, or insufficient items in the cash unit are preventing further dispense operations. This does not apply to cash units where <i>usType</i> is WFS_CDM_TYPEREJECTCASSETTE or WFS_CDM_TYPERETRACTCASSETTE.
WFS_CDM_STATCUINOP	The cash unit is inoperative.
WFS_CDM_STATCUMISSING	The cash unit is missing.
WFS_CDM_STATCUNOVAL	The values of the specified cash unit are not available.
WFS_CDM_STATCUNOREF	There is no reference value available for the notes in this cash unit. The cash unit has not been calibrated.
WFS_CDM_STATCUMANIP	The cash unit has been inserted (including removal followed by a reinsertion) when the device was not in the exchange state. This cash unit cannot be dispensed from.

*ulDispensedCount*

The number of items dispensed from all the physical cash units associated with this cash unit. This count is incremented when the items are removed from any of the associated physical cash units. This count includes any items that were rejected during the dispense operation. This field is always zero for cash units with a *usType* of WFS\_CDM\_TYPEREJECTCASSETTE or WFS\_CDM\_TYPERETRACTCASSETTE. This value is persistent.

*ulPresentedCount*

The number of items from all the physical cash units associated with this cash unit that have been presented to the customer. This count is incremented when the items are presented to the customer. If it is unknown if a customer has been presented with the items, then this count is not updated. This field is always zero for cash units with a *usType* of WFS\_CDM\_TYPEREJECTCASSETTE or WFS\_CDM\_TYPERETRACTCASSETTE. This value is persistent.

*ulRetractedCount*

The number of items that have been retracted into all the physical cash units associated with this cash unit. This value is persistent.

*usNumPhysicalCUs*

The number of physical cash unit structures returned in the following *lppPhysical* array. This number must be at least 1.

*lpPhysical*

Pointer to an array of pointers to WFSCDMPHCU structures:

```
typedef struct _wfs_cdm_physicalcu
{
    LPSTR                lpPhysicalPositionName;
    CHAR                 cUnitID[5];
    ULONG               ulInitialCount;
    ULONG               ulCount;
    ULONG               ulRejectCount;
    ULONG               ulMaximum;
    USHORT              usPStatus;
    BOOL                bHardwareSensor;
    ULONG               ulDispensedCount;
    ULONG               ulPresentedCount;
    ULONG               ulRetractedCount;
} WFSCDMPHCU, *LPWFSCDMPHCU;
```

*lpPhysicalPositionName*

A name identifying the physical location of the cash unit within the CDM. This field can be used by CDMs which are compound with a CIM to identify shared cash units.

*cUnitID*

A 5 character array uniquely identifying the physical cash unit.

*ulInitialCount*

Initial number of items contained in the cash unit. This value is persistent.

*ulCount*

As defined by the logical *ulCount* description but applies to a single physical cash unit, but with the following exceptions:

This count does not include items dispensed but not yet presented.

On cash units belonging to logical cash units with *usType* set to WFS\_CDM\_TYPERETRACTCASSETTE the physical count represents the number of items, unless the device cannot count items during a retract, in which case this count will be zero.

This value is persistent.

*ulRejectCount*

As defined by the logical *ulRejectCount* description but applies to a single physical cash unit. This value is persistent.

*ulMaximum*

The maximum number of items the cash unit can hold. This is only for informational purposes. No threshold event WFS\_USRE\_CDM\_CASHUNITTHRESHOLD will be generated. This value is persistent.

*usPStatus*

Supplies the status of the physical cash unit as one of the following values:

Value	Meaning
WFS_CDM_STATCUOK	The cash unit is in a good state.
WFS_CDM_STATCUFULL	The cash unit is full. This value only applies to cash units where <i>usType</i> is WFS_CDM_TYPEREJECTCASSETTE or WFS_CDM_TYPERETRACTCASSETTE.
WFS_CDM_STATCUHIGH	The cash unit is almost full (reached or exceeded threshold defined by <i>ulMaximum</i> ). This value only applies to cash units where <i>usType</i> is WFS_CDM_TYPEREJECTCASSETTE or WFS_CDM_TYPERETRACTCASSETTE.

WFS_CDM_STATCULOW	The cash unit is almost empty. This value does not apply to cash units where <i>usType</i> is WFS_CDM_TYPE-REJECTCASSETTE or WFS_CDM_TYPERETRACT-CASSETTE.
WFS_CDM_STATCUEMPTY	The cash unit is empty, or insufficient items in the cash unit are preventing further dispense operations. This value does not apply to cash units where <i>usType</i> is WFS_CDM_TYPE-REJECTCASSETTE or WFS_CDM_TYPERETRACT-CASSETTE.
WFS_CDM_STATCUINOP	The cash unit is inoperative.
WFS_CDM_STATCUMISSING	The cash unit is missing. The cash unit has been removed and is physically not present in the machine.
WFS_CDM_STATCUNOVAL	The values of the specified cash unit are not available.
WFS_CDM_STATCUNOREF	There is no reference value available for the notes in this cash unit. The cash unit has not been calibrated.
WFS_CDM_STATCUMANIP	The cash unit has been inserted (including removal followed by a reinsertion) when the device was not in the exchange state. This cash unit cannot be dispensed from.

*bHardwareSensor*

Specifies whether or not threshold events can be generated based on hardware sensors in the device. If this value is TRUE for any of the physical cash units related to a logical cash unit then threshold events may be generated based on hardware sensors as opposed to logical counts.

*ulDispensedCount*

As defined by the logical *ulDispensedCount* description but applies to a single physical cash unit. This value is zero if the h/w does not support physical counts. This value is persistent.

*ulPresentedCount*

As defined by the logical *ulPresentedCount* description but applies to a single physical cash unit. This value is zero if the h/w does not support physical counts. This value is persistent.

*ulRetractedCount*

As defined by the logical *ulRetractedCount* description but applies to a single physical cash unit. This value is zero if the h/w does not support physical counts. This value is persistent.

**Error Codes** Only the generic error codes defined in [Ref. 1] can be generated by this command.

**Comments** None.



## 4.4 WFS\_INF\_CDM\_TELLER\_INFO

**Description** This command only applies to Teller CDMs. It allows the application to obtain counts for each currency assigned to the teller. These counts represent the total amount of currency dispensed by the teller in all transactions.

This command also enables the application to obtain the position assigned to each teller. If the input parameter is NULL, this command will return information for all tellers and all currencies. The teller information is persistent.

**Input Param** LPWFSCDMTELLERINFO lpTellerInfo;

```
typedef struct _wfs_cdm_teller_info
{
    USHORT          usTellerID;
    CHAR            cCurrencyID[3];
} WFS_CDM_TELLERINFO, *LPWFSCDMTELLERINFO;
```

*usTellerID*

Identification of the teller. If the value of *usTellerID* is not valid the error WFS\_ERR\_CDM\_INVALIDTELLERID is reported.

*cCurrencyID*

Three character ISO format currency identifier [Ref 2].

This parameter can be an array of three ASCII 0x20 characters. In this case information on all currencies will be returned.

**Output Param** LPWFSCDMTELLERDETAILS \*lppTellerDetails;

Pointer to a NULL-terminated array of pointers to WFS\_CDM\_TELLERDETAILS structures.

```
typedef struct _wfs_cdm_teller_details
{
    USHORT          usTellerID;
    ULONG           ulInputPosition;
    WORD            fwOutputPosition;
    LPWFSCDMTELLERTOTALS *lppTellerTotals;
} WFS_CDM_TELLERDETAILS, *LPWFSCDMTELLERDETAILS;
```

*usTellerID*

Identification of the teller.

*ulInputPosition*

The input position assigned to the teller for cash entry. This is only for compatibility except when the device is a compound device. The value is specified by one of the following values:

Value	Meaning
WFS_CDM_POSNULL	No position is assigned to the teller.
WFS_CDM_POSINLEFT	Left position is assigned to the teller.
WFS_CDM_POSINRIGHT	Right position is assigned to the teller.
WFS_CDM_POSINCENTER	Center position is assigned to the teller.
WFS_CDM_POSINTOP	Top position is assigned to the teller.
WFS_CDM_POSINBOTTOM	Bottom position is assigned to the teller.
WFS_CDM_POSINFRONT	Front position is assigned to the teller.
WFS_CDM_POSINREAR	Rear position is assigned to the teller.

*fwOutputPosition*

The output position from which cash is presented to the teller. The value is specified by one of the following values:

Value	Meaning
WFS_CDM_POSNULL	No position is assigned to the teller.
WFS_CDM_POSLEFT	Left position is assigned to the teller.
WFS_CDM_POSRIGHT	Right position is assigned to the teller.
WFS_CDM_POSCENTER	Center position is assigned to the teller.
WFS_CDM_POSTOP	Top position is assigned to the teller.
WFS_CDM_POSBOTTOM	Bottom position is assigned to the teller.

WFS\_CDM\_POSFRONT                      Front position is assigned to the teller.  
WFS\_CDM\_POSREAR                      Rear position is assigned to the teller.

*lppTellerTotals*

Pointer to a NULL-terminated array of pointers to WFSCDMTELLERTOTALS structures.

```
typedef struct _wfs_cdm_teller_totals
{
    CHAR                cCurrencyID[3];
    ULONG               ulItemsReceived;
    ULONG               ulItemsDispensed;
    ULONG               ulCoinsReceived;
    ULONG               ulCoinsDispensed;
    ULONG               ulCashBoxReceived;
    ULONG               ulCashBoxDispensed;
} WFSCDMTELLERTOTALS, *LPWFSCDMTELLERTOTALS;
```

*cCurrencyID*

Three character ISO format currency identifier [Ref. 2].

*ulItemsReceived*

The total amount of items (other than coins) of the specified currency accepted. The amount is expressed in minimum dispense units (see WFS\_INF\_CDM\_CURRENCY\_EXP).

*ulItemsDispensed*

The total amount of items (other than coins) of the specified currency dispensed. The amount is expressed in minimum dispense units (see WFS\_INF\_CDM\_CURRENCY\_EXP).

*ulCoinsReceived*

The total amount of coin currency accepted. The amount is expressed in minimum dispense units (see WFS\_INF\_CDM\_CURRENCY\_EXP).

*ulCoinsDispensed*

The total amount of coin currency dispensed. The amount is expressed in minimum dispense units (see WFS\_INF\_CDM\_CURRENCY\_EXP).

*ulCashBoxReceived*

The total amount of cash box currency accepted. The amount is expressed in minimum dispense units (see WFS\_INF\_CDM\_CURRENCY\_EXP).

*ulCashBoxDispensed*

The total amount of cash box currency dispensed. The amount is expressed in minimum dispense units (see WFS\_INF\_CDM\_CURRENCY\_EXP).

**Error Codes**      In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_INVALIDCURRENCY	Specified currency not currently available.
WFS_ERR_CDM_INVALIDTELLERID	Invalid Teller ID.

**Comments**      None.

## 4.5 WFS\_INF\_CDM\_CURRENCY\_EXP

---

**Description** This command returns each exponent assigned to each currency known to the Service Provider.

**Input Param** None.

**Output Param** LPWFSCDMCURRENCYEXP \*lppCurrencyExp;

Pointer to a NULL-terminated array of pointers to WFSCDMCURRENCYEXP structures:

```
typedef struct _wfs_cdm_currency_exp
{
    CHAR                cCurrencyID [3] ;
    SHORT               sExponent ;
} WFSCDMCURRENCYEXP, *LPWFSCDMCURRENCYEXP;
```

*cCurrencyID*

Currency identifier in ISO 4217 format [see Ref 2].

*sExponent*

Currency exponent in ISO 4217 format [see Ref. 2].

**Error Codes** Only the generic error codes defined in [Ref. 1] can be generated by this command.

**Comments** For each currency ISO 4217 defines the currency identifier (a three character code) and a currency unit (e.g., European Euro, Japanese Yen). In the interface defined by this specification, every money amount is specified in terms of multiples of the minimum dispense unit, which is equal to the currency unit times ten to the power of the currency exponent. Thus an amount parameter relates to the actual cash amount as follows:

$\langle \text{cash\_amount} \rangle = \langle \text{money\_amount\_parameter} \rangle * 10^{\langle \text{sExponent} \rangle}$

Example #1 - Euro

Currency identifier is 'EUR'

Currency unit is 1 Euro (= 100 Cent)

A Service Provider is developed for an ATM that can dispense coins down to one Cent. The currency exponent (*sExponent*) is set to -2 (minus two), so the minimum dispense unit is one Cent ( $1 * 10^{-2}$  Euro); all amounts at the XFS interface are in Cent. Thus a money amount parameter of 10050 is 100 Euro and 50 Cent.

Example #2 - Japan

Currency identifier is 'JPY'

Currency unit is 1 Japanese Yen

A Service Provider is required to dispense a minimum amount of 1000 Yen. The currency exponent (*sExponent*) is set to +3 (plus three), so the minimum dispense unit is 1000 Yen; all amounts at the XFS interface are in multiples of 1000 Yen. Thus an amount parameter of 15 is 15000 Yen.

## 4.6 WFS\_INF\_CDM\_MIX\_TYPES

---

**Description** This command is used to obtain a list of supported mix algorithms and available house mix tables.

**Input Param** None.

**Output Param** LPWFSCDMMIXTYPE \*lppMixTypes;

Pointer to a NULL-terminated array of pointers to WFSCDMMIXTYPE structures:

```
typedef struct _wfs_cdm_mix_type
{
    USHORT          usMixNumber;
    USHORT          usMixType;
    USHORT          usSubType;
    LPSTR           lpszName;
} WFSCDMMIXTYPE, *LPWFSCDMMIXTYPE;
```

*usMixNumber*

Number identifying the mix algorithm or the house mix table. This number can be passed to the WFS\_INF\_CDM\_MIX\_TABLE, WFS\_CMD\_CDM\_DISPENSE and WFS\_CMD\_CDM\_DENOMINATE commands.

*usMixType*

Specifies whether the mix type is an algorithm or a house mix table. Possible values are:

Value	Meaning
WFS_CDM_MIXALGORITHM	Mix algorithm.
WFS_CDM_MIXTABLE	Mix table.

*usSubType*

Contains a vendor-defined number that identifies the type of algorithm or table. Individual vendor-defined mix algorithms are defined above hexadecimal 7FFF. Mix algorithms which are provided by the Service Provider are in the range hexadecimal 8000 - 8999. Application defined mix algorithms start at hexadecimal 9000. All numbers below 8000 hexadecimal are reserved. Predefined values are:

Value	Meaning
WFS_CDM_MIX_MINIMUM_NUMBER_OF_BILLS	Select a mix requiring the minimum possible number of items.
WFS_CDM_MIX_EQUAL_EMPTYING_OF_CASH_UNITS	The denomination is selected based upon criteria which ensure that over the course of its operation the CDM cash units will empty as far as possible at the same rate and will therefore go LOW and then EMPTY at approximately the same time.
WFS_CDM_MIX_MAXIMUM_NUMBER_OF_CASH_UNITS	The denomination will be selected based upon criteria which ensures the maximum number of different logical cash units are used.

*lpszName*

Points to the name of the table/algorithm used.

**Error Codes** Only the generic error codes defined in [Ref. 1] can be generated by this command.

**Comments** None.

## 4.7 WFS\_INF\_CDM\_MIX\_TABLE

**Description** This command is used to obtain the house mix table specified by the supplied mix number.

**Input Param** LPUSHORT *lpusMixNumber*;

*lpusMixNumber*

Pointer to the number of the requested house mix table.

**Output Param** LPWFSCDMMIXTABLE *lpMixTable*;

```
typedef struct _wfs_cdm_mix_table
{
    USHORT                usMixNumber;
    LPSTR                 lpszName;
    USHORT                usRows;
    USHORT                usCols;
    LPULONG               lpulMixHeader;
    LPWFSCDMMIXROW       *lppMixRows;
} WFS_CDM_MIX_TABLE, *LPWFSCDMMIXTABLE;
```

*usMixNumber*

Number identifying the house mix table.

*lpszName*

Points to the name of the table.

*usRows*

Number of rows in the house mix table. There is at least one row for each distinct total amount to be denominated. If there is more than one row for an amount the first row is taken that is dispensable according to the current status of the cash units.

*usCols*

Number of columns in the house mix table. There is one column for each distinct item value included in the mix.

*lpulMixHeader*

Pointer to an array of length *usCols* of unsigned longs; each element defines the value of the item corresponding to its respective column (See WFS\_INF\_CDM\_CURRENCY\_EXP).

*lppMixRows*

Pointer to an array (of length *usRows*) of pointers to WFS\_CDM\_MIX\_ROW structures:

```
typedef struct _wfs_cdm_mix_row
{
    ULONG                ulAmount;
    LPUSHORT             lpusMixture;
} WFS_CDM_MIX_ROW, *LPWFSCDMMIXROW;
```

*ulAmount*

Amount denominated by this mix row (See WFS\_INF\_CDM\_CURRENCY\_EXP).

*lpusMixture*

Pointer to a mix row, an array of length *usCols* of unsigned integers; each element defines the quantity of each item denomination in the mix used in the denomination of *ulAmount*.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_INVALIDMIXNUMBER	The <i>lpusMixNumber</i> parameter does not correspond to a defined mix table.

**Comments** None.

## 4.8 WFS\_INF\_CDM\_PRESENT\_STATUS

---

**Description** This command is used to obtain the status of the most recent attempt to dispense and/or present items to the customer. The items may have been dispensed and/or presented as a result of the WFS\_CMD\_CDM\_PRESENT or WFS\_CMD\_CDM\_DISPENSE command. This status is not updated as a result of any other command that can dispense/present items.

This value is persistent and is valid until the next time an attempt is made to present or dispense items to the customer.

The denominations reported by this command may not accurately reflect the operation if the cash units have been re-configured (e.g. if the values associated with a cash unit are changed, or new cash units are configured).

**Input Param** LPWORD lpfwPosition;

*lpfwPosition*

Pointer to the output position the items were presented or dispensed to as one of the following values:

Value	Meaning
WFS_CDM_POSNULL	The items were presented according to the default configuration.
WFS_CDM_POSLEFT	The items were presented to the left output position.
WFS_CDM_POSRIGHT	The items were presented to the right output position.
WFS_CDM_POSCENTER	The items were presented to the center output position.
WFS_CDM_POSTOP	The items were presented to the top output position.
WFS_CDM_POSBOTTOM	The items were presented to the bottom output position.
WFS_CDM_POSFRONT	The items were presented to the front output position.
WFS_CDM_POSREAR	The items were presented to the rear output position.

**Output Param** LPWFSCDMPRESENTSTATUS lpPresentStatus;

```
typedef struct _wfs_cdm_present_status
{
    LPWFSCMDDENOMINATION    lpDenomination;
    WORD                    wPresentState;
    LPSTR                    lpszExtra;
} WFSCDMPRESENTSTATUS, *LPWFSCDMPRESENTSTATUS;
```

*lpDenomination*

Pointer to a WFSCDMDENOMINATION structure which contains the amount dispensed and the number of items dispensed from each cash unit. For a description of the WFSCDMDENOMINATION structure see the definition of the command WFS\_CMD\_CDM\_DENOMINATE.

Where mixed currencies were dispensed the *ulAmount* field in the returned denomination structure will be zero and the *cCurrency* field will be set to three ASCII 0x20 characters.

*wPresentState*

Supplies the status of the last dispense or present operation. Possible values are:

Value	Meaning
WFS_CDM_PRESENTED	The items were presented. This status is set as soon as the customer has access to the items.
WFS_CDM_NOTPRESENTED	The customer has not had access to the items.
WFS_CDM_UNKNOWN	It is not known if the customer had access to the items.

*lpzExtra*

Pointer to a list of vendor-specific, or any other extended, information. The information is returned as a series of “*key=value*” strings so that it is easily extensible by Service Providers. Each string is null-terminated, with the final string terminating with two null characters. An empty list may be indicated by either a NULL pointer or a pointer to two consecutive null characters.

**Error Codes** Only the generic error codes defined in [Ref. 1] can be generated by this command.

**Comments** None.

## 5. Execute Commands

---

### 5.1 WFS\_CMD\_CDM\_DENOMINATE

---

**Description** This command provides a denomination. A denomination specifies the number of items which are required from each cash unit in order to satisfy a given amount. The denomination depends upon the currency, the mix algorithm and any partial denomination supplied by the application.

This command can also be used to validate that any denomination supplied by the application can be dispensed.

If items of differing currencies are to be included in the same denomination then the currency field must be an array of three ASCII 0x20h characters, the amount must be zero and the mix number must be WFS\_CDM\_INDIVIDUAL. However, these restrictions do not apply if a single currency is combined with non-currency items, such as coupons.

If the *bCashBox* field of the WFS\_CDMCAPS structure returned by the WFS\_INF\_CDM\_CAPABILITIES command is TRUE then, if the entire denomination cannot be satisfied, a partial denomination will be returned with the remaining amount to be supplied from the teller's cash box.

This command can be used in four different ways:

1. In order to check that it is possible to dispense a given denomination. The input parameters to the command are currency and denomination, with a mix number of WFS\_CDM\_INDIVIDUAL and an amount of zero. If items of differing currencies are to be dispensed then the currency field should be an array of three ASCII 0x20h characters.
2. In order to validate that a given amount matches a given denomination and that it is possible to dispense the denomination. The input parameters to the command should be amount, currency and denomination, with a mix number of WFS\_CDM\_INDIVIDUAL.
3. In order to obtain a denomination of a given amount. The input parameters supplied should be amount, currency and mix number.
4. In order to complete a partial denomination of a given amount. In this case the input parameters to the command should be currency, amount, mix number and either a partially specified denomination or a minimum amount from the cash box. A completed denomination is returned. *ulCashBox* of the denomination structure may be updated as a result of this command.

**Input Param** LPWFSCDMDENOMINATE lpDenominate;

```
typedef struct _wfs_cdm_denominate
{
    USHORT          usTellerID;
    USHORT          usMixNumber;
    LPWFSCDMDENOMINATION lpDenomination;
} WFS_CDMDENOMINATE, *LPWFSCDMDENOMINATE;
```

*usTellerID*

Identification of teller. This parameter is ignored if the device is a Self-Service CDM.

*usMixNumber*

Mix algorithm or house mix table to be used.

*lpDenomination*

Pointer to a WFS\_CDMDENOMINATION structure, describing the contents of the denomination operation.

```
typedef struct _wfs_cdm_denomination
{
    CHAR          cCurrencyID[3];
    ULONG         ulAmount;
    USHORT       usCount;
    LPULONG      lpulValues;
    ULONG        ulCashBox;
} WFS_CDMDENOMINATION, *LPWFSCDMDENOMINATION;
```



*cCurrencyID*

Identification of currency in ISO format [see Ref. 2]. Where the denomination contains multiple currencies this field should be set to three ASCII 0x20 characters.

*ulAmount*

The amount to be denominated or dispensed. Where the denomination contains multiple currencies this value is zero.

*usCount*

The size of the *lpulValues* list. This *usCount* is the same as the *usCount* returned from the last WFS\_INF\_CDM\_CASH\_UNIT\_INFO command or set by the last WFS\_CMD\_CDM\_SET\_CASH\_UNIT\_INFO or WFS\_CMD\_CDM\_END\_EXCHANGE commands. If this value is not required because a mix algorithm is used then the *usCount* can be set to zero.

If the application passes in an invalid *usCount* the Service Provider should return a WFS\_ERR\_INVALID\_DATA return code.

*lpulValues*

Pointer to an array of ULONGs. This list specifies the number of items to take from each of the cash units. This list corresponds to the array of cash unit structures returned by the last WFS\_INF\_CDM\_CASH\_UNIT\_INFO command or set by the last WFS\_CMD\_CDM\_SET\_CASH\_UNIT\_INFO or WFS\_CMD\_CDM\_END\_EXCHANGE commands. The first value in the array is related to the cash structure with the index number 1.

This array contains a field for each possible cash unit. If a cash unit is not required in the denomination its corresponding field in this array should be set to zero.

If the application does not wish to specify a denomination, it should set the *lpulValues* pointer to NULL.

*ulCashBox*

Only applies to Teller CDM devices. Amount to be paid from the teller's cash box.

**Output Param** LPWFSCDMDENOMINATION lpDenomination;

For a description see the input structure.

Where mixed currencies are being denominated the *ulAmount* field in the returned denomination structure will be zero and the *cCurrency* field will be set to three ASCII 0x20 characters.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_INVALIDCURRENCY	There are no cash units in the CDM of the currency specified in the <i>cCurrency</i> field of the input parameter.
WFS_ERR_CDM_INVALIDTELLERID	Invalid teller ID. This error will never be generated by a Self-Service CDM.
WFS_ERR_CDM_CASHUNITERROR	There is a problem with a cash unit. A WFS_EXEE_CDM_CASHUNITERROR event will be posted with the details.
WFS_ERR_CDM_INVALIDDENOMINATION	The <i>usMixNumber</i> is WFS_CDM_INDIVIDUAL and the sum of the values for <i>ulCashBox</i> and the items specified by <i>lpulValues</i> does not match the non-zero amount specified. This error code is not used when the amount specified is zero.
WFS_ERR_CDM_INVALIDMIXNUMBER	Unknown mix algorithm.
WFS_ERR_CDM_NOCURRENCYMIX	The cash units specified in the denomination were not all of the same currency.
WFS_ERR_CDM_NOTDISPENSABLE	The amount is not dispensable by the CDM.
WFS_ERR_CDM_TOOMANYITEMS	The request requires too many items to be dispensed.
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM is in an exchange state (see WFS_CMD_CDM_START_EXCHANGE).

WFS\_ERR\_CDM\_NOCASHBOXPRESENT    Cash box amount needed, however teller is not assigned a Cash Box.

WFS\_ERR\_CDM\_AMOUNTNOTINMIXTABLE    A mix table is being used to determine the denomination but the amount specified for the denomination is not in the mix table.

**Events**    In addition to the generic event defined in [Ref. 1], the following events can be generated as a result of this command:

<u>Value</u>	<u>Meaning</u>
WFS_EXEE_CDM_CASHUNITERROR	An error occurred while attempting to denominate from the cash unit specified by the event.

**Comments**    None.

## 5.2 WFS\_CMD\_CDM\_DISPENSE

**Description** This command performs the dispensing of items to the customer. The command provides the same functionality as the WFS\_CMD\_CDM\_DENOMINATE command plus the additional functionality of dispensing the items. If items of differing currencies are to be dispensed then the currency field must be an array of three ASCII 0x20h characters, the amount must be zero and the mix number must be WFS\_CDM\_INDIVIDUAL. However, these restrictions do not apply if a single currency is dispensed with non-currency items, such as coupons.

The WFS\_CMD\_CDM\_DISPENSE command can be used in the following ways:

1. The input parameters to the command are amount, currency and denomination. The mix number is WFS\_CDM\_INDIVIDUAL. In this case, the denomination is checked for validity and, if valid, is dispensed.
2. The input parameters are amount, currency and mix number. In this case the amount is denominated and, if this succeeds, the items are dispensed.
3. If the amount is zero, but the currency and the denomination are supplied with a mix number of WFS\_CDM\_INDIVIDUAL the denomination is checked for validity and, if valid, is dispensed.
4. The command will calculate a partial denomination of a given amount and dispense the complete denomination. In this case the input parameters to the command should be currency, amount, mix number and either a partially specified denomination or a minimum amount from the cash box. The cashbox amount may be updated as a result of this command.

When more than one physical cash unit exists for a logical cash unit number, the device selects the actual physical cash unit to use in the dispense operation.

If the *bCashBox* field of the WFSCDMCAPS structure returned by the WFS\_INF\_CDM\_CAPABILITIES command is TRUE then, if the entire denomination cannot be satisfied, a partial denomination will be returned with the remaining amount to be supplied from the teller's cash box.

If the device is a Teller CDM, the input parameter *usPosition* can be set to WFS\_CDM\_POSNULL. If this is the case the *usTellerID* is used to perform the dispense operation to the assigned teller position.

The field *bPresent* of the WFSCDMDISPENSE structure determines whether items are actually presented to the user as part of the dispense operation. If this field is set to TRUE then the items will be moved to the exit slot, if it is FALSE the items will be moved to an intermediate stacker. In the second case it will be necessary to use the WFS\_CMD\_CDM\_PRESENT command to present the items to the user. If *bPresent* is set to FALSE then the *fwPosition* parameter is ignored. If the CDM does not have an intermediate stacker then *bPresent* is ignored.

**Input Param** LPWFSCDMDISPENSE lpDispense;

```
typedef struct _wfs_cdm_dispense
{
    USHORT          usTellerID;
    USHORT          usMixNumber;
    WORD            fwPosition;
    BOOL            bPresent;
    LPWFSCMDDENOMINATION lpDenomination;
} WFSCDMDISPENSE, *LPWFSCDMDISPENSE;
```

*usTellerID*

Identifies the teller. This parameter is ignored if the device is a Self-Service CDM.

*usMixNumber*

Mix algorithm or house mix table to be used to create a denomination of the supplied amount. If the value is WFS\_CDM\_INDIVIDUAL, the denomination supplied in the *lpDenomination* field is validated prior to the dispense operation. If it is found to be invalid no alternative denomination will be calculated.

*fwPosition*

Determines to which side the amount is dispensed. If the device is a Teller CDM this field is ignored and the output position associated with *usTellerID* is used. The value is specified by one of the following values:

Value	Meaning
WFS_CDM_POSNULL	The default configuration information is used. This can be either position dependent or teller dependent.
WFS_CDM_POSLEFT	Present items to left side of device.
WFS_CDM_POSRIGHT	Present items to right side of device.
WFS_CDM_POSCENTER	Present items to center output position.
WFS_CDM_POSTOP	Present items to the top output position.
WFS_CDM_POSBOTTOM	Present items to the bottom output position.
WFS_CDM_POSFRONT	Present items to the front output position.
WFS_CDM_POSREAR	Present items to the rear output position.

*bPresent*

If this field is set to TRUE then the items will be moved to the exit slot, if it is FALSE the items will be moved to an intermediate stacker.

*lpDenomination*

Pointer to a WFSCDMDENOMINATION structure, describing the denominations used for the dispense operation. For the WFSCDMDENOMINATION structure specification see the definition of the command WFS\_CMD\_CDM\_DENOMINATE.

**Output Param** LPWFSCDMDENOMINATION *lpDenomination*;

For the WFSCDMDENOMINATION structure specification see the definition of the command WFS\_CMD\_CDM\_DENOMINATE.

The values in this structure report the amount dispensed and the number of items dispensed from each cash unit.

Where mixed currencies are being dispensed the *ulAmount* field in the returned denomination structure will be zero and the *cCurrency* field will be set to three ASCII 0x20 characters.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_INVALIDCURRENCY	There are no cash units in the CDM of the currency specified in the <i>cCurrency</i> field of the input parameter.
WFS_ERR_CDM_INVALIDTELLERID	Invalid Teller ID. This error will never be generated by a Self-Service CDM.
WFS_ERR_CDM_CASHUNITERROR	There is a problem with a cash unit. The WFS_EXEE_CDM_CASHUNITERROR execute event is posted with the details.
WFS_ERR_CDM_INVALIDDENOMINATION	The sum of the values for cash box and cash units was greater than the amount specified.
WFS_ERR_CDM_INVALIDMIXNUMBER	Mix algorithm is not known.
WFS_ERR_CDM_NOCURRENCYMIX	Cash units containing two or more different currencies were selected.
WFS_ERR_CDM_NOTDISPENSABLE	The amount is not dispensable by the CDM.
WFS_ERR_CDM_TOOMANYITEMS	The request would require too many items to be dispensed. This error is also generated if <i>bPresent</i> is FALSE and sub-dispensing is required.
WFS_ERR_CDM_UNSUPPOSITION	The specified output position is not supported.
WFS_ERR_CDM_SAFEDOOROPEN	The safe door is open. This device requires the safe door to be closed in order to perform this operation.
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM is in an exchange state.

WFS_ERR_CDM_NOCASHBOXPRESENT	Cash box amount needed, however teller is not assigned a Cash Box.
WFS_ERR_CDM_AMOUNTNOTINMIXTABLE	A mix table is being used to determine the denomination but the amount specified for the denomination is not in the mix table.
WFS_ERR_CDM_ITEMSNOTTAKEN	Items have not been taken during a sub-dispense operation. This error occurs if a hardware timeout expires.
WFS_ERR_CDM_ITEMSLEFT	Items have been left in the transport or exit slot as a result of a prior Dispense, Present or Recycler Cash-In operation.

If the *bPresent* field of the WFSCDMDISPENSE structure is TRUE, the following error codes can also be returned:

WFS_ERR_CDM_SHUTTERNOTOPEN	The shutter is not open or did not open when it should have. No items presented.
WFS_ERR_CDM_SHUTTEROPEN	The shutter is open when it should be closed. No items presented.
WFS_ERR_CDM_PRERRORNOITEMS	An error occurred while items were being moved to the exit slot - no items are presented.
WFS_ERR_CDM_PRERRORITEMS	An error occurred while items were being moved to the exit slot - at least some of the items have been presented.
WFS_ERR_CDM_PRERRORUNKNOWN	An error occurred while items were being moved to the exit slot - the position of the items is unknown. Intervention may be required to reconcile the cash amount totals.

**Events**

In addition to the generic events defined in [Ref. 1], the following events can be generated as a result of this command:

Value	Meaning
WFS_USRE_CDM_CASHUNITTHRESHOLD	A threshold condition has been reached in one of the cash units.
WFS_EXEE_CDM_DELAYEDDISPENSE	The dispense operation will be delayed by the specified time.
WFS_EXEE_CDM_STARTDISPENSE	Fired when the delayed dispense operation starts.
WFS_EXEE_CDM_CASHUNITERROR	A cash unit caused an error during a dispense operation.
WFS_SRVE_CDM_ITEMSTAKEN	The user has removed the items presented. If the dispense is not a sub-dispense this event occurs after the completion of the dispense command.
WFS_EXEE_CDM_PARTIALDISPENSE	Indicates that the dispense operation is to be divided into several sub-dispense operations.
WFS_EXEE_CDM_SUBDISPENSEOK	A sub-dispense operation was completed successfully.
WFS_EXEE_CDM_INCOMPLETEDISPENSE	It has not been possible to dispense the entire denomination but part of the denomination has been dispensed, whether on the intermediate stacker or in customer access. The return error code will be WFS_ERR_CDM_NOTDISPENSABLE.
WFS_EXEE_CDM_NOTEERROR	An item detection error has occurred.
WFS_EXEE_CDM_INPUT_P6	ECB6 Level 2 and/or level 3 notes have been detected.

**Comments**      None.

### 5.3 WFS\_CMD\_CDM\_COUNT

**Description** This command empties the specified physical cash unit(s). All items dispensed from the cash unit are counted and moved to the specified output location.

The number of items counted can be different from the number of items dispensed in cases where the CDM has the ability to detect this information. If the CDM cannot differentiate between what is dispensed and what is counted then *ulDispensed* will be the same as *ulCounted*.

Upon successful WFS\_CMD\_CDM\_COUNT command execution the physical cash unit(s) *ulCount* field within the WFSCDMPHCU structure is reset.

**Input Param** LPWFSCDMPHYSICALCU lpPhysicalCU;

```
typedef struct _wfs_cdm_physical_cu
{
    BOOL                bEmptyAll;
    WORD                fwPosition;
    LPSTR               lpPhysicalPositionName;
} WFSCDMPHYSICALCU, *LPWFSCDMPHYSICALCU;
```

*bEmptyAll*

Specifies whether all physical cash units are to be emptied. If this value is TRUE then *lpPhysicalPositionName* is ignored.

*fwPosition*

Specifies the location to which items should be moved. The value is set to one of the following values:

Value	Meaning
WFS_CDM_POSNULL	Output location is determined by Service Provider.
WFS_CDM_POSLEFT	Present items to left side of device.
WFS_CDM_POSRIGHT	Present items to right side of device.
WFS_CDM_POSCENTER	Present items to center output position.
WFS_CDM_POSTOP	Present items to the top output position.
WFS_CDM_POSBOTTOM	Present items to the bottom output position.
WFS_CDM_POSFRONT	Present items to the front output position.
WFS_CDM_POSREAR	Present items to the rear output position.
WFS_CDM_POSREJECT	Reject bin is used as output location.

*lpPhysicalPositionName*

Specifies which physical cash unit to empty and count. This name is the same as the *lpPhysicalPositionName* in the WFSCDMPHCU structure.

**Output Param** LPWFSCDMCOUNT lpCount;

```
typedef struct _wfs_cdm_count
{
    USHORT              usNumPhysicalCUs;
    LPWFSCDMCOUNTEDPHYSUCU *lppCountedPhysCUs;
} WFSCDMCOUNT, *LPWFSCDMCOUNT;
```

*usNumPhysicalCUs*

This value indicates the number of physical cash unit structures (WFSCDMCOUNTEDPHYSUCU) returned. This value will always be greater than zero.

*lppCountedPhysCUs*

Pointer to an array of pointers to WFSCDMCOUNTEDPHYSUCU structures:

```
typedef struct _wfs_cdm_counted_phys_cu
{
    LPSTR              lpPhysicalPositionName;
    CHAR               cUnitId[5];
    ULONG              ulDispensed;
    ULONG              ulCounted;
    USHORT             usPStatus;
} WFSCDMCOUNTEDPHYSUCU, *LPWFSCDMCOUNTEDPHYSUCU;
```

*lpPhysicalPositionName*

Specifies which physical cash unit was emptied and counted. This name is that defined in the *lpPhysicalPositionName* field of the WFSCDMPHCU structure.

*cUnitID*

Cash unit ID. This is the identifier defined in the *cUnitID* field of the WFSCDMPHCU structure.

*ulDispensed*

The number of items that were dispensed during the emptying of the cash unit.

*ulCounted*

The number of items that were counted during the emptying of the cash unit.

*usPStatus*

Supplies the status of the physical cash unit as one of the following values:

Value	Meaning
WFS_CDM_STATCUOK	The cash unit is in a good state.
WFS_CDM_STATCUFULL	The cash unit is full.
WFS_CDM_STATCUHIGH	The cash unit is almost full (reached or exceeded the threshold defined by WFSCDMCASHUNIT. <i>ulMaximum</i> ).
WFS_CDM_STATCULOW	The cash unit is almost empty.
WFS_CDM_STATCUEMPTY	The cash unit is empty.
WFS_CDM_STATCUINOP	The cash unit is inoperative.
WFS_CDM_STATCUMISSING	The cash unit is missing.
WFS_CDM_STATCUNOVAL	The values of the specified cash unit are not available.
WFS_CDM_STATCUNOREF	There is no reference value available for the notes in this cash unit.
WFS_CDM_STATCUMANIP	The cash unit has been inserted (including removal followed by a reinsertion) when the device was not in the exchange state. This cash unit cannot be dispensed from.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_CASHUNITERROR	A cash unit caused a problem. A WFS_EXEE_CDM_CASHUNITERROR event will be posted with the details.
WFS_ERR_CDM_UNSUPPOSITION	The position specified is not supported.
WFS_ERR_CDM_SAFEDOOROPEN	The safe door is open. This device requires the safe door to be closed in order to perform this operation.
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM service is in an exchange state.

**Events** In addition to the generic events defined in [Ref. 1], the following events can be generated as a result of this command:

Value	Meaning
WFS_EXEE_CDM_CASHUNITERROR	A cash unit caused an error during the count operation.
WFS_SRVE_CDM_ITEMSTAKEN	The items emptied to the output location have been removed by the user.
WFS_SRVE_CDM_ITEMSPRESENTED	Items have been emptied to the output location. These items may need to be removed from the output location before the operation can continue.
WFS_EXEE_CDM_NOTEERROR	An Items detection error has occurred.
WFS_EXEE_CDM_INPUT_P6	ECB6 Level 2 and/or level 3 notes have been detected.

**Comments**      None.



## 5.4 WFS\_CMD\_CDM\_PRESENT

**Description** This command will move items to the exit position for removal by the user. If a shutter exists, then it will be implicitly controlled during the present operation, even if the *bShutterControl* capability is set to FALSE. The shutter will be closed when the user removes the items or the items are retracted. If *lpfwPosition* points to WFS\_CDM\_POSNULL the position set in the WFS\_CMD\_CDM\_DISPENSE command which caused these items to be dispensed will be used.

When this command successfully completes the items are in customer access.

**Input Param** LPWORD *lpfwPosition*

*lpfwPosition*

Pointer to the output position where the amount is to be presented. The value is set to one of the following values:

Value	Meaning
WFS_CDM_POSNULL	The default configuration information is used. This can be either position dependent or teller dependent.
WFS_CDM_POSLEFT	Present items to left side of device.
WFS_CDM_POSRIGHT	Present items to right side of device.
WFS_CDM_POSCENTER	Present items to center output position.
WFS_CDM_POSTOP	Present items to the top output position.
WFS_CDM_POSBOTTOM	Present items to the bottom output position.
WFS_CDM_POSFRONT	Present items to the front output position.
WFS_CDM_POSREAR	Present items to the rear output position.

**Output Param** None.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_SHUTTERNOTOPEN	The shutter did not open when it should have. No items presented.
WFS_ERR_CDM_SHUTTEROPEN	The shutter is open when it should be closed. No items presented.
WFS_ERR_CDM_NOITEMS	There are no items on the stacker.
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM service is in an exchange state.
WFS_ERR_CDM_PRERRORNOITEMS	There was an error during the present operation - no items were presented.
WFS_ERR_CDM_PRERRORITEMS	There was an error during the present operation - at least some of the items were presented.
WFS_ERR_CDM_PRERRORUNKNOWN	There was an error during the present operation - the position of the items is unknown. Intervention may be required to reconcile the cash amount totals.
WFS_ERR_CDM_UNSUPPOSITION	The position specified is not supported.

**Events** In addition to the generic events defined in [Ref. 1], the following events can be generated as a result of this command:

Value	Meaning
WFS_USRE_CDM_CASHUNITTHRESHOLD	A threshold condition has been reached in one of the cash units.
WFS_SRVE_CDM_ITEMSTAKEN	The items have been removed by the user. This event is generated after the completion of the present operation.
WFS_EXEE_CDM_INPUT_P6	ECB6 Level 2 and/or level 3 notes have been detected.

**Comments** None.

## 5.5 WFS\_CMD\_CDM\_REJECT

---

**Description** This command will move items from the intermediate stacker and transport them to the reject cash unit (i.e. a cash unit with *usType* WFS\_CDM\_TYPEREJECTCASSETTE). The *ulCount* parameter of the reject cash unit is incremented by the number of items that were thought to be present at the time of the reject or the number counted by the device during the reject. Note that the reject bin count is unreliable.

**Input Param** None.

**Output Param** None.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_CASHUNITERROR	The reject cash unit caused a problem. A WFS_EXEE_CDM_CASHUNITERROR event will be posted with the details.
WFS_ERR_CDM_NOITEMS	There were no items on the stacker.
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM service is in an exchange state.

**Events** In addition to the generic events defined in [Ref. 1], the following events can be generated as a result of this command:

Value	Meaning
WFS_USRE_CDM_CASHUNITTHRESHOLD	A reject bin threshold condition has been reached.
WFS_EXEE_CDM_CASHUNITERROR	A cash unit caused an error during the reject operation.
WFS_EXEE_CDM_INPUT_P6	ECB6 Level 2 and/or level 3 notes have been detected.

**Comments** None.

## 5.6 WFS\_CMD\_CDM\_RETRACT

**Description** This command will retract items which may have been in customer access. Retracted items will be moved to either a retract cash unit, the reject cash unit, an item cash unit, the transport or the intermediate stacker. After the items are retracted the shutter is closed automatically, even if the *bShutterControl* capability is set to FALSE.

If items are moved to a retract cash unit (i.e. a cash unit with *usType* WFS\_CDM\_TYPERETRACTCASSETTE), then the *ulCount* parameter of the retract cash unit must be incremented by 1 to specify the number of retracts. If items are moved to any other cash unit (e.g. a cash unit with *usType* WFS\_CDM\_TYPEREJECTCASSETTE) then the *ulCount* parameter of the cash unit must be incremented by the number of items that were present at the time the WFS\_CMD\_CDM\_RETRACT command was issued or the number counted by the device during the retract. Note that reject bin counts are unreliable.

The *bRetract* field of the WFS\_CDMCAPS structure specifies whether or not this command is supported.

**Input Param** LPWFSCDMRETRACT lpRetract;

```
typedef struct _wfs_cdm_retract
{
    WORD                fwOutputPosition;
    USHORT              usRetractArea;
    USHORT              usIndex;
} WFS_CDM_RETRACT, *LPWFSCDMRETRACT;
```

### *fwOutputPosition*

Specifies the output position from which to retract the items. The value is set to one of the following values:

Value	Meaning
WFS_CDM_POSNULL	The default configuration information should be used.
WFS_CDM_POSLEFT	Retract items from the left output position.
WFS_CDM_POSRIGHT	Retract items from the right output position.
WFS_CDM_POSCENTER	Retract items from the center output position.
WFS_CDM_POSTOP	Retract items from the top output position.
WFS_CDM_POSBOTTOM	Retract items from the bottom output position.
WFS_CDM_POSFRONT	Retract items from the front output position.
WFS_CDM_POSREAR	Retract items from the rear output position.

### *usRetractArea*

This value specifies the area to which the items are to be retracted. Possible values are:

Value	Meaning
WFS_CDM_RA_RETRACT	Retract the items to a retract cash unit.
WFS_CDM_RA_TRANSPORT	Retract the items to the transport.
WFS_CDM_RA_STACKER	Retract the items to the intermediate stacker area.
WFS_CDM_RA_REJECT	Retract the items to a reject cash unit.
WFS_CDM_RA_ITEMCASSETTE	Retract the items to the item cassettes, i.e. cassettes that can be dispensed from.

### *usIndex*

If *usRetractArea* is set to WFS\_CDM\_RA\_RETRACT this field is the logical retract position inside the container into which the cash is to be retracted. This logical number starts with a value of one (1) for the first retract position and increments by one for each subsequent position. If the container contains several logical retract cash units (of type WFS\_CDM\_TYPERETRACTCASSETTE in command WFS\_INF\_CDM\_CASH\_UNIT\_INFO), *usIndex* would be incremented from the first position of the first retract cash unit to the last position of the last retract cash unit defined in WFS\_CDM\_CUINFO. The maximum value of *usIndex* is the sum of WFS\_CDM\_CASHUNIT.*ulMaximum* of each retract cash unit. If *usRetractArea* is not set to WFS\_CDM\_RA\_RETRACT the value of this field is ignored.

**Output Param** None.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_CASHUNITERROR	The retract cash unit caused a problem. A WFS_EXEE_CDM_CASHUNITERROR event will be posted with the details.
WFS_ERR_CDM_NOITEMS	There were no items to retract.
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM is in an exchange state.
WFS_ERR_CDM_SHUTTERNOTCLOSED	The shutter failed to close.
WFS_ERR_CDM_ITEMSTAKEN	Items were present at the output position at the start of the operation, but were removed before the operation was complete - some or all of the items were not retracted.
WFS_ERR_CDM_INVALIDRETRACTPOSITION	The <i>usIndex</i> is not supported.
WFS_ERR_CDM_NOTRETRACTAREA	The retract area specified in <i>usRetractArea</i> is not supported.

**Events** In addition to the generic events defined in [Ref. 1], the following events can be generated as a result of this command:

Value	Meaning
WFS_USRE_CDM_CASHUNITTHRESHOLD	A threshold condition has been reached in the retract or reject cash unit.
WFS_EXEE_CDM_CASHUNITERROR	An error occurred while attempting to retract to the retract or reject cash unit.
WFS_SRVE_CDM_ITEMSTAKEN	The items presented have been removed by the user.
WFS_EXEE_CDM_INPUT_P6	ECB6 Level 2 and/or level 3 notes have been detected.

**Comments** None.

## 5.7 WFS\_CMD\_CDM\_OPEN\_SHUTTER

---

**Description** This command opens the shutter.

**Input Param** LPWORD *lpfwPosition*;

*lpfwPosition*

Pointer to the output position where the shutter is to be opened. If the application does not need to specify a shutter, this field can be set to NULL or its contents to WFS\_CMD\_POSNULL. The position can be set to one of the following values:

Value	Meaning
WFS_CMD_POSNULL	The default configuration information should be used.
WFS_CMD_POSLEFT	Open the shutter at the left output position.
WFS_CMD_POSRIGHT	Open the shutter at the right output position.
WFS_CMD_POSCENTER	Open the shutter at the center output position.
WFS_CMD_POSTOP	Open the shutter at the top output position.
WFS_CMD_POSBOTTOM	Open the shutter at the bottom output position.
WFS_CMD_POSFRONT	Open the shutter at the front output position.
WFS_CMD_POSREAR	Open the shutter at the rear output position.

**Output Param** None.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_UNSUPPOSITION	The position specified is not supported.
WFS_ERR_CDM_SHUTTERNOTOPEN	The shutter failed to open.
WFS_ERR_CDM_SHUTTEROPEN	The shutter was already open.
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM is in an exchange state.

**Events** Only the generic events defined in [Ref. 1] can be generated by this command.

**Comments** None.

## 5.8 WFS\_CMD\_CDM\_CLOSE\_SHUTTER

---

**Description** This command closes the shutter.

**Input Param** LPWORD *lpfwPosition*;

*lpfwPosition*

Pointer to the output position where the shutter is to be closed. If the application does not need to specify a shutter, this field can be set to NULL or its contents to WFS\_CDM\_POSNULL. The position can be set to one of the following values:

Value	Meaning
WFS_CDM_POSNULL	The default configuration information should be used.
WFS_CDM_POSLEFT	Close the shutter at the left output position.
WFS_CDM_POSRIGHT	Close the shutter at the right output position.
WFS_CDM_POSCENTER	Close the shutter at the center output position.
WFS_CDM_POSTOP	Close the shutter at the top output position.
WFS_CDM_POSBOTTOM	Close the shutter at the bottom output position.
WFS_CDM_POSFRONT	Close the shutter at the front output position.
WFS_CDM_POSREAR	Close the shutter at the rear output position.

**Output Param** None.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_UNSUPPOSITION	The position specified is not supported.
WFS_ERR_CDM_SHUTTERCLOSED	The shutter was already closed.
WFS_ERR_CDM_SHUTTERNOTCLOSED	The shutter failed to close.
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM is in an exchange state.

**Events** Only the generic events defined in [Ref. 1] can be generated by this command.

**Comments** None.

## 5.9 WFS\_CMD\_CDM\_SET\_TELLER\_INFO

---

**Description** This command allows the application to set the teller position and initialize counts for each currency assigned to the teller. The values set by this command are persistent. This command only applies to Teller CDMs.

**Input Param** LPWFSCDMTELLERUPDATE lpTellerUpdate;

```
typedef struct _wfs_cdm_teller_update
{
    USHORT                usAction;
    LPWFSCDMTELLERDETAILS lpTellerDetails;
} WFS_CDMTELLERUPDATE, *LPWFSCDMTELLERUPDATE;
```

*usAction*

The action to be performed specified as one of the following values:

Value	Meaning
WFS_CDM_CREATE_TELLER	A teller is to be added.
WFS_CDM_MODIFY_TELLER	Information about an existing teller is to be modified.
WFS_CDM_DELETE_TELLER	A teller is to be removed.

*lpTellerDetails*

For a specification of the structure WFS\_CDMTELLERDETAILS please refer to the WFS\_INF\_CDM\_TELLER\_INFO command.

**Output Param** None.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_INVALIDCURRENCY	The specified currency is not currently available.
WFS_ERR_CDM_INVALIDTELLERID	The teller ID is invalid. This error will never be generated by a Self-Service CDM.
WFS_ERR_CDM_UNSUPPOSITION	The position specified is not supported.
WFS_ERR_CDM_EXCHANGEACTIVE	The target teller is currently in the middle of an exchange operation.

**Events** In addition to the generic events defined in [Ref. 1], the following events can be generated as a result of this command:

Value	Meaning
WFS_SRVE_CDM_TELLERINFOCHANGED	Teller information has been created, modified or deleted.

**Comments** None.

## 5.10 WFS\_CMD\_CDM\_SET\_CASH\_UNIT\_INFO

---

<b>Description</b>	<p>This command is used to adjust information regarding the status and contents of the cash units present in the CDM.</p> <p>This command generates the service event WFS_SRVE_CDM_CASHUNITINFOCHANGED to inform applications that the information for a cash unit has been changed.</p> <p>This command can only be used to change software counters, thresholds and the application lock. All other fields in the input structure will be ignored.</p> <p>The following fields of the WFSCDMCASHUNIT structure may be updated by this command:</p> <p><i>ulInitialCount</i> <i>ulCount</i> <i>ulRejectCount</i> <i>ulMaximum</i> <i>ulDispensedCount</i> <i>ulPresentedCount</i> <i>ulRetractedCount</i> <i>ulMinimum</i> <i>bAppLock</i></p> <p>As may the following fields of the WFSCDMPHCU structure:</p> <p><i>ulInitialCount</i> <i>ulCount</i> <i>ulRejectCount</i> <i>ulDispensedCount</i> <i>ulPresentedCount</i> <i>ulRetractedCount</i></p> <p>Any other changes must be performed via an exchange operation.</p> <p>If the fields <i>ulCount</i> and <i>ulRejectCount</i> of <i>lppPhysical</i> are set to zero by this command, the application is indicating that it does not wish counts to be maintained for the physical cash units. Counts on the logical cash units will still be maintained and can be used by the application. If the physical counts are set by this command then the logical count will be the sum of the physical counts and any value sent as a logical count will be ignored.</p> <p>The values set by this command are persistent.</p>										
<b>Input Param</b>	<p>LPWFSCDMCUINFO lpCUInfo;</p> <p>The WFSCDMCUINFO structure is specified in the documentation of the WFS_INF_CDM_CASH_UNIT_INFO command.</p>										
<b>Output Param</b>	None.										
<b>Error Codes</b>	<p>In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:</p> <table border="0"> <thead> <tr> <th style="text-align: left; border-bottom: 1px solid black;">Value</th> <th style="text-align: left; border-bottom: 1px solid black;">Meaning</th> </tr> </thead> <tbody> <tr> <td>WFS_ERR_CDM_INVALIDTELLERID</td> <td>Invalid Teller ID. This error will never be generated by a Self-Service CDM.</td> </tr> <tr> <td>WFS_ERR_CDM_INVALIDCASHUNIT</td> <td>Invalid cash unit.</td> </tr> <tr> <td>WFS_ERR_CDM_EXCHANGEACTIVE</td> <td>The CDM is in an exchange state.</td> </tr> <tr> <td>WFS_ERR_CDM_CASHUNITERROR</td> <td>A problem occurred with a cash unit. A WFS_EXEE_CDM_CASHUNITERROR event will be posted with the details.</td> </tr> </tbody> </table>	Value	Meaning	WFS_ERR_CDM_INVALIDTELLERID	Invalid Teller ID. This error will never be generated by a Self-Service CDM.	WFS_ERR_CDM_INVALIDCASHUNIT	Invalid cash unit.	WFS_ERR_CDM_EXCHANGEACTIVE	The CDM is in an exchange state.	WFS_ERR_CDM_CASHUNITERROR	A problem occurred with a cash unit. A WFS_EXEE_CDM_CASHUNITERROR event will be posted with the details.
Value	Meaning										
WFS_ERR_CDM_INVALIDTELLERID	Invalid Teller ID. This error will never be generated by a Self-Service CDM.										
WFS_ERR_CDM_INVALIDCASHUNIT	Invalid cash unit.										
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM is in an exchange state.										
WFS_ERR_CDM_CASHUNITERROR	A problem occurred with a cash unit. A WFS_EXEE_CDM_CASHUNITERROR event will be posted with the details.										
<b>Events</b>	<p>In addition to the generic events defined in [Ref. 1], the following events can be generated as a result of this command:</p> <table border="0"> <thead> <tr> <th style="text-align: left; border-bottom: 1px solid black;">Value</th> <th style="text-align: left; border-bottom: 1px solid black;">Meaning</th> </tr> </thead> <tbody> <tr> <td>WFS_USRE_CDM_CASHUNITTHRESHOLD</td> <td>A threshold condition has been reached in one of the cash units.</td> </tr> </tbody> </table>	Value	Meaning	WFS_USRE_CDM_CASHUNITTHRESHOLD	A threshold condition has been reached in one of the cash units.						
Value	Meaning										
WFS_USRE_CDM_CASHUNITTHRESHOLD	A threshold condition has been reached in one of the cash units.										



WFS\_SRVE\_CDM\_CASHUNITINFOCHANGED

A cash unit was updated as a result of this command.

WFS\_EXEE\_CDM\_CASHUNITERROR

An error occurred while accessing a cash unit.

**Comments**      None.

## 5.11 WFS\_CMD\_CDM\_START\_EXCHANGE

---

**Description** This command puts the CDM in an exchange state, i.e. a state in which cash units can be emptied, replenished, removed or replaced. Other than the updates which can be made via the WFS\_CMD\_CDM\_SET\_CASH\_UNIT\_INFO command all changes to a cash unit must take place while the cash unit is in an exchange state.

This command returns current cash unit information in the form described in the documentation of the WFS\_INF\_CDM\_CASH\_UNIT\_INFO command. This command will also initiate any physical processes which may be necessary to make the cash units accessible. Before using this command an application should first have ensured that it has exclusive control of the CDM.

This command may return WFS\_SUCCESS even if WFS\_EXEE\_CDM\_CASHUNITERROR events are generated. If this command returns WFS\_SUCCESS or WFS\_ERR\_CDM\_EXCHANGEACTIVE the CDM is in an exchange state.

While in an exchange state the CDM will process all WFS requests but exclude WFS[Async]Execute commands, except those listed below:

WFS\_CMD\_CDM\_END\_EXCHANGE

WFS\_CMD\_CDM\_SET\_MIX\_TABLE

Any other WFS[Async]Execute commands will result in the error WFS\_ERR\_CDM\_EXCHANGEACTIVE being generated.

If an error is returned by this command, the WFS\_CMD\_CDM\_CASH\_UNIT\_INFO command should be used to determine cash unit information.

If the CDM is part of a compound device together with a CIM (i.e. a cash recycler), exchange operations can either be performed separately on each interface to the compound device, or the entire exchange operation can be done through the CIM interface.

### Exchange via CDM and CIM interfaces

If the exchange is performed separately via the CDM and CIM interfaces then these operations cannot be performed simultaneously. An exchange state must therefore be initiated on each interface in the following sequence:

CDM

(Lock)  
WFS\_CMD\_CDM\_START\_EXCHANGE  
...exchange action...  
WFS\_CMD\_CDM\_END\_EXCHANGE  
(Unlock)

CIM

(Lock)  
WFS\_CMD\_CIM\_START\_EXCHANGE  
...exchange action...  
WFS\_CMD\_CIM\_END\_EXCHANGE  
(Unlock)

In the case of a recycler, the cash-in cash unit counts are set via the CIM interface and the cash-out cash unit counts are set via the CDM interface. Recycling cash units can be set via either interface. However, if the device has recycle units of multiple currencies and/or denominations (or multiple note identifiers associated with the same denomination) then the CIM interface should be used for exchange operations which affect these units. Those fields which are not common to both the CDM and CIM cash units are left unchanged when an exchange (or WFS\_CMD\_XXX\_SET\_CASH\_UNIT\_INFO) is executed on the other interface. For example if the CDM is used to set the current counts then the CIM *lpNoteNumberList* structure is not changed even if the data becomes inconsistent.

### Exchange via the CIM Interface

All cash unit info fields exposed through the CDM interface are also exposed through the CIM interface, so the entire exchange operation for a recycling device can be achieved through the CIM interface.

**Input Param** LPWFSCDMSTARTEX lpStartEx;

```
typedef struct _wfs_cdm_start_ex
{
    WORD                fwExchangeType;
    USHORT              usTellerID;
    USHORT              usCount;
    LPUSHORT            lpusCUNumList;
} WFS_CDMSTARTEX, *LPWFSCDMSTARTEX;
```

*fwExchangeType*

Specifies the type of cash unit exchange operation. This field should be set to one of the following values:

Value	Meaning
WFS_CDM_EXBYHAND	The cash units will be replenished manually either by filling or emptying the cash unit by hand or by replacing the cash unit.
WFS_CDM_EXTOCASSETTES	Items will be moved from the replenishment container to the bill cash units.

*usTellerID*

Identifies the teller. If the device is a Self-Service CDM this field is ignored.

*usCount*

Number of cash units to be exchanged. This is also the size of the array contained in the *lpusCUNumList* field.

*lpusCUNumList*

Pointer to an array of unsigned shorts containing the logical numbers of the cash units to be exchanged. If an invalid logical number is contained in this list, the command will fail with a WFS\_ERR\_CDM\_CASHUNITERROR error.

**Output Param** LPWFSCDMCUINFO lpCUInfo;

The WFS\_CDMCUINFO structure is specified in the documentation of the WFS\_INF\_CDM\_CASH\_UNIT\_INFO command. This is the complete list of cash units not just the cash units that are to be changed.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_INVALIDTELLERID	Invalid teller ID. This error will never be generated by a Self-Service CDM.
WFS_ERR_CDM_CASHUNITERROR	An error occurred with a cash unit while performing the exchange operation. A WFS_EXEE_CDM_CASHUNITERROR event will be posted with the details.
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM is already in an exchange state.

**Events** In addition to the generic events defined in [Ref. 1] the following events can be generated by this command:

Value	Meaning
WFS_EXEE_CDM_CASHUNITERROR	A cash unit caused an error.
WFS_EXEE_CDM_NOTEERROR	An item detection error has occurred.
WFS_EXEE_CDM_INPUT_P6	ECB6 Level 2 and/or level 3 notes have been detected.

**Comments** None.

## 5.12 WFS\_CMD\_CDM\_END\_EXCHANGE

**Description** This command will end the exchange state. If any physical action took place as a result of the WFS\_CMD\_CDM\_START\_EXCHANGE command then this command will cause the cash units to be returned to their normal physical state. Any necessary device testing will also be initiated. The application can also use this command to update cash unit information in the form described in the documentation of the WFS\_INF\_CDM\_CASH\_UNIT\_INFO command.

When *lpCUInfo* is not NULL the input parameters to this command may be ignored if the Service Provider can obtain cash unit information from self-configuring cash units.

If the fields *ulCount*, and *ulRejectCount* of *lppPhysical* are set to zero by this command, the application is indicating that it does not wish counts to be maintained for the physical cash units. Counts on the logical cash units will still be maintained and can be used by the application. If the physical counts are set by this command then the logical count will be the sum of the physical counts and any value sent as a logical count will be ignored.

If an error occurs during the execution of this command, the application must issue WFS\_INF\_CDM\_CASH\_UNIT\_INFO to determine the cash unit information.

Even if this command does not return WFS\_SUCCESS the exchange state has ended.

The values set by this command are persistent.

**Input Param** LPWFSCDMCUINFO *lpCUInfo*;

The WFS\_CDMCUINFO structure is specified in the documentation for the WFS\_INF\_CDM\_CASH\_UNIT\_INFO command. This pointer can be NULL if the cash unit information has not changed. If this parameter is not NULL then it must contain the complete list of cash unit structures, not just the ones that have changed. If this parameter is NULL then any cash unit in a manipulated state (i.e. *usPStatus* value of WFS\_CDM\_STATCUMANIP) will remain in this state after the command completes.

The *usStatus* and *usPStatus* values passed in the cash unit structures included within the *lpCUInfo* parameter are ignored and the actual status of the cash units is determined when this command is executed. When *lpCUInfo* is not NULL and this command is successfully executed cash units will no longer be in a manipulated state (i.e. *usPStatus* will no longer be WFS\_CDM\_STATCUMANIP).

**Output Param** None.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_INVALIDTELLERID	Invalid teller ID. This error will never be generated by a Self-Service CDM.
WFS_ERR_CDM_CASHUNITERROR	A problem occurred with a cash unit A WFS_EXEE_CDM_CASHUNITERROR event will be posted with the details.
WFS_ERR_CDM_NOEXCHANGEACTIVE	There is no exchange active.

**Events** In addition to the generic events defined in [Ref. 1], the following events can be generated by this command:

Value	Meaning
WFS_EXEE_CDM_CASHUNITERROR	A cash unit caused an error.
WFS_SRVE_CDM_CASHUNITINFOCHANGED	A cash unit was changed.
WFS_USRE_CDM_CASHUNITTHRESHOLD	A threshold condition has been reached in one of the cash units.
WFS_EXEE_CDM_NOTEERROR	An item detection error has occurred.
WFS_EXEE_CDM_INPUT_P6	ECB6 Level 2 and/or level 3 notes have been detected.

**Comments** None.

### 5.13 WFS\_CMD\_CDM\_OPEN\_SAFE\_DOOR

---

**Description** This command unlocks the safe door or starts the time delay count down prior to unlocking the safe door, if the device supports it. The command completes when the door is unlocked or the timer has started.

**Input Param** None.

**Output Param** None.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM is in an exchange state.

**Events** Only the generic events defined in [Ref. 1] can be generated by this command.

**Comments** None.

## 5.14 WFS\_CMD\_CDM\_CALIBRATE\_CASH\_UNIT

---

**Description** This command will cause a vendor dependent sequence of hardware events which will calibrate one or more physical cash units associated with a logical cash unit. This is necessary if a new type of bank note is put into the cash unit as the command enables the CDM to obtain the measures of the new bank notes.

If more than one physical cash unit is associated with the cash unit, it is up to the Service Provider to determine whether all the physical cash units need to be calibrated or if it is sufficient to calibrate for one physical unit and load the data into the others.

This command cannot be used to calibrate cash units which have been locked by the application. A WFS\_ERR\_CDM\_CASHUNITERROR code will be returned and the WFS\_EXEE\_CDM\_CASHUNITERROR event generated.

**Input Param** LPWFSCDMCALIBRATE lpCalibrateIn;

```
typedef struct _wfs_cdm_calibrate
{
    USHORT                usNumber;
    USHORT                usNumOfBills;
    LPWFSCDMITEMPOSITION *lpPosition;
} WFS_CDMCALIBRATE, *LPWFSCDMCALIBRATE;
```

*usNumber*

The logical number of the cash unit.

*usNumOfBills*

The number of bills to be dispensed during the calibration process.

*lpPosition*

Specifies where the dispensed items should be moved to. For a description of the WFS\_CDMITEMPOSITION structure see Section WFS\_CMD\_CDM\_RESET.

**Output Param** LPWFSCDMCALIBRATE lpCalibrateOut;

The WFS\_CDMCALIBRATE structure is defined in the Input Param section.

*usNumber*

The logical number of cash unit which has been calibrated.

*usNumOfBills*

Number of items that were actually dispensed during the calibration process. This value may be different from that passed in using the input structure if the cash dispenser always dispenses a default number of bills. When bills are presented to an output position this is the count of notes presented to the output position, any other notes rejected during the calibration process are not included in this count as they will be accounted for within the cash unit counts.

*lpPosition*

Specifies where the items were moved to during the calibration process.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_CASHUNITERROR	A cash unit caused an error. A WFS_EXEE_CDM_CASHUNITERROR event will be sent with the details.
WFS_ERR_CDM_UNSUPPOSITION	The position specified is not valid.
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM is in an exchange state.
WFS_ERR_CDM_INVALIDCASHUNIT	The cash unit number specified is not valid.

**Events** In addition to the generic events defined in [Ref. 1], the following events can be generated by this command:

Value	Meaning
WFS_USRE_CDM_CASHUNITTHRESHOLD	A threshold condition has been reached in one of the cash units.

WFS\_SRVE\_CDM\_CASHUNITINFOCHANGED

A cash unit was changed.

WFS\_EXEE\_CDM\_CASHUNITERROR

A cash unit caused an error.

WFS\_SRVE\_CDM\_ITEMSTAKEN

The items were removed.

WFS\_EXEE\_CDM\_NOTEERROR

An item detection error has occurred.

WFS\_EXEE\_CDM\_INPUT\_P6

ECB6 Level 2 and/or level 3 notes have been detected.

**Comments**      None.

## 5.15 WFS\_CMD\_CDM\_SET\_MIX\_TABLE

---

**Description** This command is used to set up the mix table specified by the mix number. Mix tables are persistent and are available to all applications in the system. An amount can be specified as different denominations within the mix table. If the amount is specified more than once the Service Provider will attempt to denominate or dispense the first amount in the table. If this does not succeed (e.g. because of a cash unit failure) the Service Provider will attempt to denominate or dispense the next amount in the table. The Service Provider can only dispense amounts which are explicitly mentioned in the mix table.

If a mix number passed in already exists then the information is overwritten with the new information.

The values set by this command are persistent.

**Input Param** LPWFSCDMMIXTABLE lpMixTable;

The structure WFSCDMMIXTABLE is defined in the documentation of the command WFS\_INF\_CDM\_MIX\_TABLE.

**Output Param** None.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_INVALIDMIXNUMBER	The supplied <i>usMixNumber</i> is reserved for a predefined mix algorithm.
WFS_ERR_CDM_INVALIDMIXTABLE	The contents of at least one of the defined rows of the mix table is incorrect.

**Events** Only the generic events defined in [Ref. 1] can be generated by this command.

**Comments** None.



## 5.16 WFS\_CMD\_CDM\_RESET

**Description** This command is used by the application to perform a hardware reset which will attempt to return the CDM device to a known good state. This command does not over-ride a lock obtained through WFS[Async]Lock on another application or service handle.

The device will attempt to move any items found anywhere within the device to the cash unit or output position specified in the *lpResetIn* parameter. This may not always be possible because of hardware problems.

If items are found inside the device the WFS\_SRVE\_CDM\_MEDIADETECTED event will be generated and will inform the application where the items were actually moved to.

If an exchange state is active then this command will end the exchange state (even if this command does not complete successfully).

If items are moved to a retract cash unit (i.e. a cash unit with *usType* WFS\_CDM\_TYPERETRACTCASSETTE), then the *ulCount* parameter of the retract cash unit must be incremented by 1 to specify the number of operations that changed the count. If items are moved to any other cash unit (e.g. a cash unit with *usType* WFS\_CDM\_TYPEREJECTCASSETTE), then the *ulCount* parameter of the cash unit must be incremented either by the number of items that were present at the time the WFS\_CMD\_CDM\_RESET command was issued or the number counted by the device during the WFS\_CMD\_CDM\_RESET command. Note that reject bin counts are unreliable.

**Input Param** LPWFSCDMITEMPOSITION lpResetIn;

```
typedef struct _wfs_cdm_itemposition
{
    USHORT                usNumber;
    LPWFSCDMRETRACT      lpRetractArea;
    WORD                  fwOutputPosition;
} WFS_CDMITEMPOSITION *LPWFSCDMITEMPOSITION;
```

*usNumber*

The *usNumber* of the cash unit to which items found inside the CDM are to be moved. If the items are to be moved to an output position this value is zero and the output position is defined by *fwOutputPosition*.

*lpRetractArea*

This field is only used if the cash unit specified by *usNumber* is a retract cash unit. In all other cases this field is set to NULL. For a description of this structure see the WFS\_CDMRETRACT structure defined in WFS\_CMD\_CDM\_RETRACT.

*fwOutputPosition*

The output position to which items are to be moved. If the *usNumber* is non-zero then this field will be ignored. The value is specified as one of the following values:

Value	Meaning
WFS_CDM_POSNULL	The default configuration.
WFS_CDM_POSLEFT	The left output position.
WFS_CDM_POSRIGHT	The right output position.
WFS_CDM_POSCENTER	The center output position.
WFS_CDM_POSTOP	The top output position.
WFS_CDM_POSBOTTOM	The bottom output position.
WFS_CDM_POSFRONT	The front output position.
WFS_CDM_POSREAR	The rear output position.

If the application does not wish to specify a cash unit or position it can set *lpResetIn* to NULL. In this case the Service Provider will determine where to move any items found.

**Output Param** None.

**Error Codes** In addition to the generic error codes defined in [Ref. 1] the following can be generated by this command:

Value	Meaning
WFS_ERR_CDM_CASHUNITERROR	A cash unit caused an error.

WFS\_ERR\_CDM\_UNSUPPOSITION           The position specified is not supported.  
WFS\_ERR\_CDM\_INVALIDCASHUNIT        The cash unit number specified is not valid.

**Events**           In addition to the generic events defined in [Ref. 1], the following events can be generated by this command:

Value	Meaning
WFS_USRE_CDM_CASHUNITTHRESHOLD	A threshold condition has been reached in one of the cash units.
WFS_EXEE_CDM_CASHUNITERROR	A cash unit caused an error.
WFS_SRVE_CDM_MEDIADETECTED	Media has been found in the device.
WFS_SRVE_CDM_ITEMSTAKEN	The items presented have been removed by the user.
WFS_EXEE_CDM_INPUT_P6	ECB6 Level 2 and/or level 3 notes have been detected.

**Comments**       None.

## 5.17 WFS\_CMD\_CDM\_TEST\_CASH\_UNITS

**Description** This command is used to test cash units following replenishment. All physical cash units which are testable (i.e. that have a status of WFS\_CDM\_STATCUOK or WFS\_CDM\_STATCULOW and no application lock in the logical cash unit associated with the physical cash unit) are tested. If the hardware is able to do so tests are continued even if an error occurs while testing one of the cash units. The command completes with WFS\_SUCCESS if the Service Provider successfully manages to test all of the testable cash units regardless of the outcome of the test. This is the case if all testable cash units could be tested and a dispense was possible from at least one of the cash units.

A WFS\_EXEE\_CDM\_CASHUNITERROR event will be sent for any logical cash unit which has one or more physical cash units which can not be tested or which fail the test, even if the logical cash unit has other physical cash units which are successfully tested. If all the cash units could not be tested or no cash units are testable then a WFS\_ERR\_CDM\_CASHUNITERROR code will be returned and WFS\_EXEE\_CDM\_CASHUNITERROR events generated for every logical cash unit that encountered a problem. The operation performed to test the cash units is vendor dependent. Items may be dispensed or transported into the reject bin as a result of this command.

If no cash units are testable then a WFS\_ERR\_CDM\_CASHUNITERROR code will be returned and WFS\_EXEE\_CDM\_CASHUNITERROR events will be generated for every cash unit.

**Input Param** LPWFSCDMITEMPOSITION lpPosition;

Specifies where items dispensed as a result of this command should be moved to. For a description of the WFSCDMITEMPOSITION structure see section WFS\_CMD\_CDM\_RESET.

If a Service Provider default configuration is to be used this parameter can be NULL.

**Output Param** LPWFSCDMCUINFO lpCUInfo;

The WFSCDMCUINFO structure is defined in the documentation of the WFS\_INF\_CDM\_CASH\_UNIT\_INFO command.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_CASHUNITERROR	A cash unit caused a problem that meant all cash units could not be tested or no cash units were testable. One or more WFS_EXEE_CDM_CASHUNITERROR events will be posted with the details.
WFS_ERR_CDM_UNSUPPOSITION	The position specified is not supported.
WFS_ERR_CDM_SHUTTERNOTOPEN	The shutter is not open or did not open when it should have. No items presented.
WFS_ERR_CDM_SHUTTEROPEN	The shutter is open when it should be closed. No items presented.
WFS_ERR_CDM_INVALIDCASHUNIT	The cash unit number specified is not valid.
WFS_ERR_CDM_EXCHANGEACTIVE	The CDM service is in an exchange state.
WFS_ERR_CDM_PRERRORNOITEMS	There was an error during the present operation - no items were presented.
WFS_ERR_CDM_PRERRORITEMS	There was an error during the present operation - at least some of the items were presented.
WFS_ERR_CDM_PRERRORUNKNOWN	There was an error during the present operation - the position of the items is unknown. Intervention may be required to reconcile the cash amount totals.

**Events** In addition to the generic events defined in [Ref. 1], the following events can be generated by this command:

Value	Meaning
WFS_USRE_CDM_CASHUNITTHRESHOLD	A threshold condition has been reached in one of the cash units.

WFS_SRVE_CDM_CASHUNITINFOCHANGED	A cash unit was changed.
WFS_EXEE_CDM_CASHUNITERROR	A cash unit has failed the test or a cash unit was not testable.
WFS_SRVE_CDM_ITEMSTAKEN	The items presented have been removed by the user.
WFS_SRVE_CDM_CASHUNITINFOCHANGED	A cash unit was updated as a result of this command.
WFS_EXEE_CDM_NOTEERROR	An item detection error has occurred.
WFS_EXEE_CDM_INPUT_P6	ECB6 Level 2 and/or level 3 notes have been detected.

**Comments**      None.

## 5.18 WFS\_CMD\_CDM\_SET\_GUIDANCE\_LIGHT

**Description** This command is used to set the status of the CDM guidance lights. This includes defining the flash rate and the color. When an application tries to use a color that is not supported then the Service Provider will return the generic error WFS\_ERR\_UNSUPP\_DATA.

**Input Param** LPWFSCDMSETGUIDLIGHT lpSetGuidLight;

```
typedef struct _wfs_cdm_set_guidlight
{
    WORD                wGuidLight;
    DWORD               dwCommand;
} WFS_CDMSETGUIDLIGHT, *LPWFSCDMSETGUIDLIGHT;
```

*wGuidLight*

Specifies the index of the guidance light to set as one of the values defined within the capabilities section in the *dwGuidLights* field.

*dwCommand*

Specifies the state of the guidance light indicator as WFS\_CDM\_GUIDANCE\_OFF or a combination of the following flags consisting of one type B, and optionally one type C. If no value of type C is specified then the default color is used. The Service Provider determines which color is used as the default color.

Value	Meaning	Type
WFS_CDM_GUIDANCE_OFF	The light indicator is turned off.	A
WFS_CDM_GUIDANCE_SLOW_FLASH	The light indicator is set to flash slowly.	B
WFS_CDM_GUIDANCE_MEDIUM_FLASH	The light indicator is set to flash medium frequency.	B
WFS_CDM_GUIDANCE_QUICK_FLASH	The light indicator is set to flash quickly.	B
WFS_CDM_GUIDANCE_CONTINUOUS	The light indicator is turned on continuously (steady).	B
WFS_CDM_GUIDANCE_RED	The light indicator color is set to red.	C
WFS_CDM_GUIDANCE_GREEN	The light indicator color is set to green.	C
WFS_CDM_GUIDANCE_YELLOW	The light indicator color is set to yellow.	C
WFS_CDM_GUIDANCE_BLUE	The light indicator color is set to blue.	C
WFS_CDM_GUIDANCE_CYAN	The light indicator color is set to cyan.	C
WFS_CDM_GUIDANCE_MAGENTA	The light indicator color is set to magenta.	C
WFS_CDM_GUIDANCE_WHITE	The light indicator color is set to white.	C

**Output Param** None.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CDM_INVALID_PORT	An attempt to set a guidance light to a new value was invalid because the guidance light does not exist.

**Events** Only the generic events defined in [Ref. 1] can be generated by this command.

**Comments** Guidance light support was added into the CDM primarily to support guidance lights for workstations where more than one instance of a CDM is present. The original SIU guidance light mechanism was not able to manage guidance lights for workstations with multiple CDMs. This command can also be used to set the status of the CDM guidance lights when only one instance of a CDM is present.

## 5.19 WFS\_CMD\_CDM\_POWER\_SAVE\_CONTROL

---

<b>Description</b>	<p>This command activates or deactivates the power-saving mode.</p> <p>If the Service Provider receives another execute command while in power saving mode, the Service Provider automatically exits the power saving mode, and executes the requested command. If the Service Provider receives an information command while in power saving mode, the Service Provider will not exit the power saving mode.</p>						
<b>Input Param</b>	<p>LPWFSCDMPOWERSAVECONTROL lpPowerSaveControl;</p> <pre>typedef struct _wfs_cdm_power_save_control {     USHORT                usMaxPowerSaveRecoveryTime; } WFS_CDMPOWERSAVECONTROL, *LPWFSCDMPOWERSAVECONTROL;</pre> <p><i>usMaxPowerSaveRecoveryTime</i> Specifies the maximum number of seconds in which the device must be able to return to its normal operating state when exiting power save mode. The device will be set to the highest possible power save mode within this constraint. If <i>usMaxPowerSaveRecoveryTime</i> is set to zero then the device will exit the power saving mode.</p>						
<b>Output Param</b>	None.						
<b>Error Codes</b>	<p>In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:</p> <table border="0" style="width: 100%;"> <thead> <tr> <th style="text-align: left; border-bottom: 1px solid black;">Value</th> <th style="text-align: left; border-bottom: 1px solid black;">Meaning</th> </tr> </thead> <tbody> <tr> <td style="border-bottom: 1px solid black;">WFS_ERR_CDM_POWERSAVETOOSHORT</td> <td style="border-bottom: 1px solid black;">The power saving mode has not been activated because the device is not able to resume from the power saving mode within the specified <i>usMaxPowerSaveRecoveryTime</i> value.</td> </tr> <tr> <td style="border-bottom: 1px solid black;">WFS_ERR_CDM_POWERSAVEMEDIAPRESENT</td> <td style="border-bottom: 1px solid black;">The power saving mode has not been activated because media is present inside the device.</td> </tr> </tbody> </table>	Value	Meaning	WFS_ERR_CDM_POWERSAVETOOSHORT	The power saving mode has not been activated because the device is not able to resume from the power saving mode within the specified <i>usMaxPowerSaveRecoveryTime</i> value.	WFS_ERR_CDM_POWERSAVEMEDIAPRESENT	The power saving mode has not been activated because media is present inside the device.
Value	Meaning						
WFS_ERR_CDM_POWERSAVETOOSHORT	The power saving mode has not been activated because the device is not able to resume from the power saving mode within the specified <i>usMaxPowerSaveRecoveryTime</i> value.						
WFS_ERR_CDM_POWERSAVEMEDIAPRESENT	The power saving mode has not been activated because media is present inside the device.						
<b>Events</b>	<p>In addition to the generic events defined in [Ref. 1], the following events can be generated by this command:</p> <table border="0" style="width: 100%;"> <thead> <tr> <th style="text-align: left; border-bottom: 1px solid black;">Value</th> <th style="text-align: left; border-bottom: 1px solid black;">Meaning</th> </tr> </thead> <tbody> <tr> <td style="border-bottom: 1px solid black;">WFS_SRVE_CDM_POWER_SAVE_CHANGE</td> <td style="border-bottom: 1px solid black;">The power save recovery time has changed.</td> </tr> </tbody> </table>	Value	Meaning	WFS_SRVE_CDM_POWER_SAVE_CHANGE	The power save recovery time has changed.		
Value	Meaning						
WFS_SRVE_CDM_POWER_SAVE_CHANGE	The power save recovery time has changed.						
<b>Comments</b>	None.						

## 5.20 WFS\_CMD\_CDM\_PREPARE\_DISPENSE

---

- Description** On some hardware it can take a significant amount of time for the dispenser to get ready to dispense media. On this type of hardware the WFS\_CMD\_CDM\_PREPARE\_DISPENSE command can be used to improve transaction performance.
- If this command is supported (see the *bPrepareDispense* capability) then applications can help to improve the time taken to dispense media by issuing this command as soon as the application knows that a dispense is likely to happen. This command either prepares the device for the next dispense operation, or terminates the dispense preparation if the subsequent dispense operation is no longer required.
- With the exception of the WFS\_CMD\_CDM\_DENOMINATE command, which will not stop the dispense preparation, any execute command on CDM or CIM will automatically stop the dispense preparation.
- If this command is executed and the device is already in the specified *wAction* state, then this execution will have no effect and will complete with WFS\_SUCCESS.
- Input Param** LPWFSCDMPREPAREDISPENSE lpPrepareDispense;
- ```
typedef struct _wfs_cdm_prepare_dispense
{
    WORD wAction;
} WFS_CDM_PREPAREDISPENSE, *LPWFSCDMPREPAREDISPENSE;
```
- wAction*  
A value specifying the type of actions. The value is set to one of the following values:
- | Value         | Meaning                                                                                                                                                                                                                          |
|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| WFS_CDM_START | Initiates the action to prepare for the next dispense command. This command does not wait until the device is ready to dispense before returning a completion event, it completes as soon as the preparation has been initiated. |
| WFS_CDM_STOP  | Stops the previously activated dispense preparation. For example the motor of the transport will be stopped. This should be used if for some reason the subsequent dispense operation is no longer required.                     |
- Output Param** None.
- Error Codes** Only the generic error codes defined in [Ref. 1] can be generated by this command.
- Events** Only the generic events defined in [Ref. 1] can be generated by this command.
- Comments** None.

## 6. Events

---

### 6.1 WFS\_SRVE\_CDM\_SAFEDOOROPEN

---

|                    |                                                                     |
|--------------------|---------------------------------------------------------------------|
| <b>Description</b> | This service event is generated when the safe door has been opened. |
| <b>Event Param</b> | None.                                                               |
| <b>Comments</b>    | None.                                                               |



## **6.2 WFS\_SRVE\_CDM\_SAFEDOORCLOSED**

---

|                    |                                                                     |
|--------------------|---------------------------------------------------------------------|
| <b>Description</b> | This service event is generated when the safe door has been closed. |
| <b>Event Param</b> | None.                                                               |
| <b>Comments</b>    | None.                                                               |

### 6.3 WFS\_USRE\_CDM\_CASHUNITTHRESHOLD

---

|                    |                                                                                                                                                                                                                                                                                                                                               |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | This user event is generated when a threshold condition has occurred in one of the cash units. If the cash unit is a shared cash unit in a compound CIM/CDM then this event can also be generated as a result of a CIM operation.                                                                                                             |
| <b>Event Param</b> | LPWFSCDMCASHUNIT lpCashUnit;<br><br><i>lpCashUnit</i><br>Pointer to WFSCDMCASHUNIT structure, describing the cash unit on which the threshold condition occurred. See <i>lpCashUnit-&gt;usStatus</i> for the current status. For a description of the WFSCDMCASHUNIT structure, see the definition of the WFS_INF_CDM_CASH_UNIT_INFO command. |
| <b>Comments</b>    | None.                                                                                                                                                                                                                                                                                                                                         |

## 6.4 WFS\_SRVE\_CDM\_CASHUNITINFOCHANGED

---

|                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | <p>This service event is generated when information about a physical or logical cash unit has changed. For instance, a physical cash unit may have been removed or inserted. This event will also be posted for every cash unit changed in any way (including changes to counts, e.g. <i>ulCount</i>, <i>ulRejectCount</i>, <i>ulInitialCount</i>, <i>ulDispensedCount</i> and <i>ulPresentedCount</i>) as a result of the following commands:</p> <pre>WFS_CMD_CDM_SET_CASH_UNIT_INFO WFS_CMD_CDM_END_EXCHANGE</pre> <p>This event will also be fired when any change is made to a cash unit by the following commands, except for changes to counts (e.g. <i>ulCount</i>, <i>ulRejectCount</i>, <i>ulInitialCount</i>, <i>ulDispensedCount</i> and <i>ulPresentedCount</i>), or if the WFS_USRE_CDM_CASHUNITTHRESHOLD is more appropriate:</p> <pre>WFS_CMD_CDM_CALIBRATE_CASH_UNIT WFS_CMD_CDM_TEST_CASH_UNITS</pre> <p>If the cash unit is shared cash unit in a compound CIM/CDM then this event can also be generated as a result of a CIM operation.</p> <p>When a physical cash unit is removed, the status of the physical cash unit becomes WFS_CDM_STATCUMISSING. If there are no physical cash units of the same logical type remaining the status of the logical type becomes WFS_CDM_STATCUMISSING.</p> <p>When a physical cash unit is inserted and this physical cash unit is of an existing logical type, both the logical and the physical cash unit structures will be updated.</p> <p>If a physical cash unit of a new logical type is inserted the cash unit structure reported by the last WFS_INF_CDM_CASH_UNIT_INFO command is no longer valid. In that case an application should issue a WFS_INF_CDM_CASH_UNIT_INFO command after receiving this event to obtain updated cash unit information.</p> |
| <b>Event Param</b> | <p>LPWFSCDMCASHUNIT lpCashUnit;</p> <p><i>lpCashUnit</i><br/>Pointer to the changed cash unit structure. For a description of the WFSCDMCASHUNIT structure see the definition of the WFS_INF_CDM_CASH_UNIT_INFO command.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Comments</b>    | <p>None.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

## **6.5 WFS\_SRVE\_CDM\_TELLERINFOCHANGED**

---

|                    |                                                                                                                                                                      |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | This service event is generated when the counts assigned to a teller have changed. This event is only returned as a result of a WFS_CMD_CDM_SET_TELLER_INFO command. |
| <b>Event Param</b> | LPUSHORT <i>lpusTellerID</i> ;<br><i>lpusTellerID</i><br>Pointer to an unsigned short holding the ID of the teller whose counts have changed.                        |
| <b>Comments</b>    | None.                                                                                                                                                                |

## 6.6 WFS\_EXEE\_CDM\_DELAYEDDISPENSE

---

|                    |                                                                                                                                    |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | This execute event is generated if the start of a dispense operation has been delayed.                                             |
| <b>Event Param</b> | LPULONG lpulDelay;<br><br><i>lpulDelay</i><br>Pointer to the time in milliseconds by which the dispense operation will be delayed. |
| <b>Comments</b>    | None.                                                                                                                              |

## **6.7 WFS\_EXEE\_CDM\_STARTDISPENSE**

---

|                    |                                                                                                             |
|--------------------|-------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | This execute event is generated when a delayed dispense operation begins.                                   |
| <b>Event Param</b> | LPREQUESTID lpReqID;<br><i>lpReqID</i><br>Pointer to the <i>RequestID</i> of the original dispense command. |
| <b>Comments</b>    | None.                                                                                                       |

## 6.8 WFS\_EXEE\_CDM\_CASHUNITERROR

---

**Description** This execute event is generated if there is a problem with a cash unit during the execution of a command.

**Event Param** LPWFSCDMCUERROR lpCashUnitError;

```
typedef struct _wfs_cdm_cu_error
{
    WORD wFailure;
    LPWFSCDMCASHUNIT lpCashUnit;
} WFS_CDM_CU_ERROR, *LPWFSCDMCUERROR;
```

*wFailure*

Specifies the kind of failure that occurred in the cash unit. Values are:

| Value                   | Meaning                                                                          |
|-------------------------|----------------------------------------------------------------------------------|
| WFS_CDM_CASHUNITEMPTY   | Specified cash unit is empty.                                                    |
| WFS_CDM_CASHUNITERROR   | Specified cash unit has malfunctioned.                                           |
| WFS_CDM_CASHUNITFULL    | Specified cash unit is full.                                                     |
| WFS_CDM_CASHUNITLOCKED  | Specified cash unit is locked.                                                   |
| WFS_CDM_CASHUNITINVALID | Specified cash unit is invalid.                                                  |
| WFS_CDM_CASHUNITCONFIG  | An attempt has been made to change the settings of a self-configuring cash unit. |
| WFS_CDM_CASHUNITNOTCONF | Specified cash unit is not configured.                                           |

*lpCashUnit*

Pointer to the cash unit structure that caused the problem. The WFS\_CDM\_CASHUNIT structure is defined in the documentation of the WFS\_INF\_CDM\_CASH\_UNIT\_INFO command. It is possible that this pointer may be NULL if the *wFailure* field is WFS\_CDM\_CASHUNITINVALID.

**Comments** None.

## 6.9 WFS\_SRVE\_CDM\_ITEMSTAKEN

---

**Description** This service event is generated when items presented to the user have been taken. This event may be generated at any time.

**Event Param** LPWORD lpfwPosition;

*lpfwPosition*

The output position from which the items have been removed. Possible values are:

| Value             | Meaning                     |
|-------------------|-----------------------------|
| WFS_CDM_POSNULL   | The default configuration.  |
| WFS_CDM_POSLEFT   | The left output position.   |
| WFS_CDM_POSRIGHT  | The right output position.  |
| WFS_CDM_POSCENTER | The center output position. |
| WFS_CDM_POSTOP    | The top output position.    |
| WFS_CDM_POSBOTTOM | The bottom output position. |
| WFS_CDM_POSFRONT  | The front output position.  |
| WFS_CDM_POSREAR   | The rear output position.   |

**Comments** None.



## 6.10 WFS\_SRVE\_CDM\_COUNTS\_CHANGED

---

**Description** This service event is generated if the device is a compound device together with a CIM and the counts in a shared cash unit have changed as a result of any CIM operation other than WFS\_CMD\_CIM\_SET\_CASH\_UNIT\_INFO and WFS\_CMD\_CIM\_END\_EXCHANGE.

**Event Param** LPWFSCDMCOUNTSCHANGED lpCountsChanged;

```
typedef struct _wfs_cdm_counts_changed
{
    USHORT                usCount;
    LPUSHORT              lpusCUNumList;
} WFS_CDMCOUNTSCHANGED, *LPWFSCDMCOUNTSCHANGED;
```

*usCount*

The size of *lpusCUNumList*.

*lpusCUNumList*

A list of the *usNumbers* of the cash units whose counts have changed.

**Comments** None.

## **6.11 WFS\_EXEE\_CDM\_PARTIALDISPENSE**

---

|                    |                                                                                                                                                                 |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | This execute event is generated when a dispense operation is divided into several sub-dispense operations because the hardware capacity of the CDM is exceeded. |
| <b>Event Param</b> | LPUSHORT <i>lpusDispNum</i> ;<br><br><i>lpusDispNum</i><br>Pointer to the number of sub-dispense operations into which the dispense operation has been divided. |
| <b>Comments</b>    | None.                                                                                                                                                           |

## 6.12 WFS\_EXEE\_CDM\_SUBDISPENSEOK

---

|                    |                                                                                                                                                                                                                                                                                                                             |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | This execute event is generated when one of the sub-dispense operations into which the dispense operation was divided has finished successfully.                                                                                                                                                                            |
| <b>Event Param</b> | LPWFSCDMDENOMINATION lpDenomination;<br><br><i>lpDenomination</i><br>The WFSCDMDENOMINATION structure is defined in the documentation of the command WFS_CMD_CDM_DENOMINATE. Note that in this case the values in this structure report the amount and number of each denomination dispensed in the sub-dispense operation. |
| <b>Comments</b>    | None.                                                                                                                                                                                                                                                                                                                       |

## 6.13 WFS\_EXEE\_CDM\_INCOMPLETEDISPENSE

---

|                    |                                                                                                                                                                                                                                                                                                                        |
|--------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | This execute event is generated when not all of the items specified in a WFS_CMD_CDM_DISPENSE operation could be dispensed. Some of the items have been dispensed. If the device has no intermediate stacker then the items that were dispensed will be in customer access.                                            |
| <b>Event Param</b> | LPWFSCDMDENOMINATION lpDenomination;<br><br><i>lpDenomination</i><br>The WFS_CDM_DENOMINATION structure is defined in the documentation of the command WFS_CMD_CDM_DENOMINATE. Note that in this case the values in this structure report the amount and number of each denomination that has actually been dispensed. |
| <b>Comments</b>    | None.                                                                                                                                                                                                                                                                                                                  |

## 6.14 WFS\_EXEE\_CDM\_NOTEERROR

---

**Description** This execute event specifies the reason for a note detection error during the execution of a command.

**Event Param** LPUSHORT lpusReason;

*lpusReason*

Pointer to the reason for the notes detection error. Possible values are:

| Value                      | Meaning                                                          |
|----------------------------|------------------------------------------------------------------|
| WFS_CDM_DOUBLENOTEDETECTED | Double notes have been detected.                                 |
| WFS_CDM_LONGNOTEDETECTED   | A long note has been detected.                                   |
| WFS_CDM_SKEWEDNOTE         | A skewed note has been detected.                                 |
| WFS_CDM_INCORRECTCOUNT     | An item counting error has occurred.                             |
| WFS_CDM_NOTESTOOCLOSE      | Notes have been detected as being too close.                     |
| WFS_CDM_OTHERNOTEERROR     | An item error not covered by the other values has been detected. |
| WFS_CDM_SHORTNOTEDETECTED  | Short notes have been detected.                                  |

**Comments** None.

## **6.15 WFS\_SRVE\_CDM\_ITEMSPRESENTED**

---

|                    |                                                                                                                        |
|--------------------|------------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | This service event specifies that items have been presented to the user during a count operation and need to be taken. |
| <b>Event Param</b> | None.                                                                                                                  |
| <b>Comments</b>    | None.                                                                                                                  |

## 6.16 WFS\_SRVE\_CDM\_MEDIADETECTED

---

|                    |                                                                                                                                                                                                                                                                                                          |
|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | This service event is generated if media is detected during a reset (WFS_CMD_CDM_RESET). The parameter on the event informs the application of the position of the media after the reset completes. If the device has been unable to successfully move the items found then this parameter will be NULL. |
| <b>Event Param</b> | LPWFSCDMITEMPOSITION *lpItemPosition;<br>For a description of this parameter see WFS_CMD_CDM_RESET.                                                                                                                                                                                                      |
| <b>Comments</b>    | None.                                                                                                                                                                                                                                                                                                    |

## **6.17 WFS\_EXEE\_CDM\_INPUT\_P6**

---

|                    |                                                                                                                                                                                                                          |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Description</b> | This execute event is generated if level 2 and/or level 3 notes are detected during execution of a CDM command. Details about the notes detected and their associated signatures are obtained through the CIM interface. |
| <b>Event Param</b> | None.                                                                                                                                                                                                                    |
| <b>Comments</b>    | None.                                                                                                                                                                                                                    |



## 6.18 WFS\_SRVE\_CDM\_DEVICEPOSITION

---

**Description** This service event reports that the device has changed its position status.

**Event Param** LPWFSCDMDEVICEPOSITION lpDevicePosition;

```
typedef struct _wfs_cdm_device_position
{
    WORD wPosition;
} WFS_CDM_DEVICEPOSITION, *LPWFSCDMDEVICEPOSITION;
```

*wPosition*

Position of the device as one of the following values:

| Value                       | Meaning                                                         |
|-----------------------------|-----------------------------------------------------------------|
| WFS_CDM_DEVICEINPOSITION    | The device is in its normal operating position.                 |
| WFS_CDM_DEVICENOTINPOSITION | The device has been removed from its normal operating position. |
| WFS_CDM_DEVICEPOSUNKNOWN    | The position of the device cannot be determined.                |

**Comments** None.

## 6.19 WFS\_SRVE\_CDM\_POWER\_SAVE\_CHANGE

---

**Description** This service event specifies that the power save recovery time has changed.

**Event Param** LPWFSCDMPOWERSAVECHANGE lpPowerSaveChange;

```
typedef struct _wfs_cdm_power_save_change
{
    USHORT          usPowerSaveRecoveryTime;
} WFS_CDMPOWERSAVECHANGE, *LPWFSCDMPOWERSAVECHANGE;
```

*usPowerSaveRecoveryTime*

Specifies the actual number of seconds required by the device to resume its normal operational state. This value is zero if the device exited the power saving mode.

**Comments** None.

## 7. Sub-Dispensing Command Flow

“Sub-dispensing” of bills occur when a WFS\_CMD\_CDM\_DISPENSE execute command is issued and the required number of bills to be dispensed exceeds the CDM hardware limit for bills that can be dispensed with a single “hardware level” dispense command. In this situation, the CDM Service Provider determines the number of “hardware level” dispense commands required and enters what is referred to as a “sub-dispensing” operation until the full amount has been dispensed. Through use of a “sub-dispensing” operation the application is fully removed from “hardware level dependencies” as to how many bills can be dispensed based on hardware vendor design limitations.

The following series of tables illustrate the steps taken on behalf of an end-user, application, XFS Service Provider, and CDM hardware for sub-dispensing operations: All examples below assume the *bPresent* parameter in the WFS\_CMD\_CDM\_DISPENSE command is set to TRUE.

### Sub-Dispensing Is Not Required - Transaction Successful

This table illustrates a successful WFS\_CMD\_CDM\_DISPENSE command where sub-dispensing is not required:

| Step | End-User                           | Application                                  | XFS SP                                                                                              | CDM Hardware     |
|------|------------------------------------|----------------------------------------------|-----------------------------------------------------------------------------------------------------|------------------|
| 1.   | User wants to dispense \$40.00 USD |                                              |                                                                                                     |                  |
| 2.   |                                    | WFS_CMD_CDM_DISPENSE command issued.         |                                                                                                     |                  |
| 3.   |                                    |                                              | Determines that a single “hardware level” dispense command can be issued for full dispense request. |                  |
| 4.   |                                    |                                              | “Hardware level” dispense command issued.                                                           |                  |
| 5.   |                                    |                                              |                                                                                                     | Items presented. |
| 6.   |                                    | WFS_CMD_CDM_DISPENSE completes successfully. |                                                                                                     |                  |
| 7.   | User takes bills.                  |                                              |                                                                                                     |                  |
| 8.   |                                    |                                              | WFS_SRVE_CDM_ITEMSSTAKE N event generated.                                                          |                  |

## Sub-Dispensing Is Required - Command Successful

This table illustrates a successful WFS\_CMD\_CDM\_DISPENSE command where sub-dispensing is required:

| Step | End-User                                                   | Application                                  | XFS SP                                                                                                                                        | CDM Hardware     |
|------|------------------------------------------------------------|----------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| 1.   | User wants to dispense \$130 USD in \$1 USD denominations. |                                              |                                                                                                                                               |                  |
| 2.   |                                                            | WFS_CMD_CDM_DISPENSE command issued.         |                                                                                                                                               |                  |
| 3.   |                                                            |                                              | Three "hardware level" dispense commands are required. CDM hardware is limited to dispensing 50 bills in any single "hardware level" dispense |                  |
| 4.   |                                                            |                                              | WFS_EXEE_CDM_PARTIALDISPENSE event generated.                                                                                                 |                  |
| 5.   |                                                            |                                              | "Hardware level" dispense command issued for \$50 USD.                                                                                        |                  |
| 6.   |                                                            |                                              |                                                                                                                                               | Items presented. |
| 7.   |                                                            |                                              | WFS_SRVE_CDM_SUBDISPENSE OK event generated.                                                                                                  |                  |
| 8.   | User takes bills.                                          |                                              |                                                                                                                                               |                  |
| 9.   |                                                            |                                              | WFS_SRVE_CDM_ITEMSTAKEN event generated.                                                                                                      |                  |
| 10.  |                                                            |                                              | "Hardware level" dispense command issued for \$50 USD.                                                                                        |                  |
| 11.  |                                                            |                                              |                                                                                                                                               | Items presented. |
| 12.  |                                                            |                                              | WFS_SRVE_CDM_SUBDISPENSE OK event generated.                                                                                                  |                  |
| 13.  | User takes bills                                           |                                              |                                                                                                                                               |                  |
| 14.  |                                                            |                                              | WFS_SRVE_CDM_ITEMSTAKEN event generated.                                                                                                      |                  |
| 15.  |                                                            |                                              | "Hardware level" dispense command issued for \$30 USD                                                                                         |                  |
| 16.  |                                                            |                                              |                                                                                                                                               | Items presented. |
| 17.  |                                                            |                                              | WFS_SRVE_CDM_SUBDISPENSE OK event generated.                                                                                                  |                  |
| 18.  |                                                            | WFS_CMD_CDM_DISPENSE completes successfully. |                                                                                                                                               |                  |
| 19.  | User takes bills                                           |                                              |                                                                                                                                               |                  |
| 20.  |                                                            |                                              | WFS_SRVE_CDM_ITEMSSTAKEN event generated.                                                                                                     |                  |

### Sub-Dispensing Is Required - Command Unsuccessful

This table illustrates an unsuccessful WFS\_CMD\_CDM\_DISPENSE command where sub-dispensing is required and the end-user does not take the bills during the second “hardware level” dispense, resulting in a timeout condition.

| Step | End-User                                                  | Application                                                     | XFS SP                                                                                                                                                 | CDM Hardware     |
|------|-----------------------------------------------------------|-----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| 1.   | User wants to dispense \$130 USD in \$1 USD denominations |                                                                 |                                                                                                                                                        |                  |
| 2.   |                                                           | WFS_CMD_CDM_DISPENSE command issued.                            |                                                                                                                                                        |                  |
| 3.   |                                                           |                                                                 | Three “hardware level” dispense commands are required. CDM hardware is limited to dispensing 50 bills in any single “hardware level” dispense command. |                  |
| 4.   |                                                           |                                                                 | WFS_EXEE_CDM_PARTIALDISPENSE event generated.                                                                                                          |                  |
| 5.   |                                                           |                                                                 | “Hardware level” dispense command issued for \$50 USD.                                                                                                 |                  |
| 6.   |                                                           |                                                                 |                                                                                                                                                        | Items presented  |
| 7.   |                                                           |                                                                 | WFS_SRVE_CDM_SUBDISPENSE OK event generated.                                                                                                           |                  |
| 8.   | User takes bills.                                         |                                                                 |                                                                                                                                                        |                  |
| 9.   |                                                           |                                                                 | WFS_SRVE_CDM_ITEMSTAKEN event generated.                                                                                                               |                  |
| 10.  |                                                           |                                                                 | “Hardware level” dispense command issued for \$50 USD.                                                                                                 |                  |
| 11.  |                                                           |                                                                 |                                                                                                                                                        | Items presented. |
| 12.  |                                                           |                                                                 | WFS_SRVE_CDM_SUBDISPENSE OK event generated.                                                                                                           |                  |
| 13.  | User does not take bills.                                 |                                                                 |                                                                                                                                                        |                  |
| 14.  |                                                           |                                                                 | Timeout occurs waiting on end-user to take bills.                                                                                                      |                  |
| 15.  |                                                           | WFS_CMD_CDM_DISPENSE completes with WFS_ERR_CDM_ITEMSNOT TAKEN. |                                                                                                                                                        |                  |

## **8. Rules for Cash Unit Exchange**

---

The XFS Start and End Exchange commands should be used by applications to supply the latest information with regards to cash unit replenishment state and content. This guarantees a certain amount of control to an application as to which denominations are stored in which position as well as the general physical state of the logical/physical cash units.

If a cash unit is removed from the CDM outside of the Start/End Exchange operations and subsequently reinserted the status of the physical cash unit should be set to WFS\_CDM\_STATCUMANIP to indicate to the application that the physical cash unit has been removed, reinserted and possibly tampered with. While the cash unit has this status the Service Provider should not attempt to use it as part of a Dispense operation. The WFS\_CDM\_STATCUMANIP status should not change until the next Start/End Exchange operation is performed, even if the cash unit is replaced in its original position.

If all the physical cash units belonging to a logical cash unit are manipulated the parent logical cash unit that the physical cash units belong to should also have its status set to WFS\_CDM\_STATCUMANIP.

When a cash unit is removed and/or replaced outside of the Start/End Exchange operations the original logical cash unit information such as the values, currency and counts should be preserved in the Cash Unit Info structure reported to the application for accounting purposes until the next Start/End Exchange operations, even if the cash unit physically contains a different denomination.

## 9. C - Header file

```

/*****
*
* xfscdm.h      XFS - Cash Dispenser (CDM) definitions
*
*              Version 3.10 (29/11/2007)
*
*****/

#ifndef __INC_XFSCDM_H
#define __INC_XFSCDM_H

#ifdef __cplusplus
extern "C" {
#endif

#include <xfsapi.h>

/* be aware of alignment */
#pragma pack (push, 1)

/* values of WFS_CDMCAPS.wClass */

#define      WFS_SERVICE_CLASS_CDM                (3)
#define      WFS_SERVICE_CLASS_VERSION_CDM      0x0A03 /* Version 3.10 */
#define      WFS_SERVICE_CLASS_NAME_CDM        "CDM"

#define      CDM_SERVICE_OFFSET                (WFS_SERVICE_CLASS_CDM * 100)

/* CDM Info Commands */

#define      WFS_INF_CDM_STATUS                (CDM_SERVICE_OFFSET + 1)
#define      WFS_INF_CDM_CAPABILITIES          (CDM_SERVICE_OFFSET + 2)
#define      WFS_INF_CDM_CASH_UNIT_INFO        (CDM_SERVICE_OFFSET + 3)
#define      WFS_INF_CDM_TELLER_INFO           (CDM_SERVICE_OFFSET + 4)
#define      WFS_INF_CDM_CURRENCY_EXP          (CDM_SERVICE_OFFSET + 6)
#define      WFS_INF_CDM_MIX_TYPES             (CDM_SERVICE_OFFSET + 7)
#define      WFS_INF_CDM_MIX_TABLE            (CDM_SERVICE_OFFSET + 8)
#define      WFS_INF_CDM_PRESENT_STATUS        (CDM_SERVICE_OFFSET + 9)

/* CDM Execute Commands */

#define      WFS_CMD_CDM_DENOMINATE            (CDM_SERVICE_OFFSET + 1)
#define      WFS_CMD_CDM_DISPENSE              (CDM_SERVICE_OFFSET + 2)
#define      WFS_CMD_CDM_PRESENT               (CDM_SERVICE_OFFSET + 3)
#define      WFS_CMD_CDM_REJECT                (CDM_SERVICE_OFFSET + 4)
#define      WFS_CMD_CDM_RETRACT               (CDM_SERVICE_OFFSET + 5)
#define      WFS_CMD_CDM_OPEN_SHUTTER          (CDM_SERVICE_OFFSET + 7)
#define      WFS_CMD_CDM_CLOSE_SHUTTER        (CDM_SERVICE_OFFSET + 8)
#define      WFS_CMD_CDM_SET_TELLER_INFO       (CDM_SERVICE_OFFSET + 9)
#define      WFS_CMD_CDM_SET_CASH_UNIT_INFO    (CDM_SERVICE_OFFSET + 10)
#define      WFS_CMD_CDM_START_EXCHANGE        (CDM_SERVICE_OFFSET + 11)
#define      WFS_CMD_CDM_END_EXCHANGE          (CDM_SERVICE_OFFSET + 12)
#define      WFS_CMD_CDM_OPEN_SAFE_DOOR        (CDM_SERVICE_OFFSET + 13)
#define      WFS_CMD_CDM_CALIBRATE_CASH_UNIT  (CDM_SERVICE_OFFSET + 15)
#define      WFS_CMD_CDM_SET_MIX_TABLE         (CDM_SERVICE_OFFSET + 20)
#define      WFS_CMD_CDM_RESET                 (CDM_SERVICE_OFFSET + 21)
#define      WFS_CMD_CDM_TEST_CASH_UNITS       (CDM_SERVICE_OFFSET + 22)
#define      WFS_CMD_CDM_COUNT                 (CDM_SERVICE_OFFSET + 23)
#define      WFS_CMD_CDM_SET_GUIDANCE_LIGHT    (CDM_SERVICE_OFFSET + 24)
#define      WFS_CMD_CDM_POWER_SAVE_CONTROL    (CDM_SERVICE_OFFSET + 25)
#define      WFS_CMD_CDM_PREPARE_DISPENSE      (CDM_SERVICE_OFFSET + 26)

/* CDM Messages */

#define      WFS_SRVE_CDM_SAFEDOOROPEN         (CDM_SERVICE_OFFSET + 1)
#define      WFS_SRVE_CDM_SAFEDOORCLOSED      (CDM_SERVICE_OFFSET + 2)

```

```
#define WFS_USRE_CDM_CASHUNITTHRESHOLD (CDM_SERVICE_OFFSET + 3)
#define WFS_SRVE_CDM_CASHUNITINFOCHANGED (CDM_SERVICE_OFFSET + 4)
#define WFS_SRVE_CDM_TELLERINFOCHANGED (CDM_SERVICE_OFFSET + 5)
#define WFS_EXEE_CDM_DELAYEDDISPENSE (CDM_SERVICE_OFFSET + 6)
#define WFS_EXEE_CDM_STARTDISPENSE (CDM_SERVICE_OFFSET + 7)
#define WFS_EXEE_CDM_CASHUNITERROR (CDM_SERVICE_OFFSET + 8)
#define WFS_SRVE_CDM_ITEMSTAKEN (CDM_SERVICE_OFFSET + 9)
#define WFS_EXEE_CDM_PARTIALDISPENSE (CDM_SERVICE_OFFSET + 10)
#define WFS_EXEE_CDM_SUBDISPENSEOK (CDM_SERVICE_OFFSET + 11)
#define WFS_SRVE_CDM_ITEMSPRESENTED (CDM_SERVICE_OFFSET + 13)
#define WFS_SRVE_CDM_COUNTS_CHANGED (CDM_SERVICE_OFFSET + 14)
#define WFS_EXEE_CDM_INCOMPLETEDISPENSE (CDM_SERVICE_OFFSET + 15)
#define WFS_EXEE_CDM_NOTEERROR (CDM_SERVICE_OFFSET + 16)
#define WFS_SRVE_CDM_MEDIADETECTED (CDM_SERVICE_OFFSET + 17)
#define WFS_EXEE_CDM_INPUT_P6 (CDM_SERVICE_OFFSET + 18)
#define WFS_SRVE_CDM_DEVICEPOSITION (CDM_SERVICE_OFFSET + 19)
#define WFS_SRVE_CDM_POWER_SAVE_CHANGE (CDM_SERVICE_OFFSET + 20)
```

/\* values of WFS\_CDMSTATUS.fwDevice \*/

```
#define WFS_CDM_DEVONLINE WFS_STAT_DEVONLINE
#define WFS_CDM_DEVOFFLINE WFS_STAT_DEVOFFLINE
#define WFS_CDM_DEVPOWEROFF WFS_STAT_DEVPOWEROFF
#define WFS_CDM_DEVNODEVICE WFS_STAT_DEVNODEVICE
#define WFS_CDM_DEVHWERROR WFS_STAT_DEVHWERROR
#define WFS_CDM_DEVUSERERROR WFS_STAT_DEVUSERERROR
#define WFS_CDM_DEVBUSY WFS_STAT_DEVBUSY
#define WFS_CDM_DEVFRAUDATTEMPT WFS_STAT_DEVFRAUDATTEMPT
```

/\* values of WFS\_CDMSTATUS.fwSafeDoor \*/

```
#define WFS_CDM_DOORNOTSUPPORTED (1)
#define WFS_CDM_DOOROPEN (2)
#define WFS_CDM_DOORCLOSED (3)
#define WFS_CDM_DOORUNKNOWN (5)
```

/\* values of WFS\_CDMSTATUS.fwDispenser \*/

```
#define WFS_CDM_DISPOK (0)
#define WFS_CDM_DISPCUSTATE (1)
#define WFS_CDM_DISPCUSTOP (2)
#define WFS_CDM_DISPCUUNKNOWN (3)
```

/\* values of WFS\_CDMSTATUS.fwIntermediateStacker \*/

```
#define WFS_CDM_ISEMPY (0)
#define WFS_CDM_ISNOTEMPTY (1)
#define WFS_CDM_ISNOTEMPTYCUST (2)
#define WFS_CDM_ISNOTEMPTYUNK (3)
#define WFS_CDM_ISUNKNOWN (4)
#define WFS_CDM_ISNOTSUPPORTED (5)
```

/\* Size and max index of dwGuidLights array \*/

```
#define WFS_CDM_GUIDLIGHTS_SIZE (32)
#define WFS_CDM_GUIDLIGHTS_MAX (WFS_CDM_GUIDLIGHTS_SIZE - 1)
```

/\* Indices of WFS\_CDMSTATUS.dwGuidLights [...]
WFS\_CDMCAPS.dwGuidLights [...]
\*/

```
#define WFS_CDM_GUIDANCE_POSOUTNULL (0)
#define WFS_CDM_GUIDANCE_POSOUTLEFT (1)
#define WFS_CDM_GUIDANCE_POSOUTRIGHT (2)
#define WFS_CDM_GUIDANCE_POSOUTCENTER (3)
#define WFS_CDM_GUIDANCE_POSOUTTOP (4)
#define WFS_CDM_GUIDANCE_POSOUTBOTTOM (5)
#define WFS_CDM_GUIDANCE_POSOUTFRONT (6)
#define WFS_CDM_GUIDANCE_POSOUTREAR (7)
```



```

/* Values of WFSCDMSTATUS.dwGuidLights [...]
   WFSCDMCAPS.dwGuidLights [...]
*/
#define WFS_CDM_GUIDANCE_OFF (0x00000001)
#define WFS_CDM_GUIDANCE_SLOW_FLASH (0x00000004)
#define WFS_CDM_GUIDANCE_MEDIUM_FLASH (0x00000008)
#define WFS_CDM_GUIDANCE_QUICK_FLASH (0x00000010)
#define WFS_CDM_GUIDANCE_CONTINUOUS (0x00000080)
#define WFS_CDM_GUIDANCE_RED (0x00000100)
#define WFS_CDM_GUIDANCE_GREEN (0x00000200)
#define WFS_CDM_GUIDANCE_YELLOW (0x00000400)
#define WFS_CDM_GUIDANCE_BLUE (0x00000800)
#define WFS_CDM_GUIDANCE_CYAN (0x00001000)
#define WFS_CDM_GUIDANCE_MAGENTA (0x00002000)
#define WFS_CDM_GUIDANCE_WHITE (0x00004000)

/* Values of WFSCDMSTATUS.dwGuidLights [...]
   WFSCDMCAPS.dwGuidLights [...]
*/
#define WFS_CDM_GUIDANCE_NOT_AVAILABLE (0x0000)

/* values of WFSCDMSTATUS.fwDevicePosition
   WFSCDMDEVICEPOSITION.wPosition */
#define WFS_CDM_DEVICEINPOSITION (0)
#define WFS_CDM_DEVICENOTINPOSITION (1)
#define WFS_CDM_DEVICEPOSUNKNOWN (2)
#define WFS_CDM_DEVICEPOSNOTSUPP (3)

/* values of WFSCDMOUTPOS.fwShutter */
#define WFS_CDM_SHTCLOSED (0)
#define WFS_CDM_SHTOPEN (1)
#define WFS_CDM_SHTJAMMED (2)
#define WFS_CDM_SHTUNKNOWN (3)
#define WFS_CDM_SHTNOTSUPPORTED (4)

/* values of WFSCDMOUTPOS.fwPositionStatus */
#define WFS_CDM_PSEMPY (0)
#define WFS_CDM_PSNOTEMPTY (1)
#define WFS_CDM_PSUNKNOWN (2)
#define WFS_CDM_PSNOTSUPPORTED (3)

/* values of WFSCDMOUTPOS.fwTransport */
#define WFS_CDM_TPOK (0)
#define WFS_CDM_TPINOP (1)
#define WFS_CDM_TPUNKNOWN (2)
#define WFS_CDM_TPNOTSUPPORTED (3)

/* values of WFSCDMOUTPOS.fwTransportStatus */
#define WFS_CDM_TPSTATEMPY (0)
#define WFS_CDM_TPSTATNOTEMPTY (1)
#define WFS_CDM_TPSTATNOTEMPTYCUST (2)
#define WFS_CDM_TPSTATNOTEMPTY_UNK (3)
#define WFS_CDM_TPSTATNOTSUPPORTED (4)

/* values of WFSCDMCAPS.fwType */
#define WFS_CDM_TELLERBILL (0)
#define WFS_CDM_SELFSEVICEBILL (1)
#define WFS_CDM_TELLERCOIN (2)
#define WFS_CDM_SELFSEVICECOIN (3)

/* values of WFSCDMCAPS.fwRetractAreas */

```

```
/* values of WFSCDMRETRACT.usRetractArea */

#define      WFS_CDM_RA_RETRACT                (0x0001)
#define      WFS_CDM_RA_TRANSPORT              (0x0002)
#define      WFS_CDM_RA_STACKER                (0x0004)
#define      WFS_CDM_RA_REJECT                 (0x0008)
#define      WFS_CDM_RA_NOTSUPP                (0x0010)
#define      WFS_CDM_RA_ITEMCASSETTE           (0x0020)

/* values of WFSCDMCAPS.fwRetractTransportActions */
/* values of WFSCDMCAPS.fwRetractStackerActions */

#define      WFS_CDM_PRESENT                    (0x0001)
#define      WFS_CDM_RETRACT                    (0x0002)
#define      WFS_CDM_REJECT                     (0x0004)
#define      WFS_CDM_NOTSUPP                    (0x0008)
#define      WFS_CDM_ITEMCASSETTE               (0x0010)

/* values of WFSCDMCAPS.fwMoveItems */

#define      WFS_CDM_FROMCU                      (0x0001)
#define      WFS_CDM_TOCU                        (0x0002)
#define      WFS_CDM_TOTRANSPORT                 (0x0004)

/* values of WFSCDMCASHUNIT.usType */

#define      WFS_CDM_TYPENA                       (1)
#define      WFS_CDM_TYPEREJECTCASSETTE          (2)
#define      WFS_CDM_TYPEBILLCASSETTE            (3)
#define      WFS_CDM_TYPECOINCYLINDER            (4)
#define      WFS_CDM_TYPECOINDISPENSER           (5)
#define      WFS_CDM_TYPERETRACTCASSETTE         (6)
#define      WFS_CDM_TYPECOUPON                  (7)
#define      WFS_CDM_TYPEREDOCUMENT              (8)
#define      WFS_CDM_TYPEREPCONTAINER            (11)
#define      WFS_CDM_TYPERECYCLING               (12)

/* values of WFSCDMCASHUNIT.usStatus */

#define      WFS_CDM_STATCUOK                     (0)
#define      WFS_CDM_STATCUFULL                   (1)
#define      WFS_CDM_STATCUHIGH                   (2)
#define      WFS_CDM_STATCULOW                    (3)
#define      WFS_CDM_STATCUEMPTY                  (4)
#define      WFS_CDM_STATCUINOP                   (5)
#define      WFS_CDM_STATCUMISSING                (6)
#define      WFS_CDM_STATCUNOVAL                  (7)
#define      WFS_CDM_STATCUNOREF                  (8)
#define      WFS_CDM_STATCUMANIP                  (9)

/* values of WFSCDMMIXTYPE.usMixType */

#define      WFS_CDM_MIXALGORITHM                 (1)
#define      WFS_CDM_MIXTABLE                     (2)

/* values of WFSCDMMIXTYPE.usMixNumber */

#define      WFS_CDM_INDIVIDUAL                   (0)

/* values of WFSCDMMIXTYPE.usSubType (predefined mix algorithms) */

#define      WFS_CDM_MIX_MINIMUM_NUMBER_OF_BILLS (1)
#define      WFS_CDM_MIX_EQUAL_EMPTYING_OF_CASH_UNITS (2)
#define      WFS_CDM_MIX_MAXIMUM_NUMBER_OF_CASH_UNITS (3)

/* values of WFSCDMPRESENTSTATUS.wPresentState */

#define      WFS_CDM_PRESENTED                    (1)
#define      WFS_CDM_NOTPRESENTED                 (2)
#define      WFS_CDM_UNKNOWN                      (3)
```

```
/* values of WFSCDMDISPENSE.fwPosition */
/* values of WFSCDMCAPS.fwPositions */
/* values of WFSCDMOUTPOS.fwPosition */
/* values of WFSCDMTELLERPOS.fwPosition */
/* values of WFSCDMTELLERDETAILS.fwOutputPosition */
/* values of WFSCDMPHYSICALCU.fwPosition */

#define WFS_CDM_POSNULL (0x0000)
#define WFS_CDM_POSLEFT (0x0001)
#define WFS_CDM_POSRIGHT (0x0002)
#define WFS_CDM_POSCENTER (0x0004)
#define WFS_CDM_POSTOP (0x0040)
#define WFS_CDM_POSBOTTOM (0x0080)
#define WFS_CDM_POSFRONT (0x0800)
#define WFS_CDM_POSREAR (0x1000)

/* additional values of WFSCDMPHYSICALCU.fwPosition */
#define WFS_CDM_POSREJECT (0x0100)

/* values of WFSCDMTELLERDETAILS.ulInputPosition */

#define WFS_CDM_POSINLEFT (0x0001)
#define WFS_CDM_POSINRIGHT (0x0002)
#define WFS_CDM_POSINCENTER (0x0004)
#define WFS_CDM_POSINTOP (0x0008)
#define WFS_CDM_POSINBOTTOM (0x0010)
#define WFS_CDM_POSINFRONT (0x0020)
#define WFS_CDM_POSINREAR (0x0040)

/* values of fwExchangeType */

#define WFS_CDM_EXBYHAND (0x0001)
#define WFS_CDM_EXTOCASSETTES (0x0002)

/* values of WFSCDMTELLERUPDATE.usAction */

#define WFS_CDM_CREATE_TELLER (1)
#define WFS_CDM_MODIFY_TELLER (2)
#define WFS_CDM_DELETE_TELLER (3)

/* values of WFSCDMCUERROR.wFailure */

#define WFS_CDM_CASHUNITEMPTY (1)
#define WFS_CDM_CASHUNITERROR (2)
#define WFS_CDM_CASHUNITFULL (4)
#define WFS_CDM_CASHUNITLOCKED (5)
#define WFS_CDM_CASHUNITINVALID (6)
#define WFS_CDM_CASHUNITCONFIG (7)
#define WFS_CDM_CASHUNITNOTCONF (8)

/* values of lpusReason in WFS_EXEE_CDM_NOTESERROR */

#define WFS_CDM_DOUBLENOTEDETECTED (1)
#define WFS_CDM_LONGNOTEDETECTED (2)
#define WFS_CDM_SKEWEDNOTE (3)
#define WFS_CDM_INCORRECTCOUNT (4)
#define WFS_CDM_NOTESTOOCLOSE (5)
#define WFS_CDM_OTHERNOTEERROR (6)
#define WFS_CDM_SHORTNOTEDETECTED (7)

/* values of WFSCDMPREPAREDISPENSE.wAction */
#define WFS_CDM_START (1)
#define WFS_CDM_STOP (2)

/* WOSA/XFS CDM Errors */
```

```
#define WFS_ERR_CDM_INVALIDCURRENCY          (- (CDM_SERVICE_OFFSET + 0))
#define WFS_ERR_CDM_INVALIDTELLERID        (- (CDM_SERVICE_OFFSET + 1))
#define WFS_ERR_CDM_CASHUNITERROR          (- (CDM_SERVICE_OFFSET + 2))
#define WFS_ERR_CDM_INVALIDDENOMINATION    (- (CDM_SERVICE_OFFSET + 3))
#define WFS_ERR_CDM_INVALIDMIXNUMBER       (- (CDM_SERVICE_OFFSET + 4))
#define WFS_ERR_CDM_NOCURRENCYMIX         (- (CDM_SERVICE_OFFSET + 5))
#define WFS_ERR_CDM_NOTDISPENSABLE         (- (CDM_SERVICE_OFFSET + 6))
#define WFS_ERR_CDM_TOOMANYITEMS           (- (CDM_SERVICE_OFFSET + 7))
#define WFS_ERR_CDM_UNSUPPOSITION           (- (CDM_SERVICE_OFFSET + 8))
#define WFS_ERR_CDM_SAFEDOOROPEN           (- (CDM_SERVICE_OFFSET + 10))
#define WFS_ERR_CDM_SHUTTERNOTOPEN         (- (CDM_SERVICE_OFFSET + 12))
#define WFS_ERR_CDM_SHUTTEROPEN           (- (CDM_SERVICE_OFFSET + 13))
#define WFS_ERR_CDM_SHUTTERCLOSED          (- (CDM_SERVICE_OFFSET + 14))
#define WFS_ERR_CDM_INVALIDCASHUNIT        (- (CDM_SERVICE_OFFSET + 15))
#define WFS_ERR_CDM_NOITEMS                (- (CDM_SERVICE_OFFSET + 16))
#define WFS_ERR_CDM_EXCHANGEACTIVE         (- (CDM_SERVICE_OFFSET + 17))
#define WFS_ERR_CDM_NOEXCHANGEACTIVE       (- (CDM_SERVICE_OFFSET + 18))
#define WFS_ERR_CDM_SHUTTERNOTCLOSED      (- (CDM_SERVICE_OFFSET + 19))
#define WFS_ERR_CDM_PRERRORNNOITEMS       (- (CDM_SERVICE_OFFSET + 20))
#define WFS_ERR_CDM_PRERRORITEMS          (- (CDM_SERVICE_OFFSET + 21))
#define WFS_ERR_CDM_PRERRORUNKNOWN        (- (CDM_SERVICE_OFFSET + 22))
#define WFS_ERR_CDM_ITEMSTAKEN             (- (CDM_SERVICE_OFFSET + 23))
#define WFS_ERR_CDM_INVALIDMIXTABLE        (- (CDM_SERVICE_OFFSET + 27))
#define WFS_ERR_CDM_OUTPUTPOS_NOT_EMPTY    (- (CDM_SERVICE_OFFSET + 28))
#define WFS_ERR_CDM_INVALIDRETRACTPOSITION (- (CDM_SERVICE_OFFSET + 29))
#define WFS_ERR_CDM_NOTRETRACTAREA         (- (CDM_SERVICE_OFFSET + 30))
#define WFS_ERR_CDM_NOCASHBOXPRESENTE     (- (CDM_SERVICE_OFFSET + 33))
#define WFS_ERR_CDM_AMOUNTNOTINMIXTABLE   (- (CDM_SERVICE_OFFSET + 34))
#define WFS_ERR_CDM_ITEMSNOTTAKEN         (- (CDM_SERVICE_OFFSET + 35))
#define WFS_ERR_CDM_ITEMSLEFT              (- (CDM_SERVICE_OFFSET + 36))
#define WFS_ERR_CDM_INVALID_PORT           (- (CDM_SERVICE_OFFSET + 37))
#define WFS_ERR_CDM_POWERSAVETOOSHORT     (- (CDM_SERVICE_OFFSET + 38))
#define WFS_ERR_CDM_POWERSAVEMEDIAPRESENT (- (CDM_SERVICE_OFFSET + 39))
```

```
/*=====*/
/* CDM Info Command Structures */
/*=====*/
```

```
typedef struct _wfs_cdm_position
{
    WORD          fwPosition;
    WORD          fwShutter;
    WORD          fwPositionStatus;
    WORD          fwTransport;
    WORD          fwTransportStatus;
} WFS_CDM_OUTPOS, *LPWFS_CDM_OUTPOS;
```

```
typedef struct _wfs_cdm_status
{
    WORD          fwDevice;
    WORD          fwSafeDoor;
    WORD          fwDispenser;
    WORD          fwIntermediateStacker;
    LPWFS_CDM_OUTPOS *lppPositions;
    LPSTR         lpszExtra;
    DWORD         dwGuidLights[WFS_CDM_GUIDLIGHTS_SIZE];
    WORD          wDevicePosition;
    USHORT        usPowerSaveRecoveryTime;
} WFS_CDM_STATUS, *LPWFS_CDM_STATUS;
```

```
typedef struct _wfs_cdm_caps
{
    WORD          wClass;
    WORD          fwType;
    WORD          wMaxDispenseItems;
    BOOL          bCompound;
    BOOL          bShutter;
    BOOL          bShutterControl;
    WORD          fwRetractAreas;
    WORD          fwRetractTransportActions;
```

```

WORD                fwRetractStackerActions;
BOOL                bSafeDoor;
BOOL                bCashBox;
BOOL                bIntermediateStacker;
BOOL                bItemsTakenSensor;
WORD                fwPositions;
WORD                fwMoveItems;
WORD                fwExchangeType;
LPSTR               lpszExtra;
DWORD               dwGuidLights[WFS_CDM_GUIDLIGHTS_SIZE];
BOOL                bPowerSaveControl;
BOOL                bPrepareDispense;
} WFS_CDMCAPS, *LPWFS_CDMCAPS;

typedef struct _wfs_cdm_physicalcu
{
    LPSTR             lpPhysicalPositionName;
    CHAR              cUnitID[5];
    ULONG             ulInitialCount;
    ULONG             ulCount;
    ULONG             ulRejectCount;
    ULONG             ulMaximum;
    USHORT            usPStatus;
    BOOL              bHardwareSensor;
    ULONG             ulDispensedCount;
    ULONG             ulPresentedCount;
    ULONG             ulRetractedCount;
} WFS_CDMPHCU, *LPWFS_CDMPHCU;

typedef struct _wfs_cdm_cashunit
{
    USHORT            usNumber;
    USHORT            usType;
    LPSTR             lpszCashUnitName;
    CHAR              cUnitID[5];
    CHAR              cCurrencyID[3];
    ULONG             ulValues;
    ULONG             ulInitialCount;
    ULONG             ulCount;
    ULONG             ulRejectCount;
    ULONG             ulMinimum;
    ULONG             ulMaximum;
    BOOL              bAppLock;
    USHORT            usStatus;
    USHORT            usNumPhysicalCUs;
    LPWFS_CDMPHCU    *lppPhysical;
    ULONG             ulDispensedCount;
    ULONG             ulPresentedCount;
    ULONG             ulRetractedCount;
} WFS_CDMCASHUNIT, *LPWFS_CDMCASHUNIT;

typedef struct _wfs_cdm_cu_info
{
    USHORT            usTellerID;
    USHORT            usCount;
    LPWFS_CDMCASHUNIT *lppList;
} WFS_CDMCUINFO, *LPWFS_CDMCUINFO;

typedef struct _wfs_cdm_teller_info
{
    USHORT            usTellerID;
    CHAR              cCurrencyID[3];
} WFS_CDMTELLERINFO, *LPWFS_CDMTELLERINFO;

typedef struct _wfs_cdm_teller_totals
{
    char              cCurrencyID[3];
    ULONG             ulItemsReceived;
    ULONG             ulItemsDispensed;
    ULONG             ulCoinsReceived;
}

```

```
        ULONG                ulCoinsDispensed;
        ULONG                ulCashBoxReceived;
        ULONG                ulCashBoxDispensed;
    } WFSCDMTELLERTOTALS, *LPWFSCDMTELLERTOTALS;

typedef struct _wfs_cdm_teller_details
{
    USHORT                usTellerID;
    ULONG                ulInputPosition;
    WORD                 fwOutputPosition;
    LPWFSCDMTELLERTOTALS *lppTellerTotals;
} WFSCDMTELLERDETAILS, *LPWFSCDMTELLERDETAILS;

typedef struct _wfs_cdm_currency_exp
{
    CHAR                 cCurrencyID[3];
    SHORT                sExponent;
} WFSCDMCURRENCYEXP, *LPWFSCDMCURRENCYEXP;

typedef struct _wfs_cdm_mix_type
{
    USHORT                usMixNumber;
    USHORT                usMixType;
    USHORT                usSubType;
    LPSTR                lpszName;
} WFSCDMMIXTYPE, *LPWFSCDMMIXTYPE;

typedef struct _wfs_cdm_mix_row
{
    ULONG                ulAmount;
    LPUSHORT             lpusMixture;
} WFSCDMMIXROW, *LPWFSCDMMIXROW;

typedef struct _wfs_cdm_mix_table
{
    USHORT                usMixNumber;
    LPSTR                lpszName;
    USHORT                usRows;
    USHORT                usCols;
    LPULONG              lpulMixHeader;
    LPWFSCDMMIXROW       *lppMixRows;
} WFSCDMMIXTABLE, *LPWFSCDMMIXTABLE;

typedef struct _wfs_cdm_denomination
{
    CHAR                 cCurrencyID[3];
    ULONG                ulAmount;
    USHORT                usCount;
    LPULONG              lpulValues;
    ULONG                ulCashBox;
} WFSCDMDENOMINATION, *LPWFSCDMDENOMINATION;

typedef struct _wfs_cdm_present_status
{
    LPWFSCDMDENOMINATION lpDenomination;
    WORD                 wPresentState;
    LPSTR                lpszExtra;
} WFSCDMPRESENTSTATUS, *LPWFSCDMPRESENTSTATUS;

/*=====*/
/* CDM Execute Command Structures */
/*=====*/

typedef struct _wfs_cdm_denominate
{
    USHORT                usTellerID;
    USHORT                usMixNumber;
    LPWFSCDMDENOMINATION lpDenomination;
} WFSCDMDENOMINATE, *LPWFSCDMDENOMINATE;
```

```

typedef struct _wfs_cdm_dispense
{
    USHORT          usTellerID;
    USHORT          usMixNumber;
    WORD            fwPosition;
    BOOL            bPresent;
    LPWFSCMDNOMINATION lpDenomination;
} WFSCMDDISPENSE, *LPWFSCMDDISPENSE;

typedef struct _wfs_cdm_physical_cu
{
    BOOL            bEmptyAll;
    WORD            fwPosition;
    LPSTR           lpPhysicalPositionName;
} WFSCMDPHYSICALCU, *LPWFSCMDPHYSICALCU;

typedef struct _wfs_cdm_counted_phys_cu
{
    LPSTR           lpPhysicalPositionName;
    CHAR            cUnitId[5];
    ULONG           ulDispensed;
    ULONG           ulCounted;
    USHORT          usPStatus;
} WFSCMDCOUNTEDPHYSCU, *LPWFSCMDCOUNTEDPHYSCU;

typedef struct _wfs_cdm_count
{
    USHORT          usNumPhysicalCUs;
    LPWFSCMDCOUNTEDPHYSCU *lppCountedPhysCUs;
} WFSCMDCOUNT, *LPWFSCMDCOUNT;

typedef struct _wfs_cdm_retract
{
    WORD            fwOutputPosition;
    USHORT          usRetractArea;
    USHORT          usIndex;
} WFSCDMRETRACT, *LPWFSCDMRETRACT;

typedef struct _wfs_cdm_teller_update
{
    USHORT          usAction;
    LPWFSCDMTELLERDETAILS lpTellerDetails;
} WFSCDMTELLERUPDATE, *LPWFSCDMTELLERUPDATE;

typedef struct _wfs_cdm_start_ex
{
    WORD            fwExchangeType;
    USHORT          usTellerID;
    USHORT          usCount;
    LPUSHORT        lpusCUNumList;
} WFSCDMSTARTEX, *LPWFSCDMSTARTEX;

typedef struct _wfs_cdm_itemposition
{
    USHORT          usNumber;
    LPWFSCDMRETRACT lpRetractArea;
    WORD            fwOutputPosition;
} WFSCDMITEMPOSITION, *LPWFSCDMITEMPOSITION;

typedef struct _wfs_cdm_calibrate
{
    USHORT          usNumber;
    USHORT          usNumOfBills;
    LPWFSCDMITEMPOSITION *lpPosition;
} WFSCDMCALIBRATE, *LPWFSCDMCALIBRATE;

typedef struct _wfs_cdm_set_guidlight
{

```

```
        WORD                wGuidLight;
        DWORD               dwCommand;
    } WFS_CDMSETGUIDLIGHT, *LPWFS_CDMSETGUIDLIGHT;

typedef struct _wfs_cdm_power_save_control
{
    USHORT                usMaxPowerSaveRecoveryTime;
} WFS_CDMPOWERSAVECONTROL, *LPWFS_CDMPOWERSAVECONTROL;

typedef struct _wfs_cdm_prepare_dispense
{
    WORD                wAction;
} WFS_CDMPREPAREDISPENSE, *LPWFS_CDMPREPAREDISPENSE;

/*=====*/
/* CDM Message Structures */
/*=====*/

typedef struct _wfs_cdm_cu_error
{
    WORD                wFailure;
    LPWFS_CDMCASHUNIT lpCashUnit;
} WFS_CDMCUERROR, *LPWFS_CDMCUERROR;

typedef struct _wfs_cdm_counts_changed
{
    USHORT                usCount;
    LPUSHORT              lpusCUNumList;
} WFS_CDMCOUNTSCHANGED, *LPWFS_CDMCOUNTSCHANGED;

typedef struct _wfs_cdm_device_position
{
    WORD                wPosition;
} WFS_CDMDEVICEPOSITION, *LPWFS_CDMDEVICEPOSITION;

typedef struct _wfs_cdm_power_save_change
{
    USHORT                usPowerSaveRecoveryTime;
} WFS_CDMPOWERSAVECHANGE, *LPWFS_CDMPOWERSAVECHANGE;

/* restore alignment */
#pragma pack (pop)

#ifdef __cplusplus
} /*extern "C"*/
#endif

#endif /* __INC_XFSCDM_H */
```