

CEN

CWA 15748-17

WORKSHOP

July 2008

AGREEMENT

ICS 35.240.50

English version

**Extensions for Financial Services (XFS) interface specification -
Release 3.10 - Part 17: Barcode Reader Device Class Interface
- Programmer's Reference**

This CEN Workshop Agreement has been drafted and approved by a Workshop of representatives of interested parties, the constitution of which is indicated in the foreword of this Workshop Agreement.

The formal process followed by the Workshop in the development of this Workshop Agreement has been endorsed by the National Members of CEN but neither the National Members of CEN nor the CEN Management Centre can be held accountable for the technical content of this CEN Workshop Agreement or possible conflicts with standards or legislation.

This CEN Workshop Agreement can in no way be held as being an official standard developed by CEN and its Members.

This CEN Workshop Agreement is publicly available as a reference document from the CEN Members National Standard Bodies.

CEN members are the national standards bodies of Austria, Belgium, Bulgaria, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland and United Kingdom.



EUROPEAN COMMITTEE FOR STANDARDIZATION
COMITÉ EUROPÉEN DE NORMALISATION
EUROPÄISCHES KOMITEE FÜR NORMUNG

Management Centre: rue de Stassart, 36 B-1050 Brussels

© 2008 CEN All rights of exploitation in any form and by any means reserved worldwide for CEN national Members.

Ref. No.:CWA 15748-17:2008 D/E/F

Table of Contents

Foreword	3
1. Introduction.....	6
1.1 Background to Release 3.10	6
1.2 XFS Service-Specific Programming	6
2. Barcode Readers	7
3. References	8
4. Info Commands	9
4.1 WFS_INF_BCR_STATUS	9
4.2 WFS_INF_BCR_CAPABILITIES.....	11
5. Execute Commands	14
5.1 WFS_CMD_BCR_READ	14
5.2 WFS_CMD_BCR_RESET	16
5.3 WFS_CMD_BCR_SET_GUIDANCE_LIGHT	17
5.4 WFS_CMD_BCR_POWER_SAVE_CONTROL.....	18
6. Events.....	19
6.1 WFS_SRVE_BCR_DEVICEPOSITION	19
6.2 WFS_SRVE_BCR_POWER_SAVE_CHANGE.....	20
7. C - Header file	21

Foreword

This CWA is revision 3.10 of the XFS interface specification.

The CEN/ISSS XFS Workshop gathers suppliers as well as banks and other financial service companies. A list of companies participating in this Workshop and in support of this CWA is available from the CEN/ISSS Secretariat.

This CWA was formally approved by the XFS Workshop meeting on 2007-11-29. The specification is continuously reviewed and commented in the CEN/ISSS Workshop on XFS. It is therefore expected that an update of the specification will be published in due time as a CWA, superseding this revision 3.10.

The CWA is published as a multi-part document, consisting of:

Part 1: Application Programming Interface (API) - Service Provider Interface (SPI) - Programmer's Reference

Part 2: Service Classes Definition - Programmer's Reference

Part 3: Printer and Scanning Device Class Interface - Programmer's Reference

Part 4: Identification Card Device Class Interface - Programmer's Reference

Part 5: Cash Dispenser Device Class Interface - Programmer's Reference

Part 6: PIN Keypad Device Class Interface - Programmer's Reference

Part 7: Check Reader/Scanner Device Class Interface - Programmer's Reference

Part 8: Depository Device Class Interface - Programmer's Reference

Part 9: Text Terminal Unit Device Class Interface - Programmer's Reference

Part 10: Sensors and Indicators Unit Device Class Interface - Programmer's Reference

Part 11: Vendor Dependent Mode Device Class Interface - Programmer's Reference

Part 12: Camera Device Class Interface - Programmer's Reference

Part 13: Alarm Device Class Interface - Programmer's Reference

Part 14: Card Embossing Unit Device Class Interface - Programmer's Reference

Part 15: Cash-In Module Device Class Interface - Programmer's Reference

Part 16: Card Dispenser Device Class Interface - Programmer's Reference

Part 17: Barcode Reader Device Class Interface - Programmer's Reference

Part 18: Item Processing Module Device Class Interface - Programmer's Reference

Parts 19 - 28: Reserved for future use.

Parts 29 through 47 constitute an optional addendum to this CWA. They define the integration between the SNMP standard and the set of status and statistical information exported by the Service Providers.

Part 29: XFS MIB Architecture and SNMP Extensions - Programmer's Reference

Part 30: XFS MIB Device Specific Definitions - Printer Device Class

Part 31: XFS MIB Device Specific Definitions - Identification Card Device Class

Part 32: XFS MIB Device Specific Definitions - Cash Dispenser Device Class

Part 33: XFS MIB Device Specific Definitions - PIN Keypad Device Class

Part 34: XFS MIB Device Specific Definitions - Check Reader/Scanner Device Class

Part 35: XFS MIB Device Specific Definitions - Depository Device Class

Part 36: XFS MIB Device Specific Definitions - Text Terminal Unit Device Class

Part 37: XFS MIB Device Specific Definitions - Sensors and Indicators Unit Device Class

Part 38: XFS MIB Device Specific Definitions - Camera Device Class

Part 39: XFS MIB Device Specific Definitions - Alarm Device Class

Part 40: XFS MIB Device Specific Definitions - Card Embossing Unit Class

Part 41: XFS MIB Device Specific Definitions - Cash-In Module Device Class

Part 42: Reserved for future use.

Part 43: XFS MIB Device Specific Definitions - Vendor Dependent Mode Device Class

Part 44: XFS MIB Application Management

Part 45: XFS MIB Device Specific Definitions - Card Dispenser Device Class

Part 46: XFS MIB Device Specific Definitions - Barcode Reader Device Class

Part 47: XFS MIB Device Specific Definitions - Item Processing Module Device Class

Parts 48 - 60 are reserved for future use.

Part 61: Application Programming Interface (API) - Service Provider Interface (SPI) - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 62: Printer Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 63: Identification Card Device Class Interface - Migration from Version 3.02 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 64: Cash Dispenser Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 65: PIN Keypad Device Class Interface - Migration from Version 3.03 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 66: Check Reader/Scanner Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 67: Depository Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 68: Text Terminal Unit Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 69: Sensors and Indicators Unit Device Class Interface - Migration from Version 3.01 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 70: Vendor Dependent Mode Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 71: Camera Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 72: Alarm Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 73: Card Embossing Unit Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 74: Cash-In Module Device Class Interface - Migration from Version 3.02 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

In addition to these Programmer's Reference specifications, the reader of this CWA is also referred to a complementary document, called Release Notes. The Release Notes contain clarifications and explanations on the CWA specifications, which are not requiring functional changes. The current version of the Release Notes is available online from <http://www.cen.eu/iss/Workshop/XFS>.

The information in this document represents the Workshop's current views on the issues discussed as of the date of publication. It is furnished for informational purposes only and is subject to change without notice. CEN/ISSS makes no warranty, express or implied, with respect to this document.

This CEN Workshop Agreement is publicly available as a reference document from the National Members of CEN : AENOR, AFNOR, ASRO, BDS, BSI, CSNI, CYS, DIN, DS, ELOT, EVS, IBN, IPQ, IST, LVS, LST, MSA, MSZT, NEN, NSAI, ON, PKN, SEE, SIS, SIST, SFS, SN, SNV, SUTN and UNI.

Comments or suggestions from the users of the CEN Workshop Agreement are welcome and should be addressed to the CEN Management Centre.

Revision History:

3.10	November 29, 2007	Initial release.
------	-------------------	------------------

1. Introduction

1.1 Background to Release 3.10

The CEN/ISSS XFS Workshop aims to promote a clear and unambiguous specification defining a multi-vendor software interface to financial peripheral devices. The XFS (eXtensions for Financial Services) specifications are developed within the CEN/ISSS (European Committee for Standardization/Information Society Standardization System) Workshop environment. CEN/ISSS Workshops aim to arrive at a European consensus on an issue that can be published as a CEN Workshop Agreement (CWA).

The CEN/ISSS XFS Workshop encourages the participation of both banks and vendors in the deliberations required to create an industry standard. The CEN/ISSS XFS Workshop achieves its goals by focused sub-groups working electronically and meeting quarterly.

Release 3.10 of the XFS specification is based on a C API and is delivered with the continued promise for the protection of technical investment for existing applications. This release of the XFS specification has been prompted by a series of factors.

There has been a technical imperative to extend the scope of the existing specification to include new devices, such as the Barcode Reader, Card Dispenser and Item Processing Module.

Similarly, there has also been pressure, through implementation experience and additional requirements, to extend the functionality and capabilities of the existing devices covered by the specification.

1.2 XFS Service-Specific Programming

The service classes are defined by their service-specific commands and the associated data structures, error codes, messages, etc. These commands are used to request functions that are specific to one or more classes of Service Providers, but not all of them, and therefore are not included in the common API for basic or administration functions.

When a service-specific command is common among two or more classes of Service Providers, the syntax of the command is as similar as possible across all services, since a major objective of the XFS is to standardize function codes and structures for the broadest variety of services. For example, using the **WFSExecute** function, the commands to read data from various services are as similar as possible to each other in their syntax and data structures.

In general, the specific command set for a service class is defined as a superset of the specific capabilities likely to be provided by the developers of the services of that class; thus any particular device will normally support only a subset of the defined command set.

There are three cases in which a Service Provider may receive a service-specific command that it does not support:

The requested capability is defined for the class of Service Providers by the XFS specification, the particular vendor implementation of that service does not support it, and the unsupported capability is *not* considered to be fundamental to the service. In this case, the Service Provider returns a successful completion, but does no operation. An example would be a request from an application to turn on a control indicator on a passbook printer; the Service Provider recognizes the command, but since the passbook printer it is managing does not include that indicator, the Service Provider does no operation and returns a successful completion to the application.

The requested capability is defined for the class of Service Providers by the XFS specification, the particular vendor implementation of that service does not support it, and the unsupported capability *is* considered to be fundamental to the service. In this case, a `WFS_ERR_UNSUPP_COMMAND` error is returned to the calling application. An example would be a request from an application to a cash dispenser to dispense coins; the Service Provider recognizes the command but, since the cash dispenser it is managing dispenses only notes, returns this error.

The requested capability is *not* defined for the class of Service Providers by the XFS specification. In this case, a `WFS_ERR_INVALID_COMMAND` error is returned to the calling application.

This design allows implementation of applications that can be used with a range of services that provide differing subsets of the functionalities that are defined for their service class. Applications may use the **WFSGetInfo** and **WFSAsyncGetInfo** commands to inquire about the capabilities of the service they are about to use, and modify their behavior accordingly, or they may use functions and then deal with `WFS_ERR_UNSUPP_COMMAND` error returns to make decisions as to how to use the service.

2. Barcode Readers

This specification describes the functionality of a Barcode Reader (BCR) Service Provider. It defines the service-specific commands that can be issued to the Service Provider using the **WFSGetInfo**, **WFSAsyncGetInfo**, **WFSExecute** and **WFSAsyncExecute** functions.

Persistent values are maintained through power failures, open sessions, close session and system resets.

This extension to XFS specifications defines the functionality of BCR service.

A Barcode Reader scans barcodes using any scanning technology. The device logic converts light signals or image recognition into application data and transmits it to the host system.

The basic operation of the Barcode Reader is managed using **WFSExecute/WFSAsyncExecute** functions.

When an application wants to read a barcode, it issues a **WFS_CMD_BCR_READ** command to prepare the scanner to read any barcode presented to it. When a document is presented to the BCR and a barcode type is recognized, a completion event is received which contains the barcode data that has been read.

3. References

1. XFS Application Programming Interface (API)/Service Provider Interface (SPI), Programmer's Reference Revision 3.10

4. Info Commands

4.1 WFS_INF_BCR_STATUS

Description This command is used to request status information for the device.

Input Param None.

Output Param LPWFSBCRSTATUS lpStatus;

```
typedef struct _wfs_bcr_status
{
    WORD                fwDevice;
    WORD                fwBCRScanner;
    DWORD              dwGuidLights[WFS_BCR_GUIDLIGHTS_SIZE];
    LPSTR              lpszExtra;
    WORD               wDevicePosition;
    USHORT             usPowerSaveRecoveryTime;
} WFSBCRSTATUS, *LPWFSBCRSTATUS;
```

fwDevice

Specifies the state of the BCR device as one of the following flags:

Value	Meaning
WFS_BCR_DEVONLINE	The device is online (i.e. powered on and operable).
WFS_BCR_DEVOFFLINE	The device is offline (e.g., the operator has taken the device offline by turning a switch or pulling out the device).
WFS_BCR_DEVPOWEROFF	The device is powered off or physically not connected.
WFS_BCR_DEVNODEVICE	There is no device intended to be there; e.g. this type of self service machine does not contain such a device or it is internally not configured.
WFS_BCR_DEVHWERROR	The device is inoperable due to a hardware error.
WFS_BCR_DEVUSERERROR	The device is present but a person is preventing proper device operation.
WFS_BCR_DEVBUSY	The device is busy and unable to process an execute command at this time.
WFS_BCR_DEVFRAUDATTEMPT	The device is present but has detected a fraud attempt.

fwBCRScanner

Specifies the scanner status (laser, camera or other technology) as one of the following flags:

Value	Meaning
WFS_BCR_SCANNERON	Scanner is enabled for reading.
WFS_BCR_SCANNEROFF	Scanner is disabled.
WFS_BCR_SCANNERINOP	Scanner is inoperative due to a hardware error.
WFS_BCR_SCANNERUNKNOWN	Scanner status cannot be determined.

dwGuidLights [...]

Specifies the state of the guidance light indicators. A number of guidance light types are defined below. Vendor specific guidance lights are defined starting from the end of the array. The maximum guidance light index is WFS_BCR_GUIDLIGHTS_MAX.

Specifies the state of the guidance light indicator as

WFS_BCR_GUIDANCE_NOT_AVAILABLE, WFS_BCR_GUIDANCE_OFF or a combination of the following flags consisting of one type B, and optionally one type C.

Value	Meaning	Type
WFS_BCR_GUIDANCE_NOT_AVAILABLE	The status is not available.	A
WFS_BCR_GUIDANCE_OFF	The light is turned off.	A

WFS_BCR_GUIDANCE_SLOW_FLASH	The light is blinking slowly.	B
WFS_BCR_GUIDANCE_MEDIUM_FLASH	The light is blinking medium frequency.	B
WFS_BCR_GUIDANCE_QUICK_FLASH	The light is blinking quickly.	B
WFS_BCR_GUIDANCE_CONTINUOUS	The light is turned on continuous (steady).	B
WFS_BCR_GUIDANCE_RED	The light is red.	C
WFS_BCR_GUIDANCE_GREEN	The light is green.	C
WFS_BCR_GUIDANCE_YELLOW	The light is yellow.	C
WFS_BCR_GUIDANCE_BLUE	The light is blue.	C
WFS_BCR_GUIDANCE_CYAN	The light is cyan.	C
WFS_BCR_GUIDANCE_MAGENTA	The light is magenta.	C
WFS_BCR_GUIDANCE_WHITE	The light is white.	C

dwGuidLights [WFS_BCR_GUIDANCE_BCR]

Specifies the state of the guidance light indicator on the Barcode Reader unit.

lpzExtra

Pointer to a list of vendor-specific, or any other extended, information. The information is returned as a series of "key=value" strings so that it is easily extensible by Service Providers. Each string is null-terminated, with the final string terminating with two null characters. An empty list may be indicated by either a NULL pointer or a pointer to two consecutive null characters.

wDevicePosition

Specifies the device position. The device position value is independent of the *fwDevice* value, e.g. when the device position is reported as WFS_BCR_DEVICENOTINPOSITION, *fwDevice* can have any of the values defined above (including WFS_BCR_DEVONLINE or WFS_BCR_DEVOFFLINE). This value is one of the following values:

Value	Meaning
WFS_BCR_DEVICEINPOSITION	The device is in its normal operating position, or is fixed in place and cannot be moved.
WFS_BCR_DEVICENOTINPOSITION	The device has been removed from its normal operating position.
WFS_BCR_DEVICEPOSUNKNOWN	Due to a hardware error or other condition, the position of the device cannot be determined.
WFS_BCR_DEVICEPOSNOTSUPP	The physical device does not have the capability of detecting the position.

usPowerSaveRecoveryTime

Specifies the actual number of seconds required by the device to resume its normal operational state from the current power saving mode. This value is zero if either the power saving mode has not been activated or no power save control is supported.

Error Codes Only the generic error codes defined in [Ref. 1] can be generated by this command.

Comments In the case where communications with the device has been lost, the *fwDevice* field will report WFS_BCR_DEVPOWEROFF when the device has been removed or WFS_BCR_DEVHWERROR if the communications are unexpectedly lost. All other fields should contain a value based on the following rules and priority:

1. Report the value as unknown.
2. Report the value as a general h/w error.
3. Report the value as the last known value.

4.2 WFS_INF_BCR_CAPABILITIES

Description This command is used to retrieve the capabilities of the BCR unit.

Input Param None.

Output Param LPWFSBCRCAPS lpCaps;

```
typedef struct _wfs_bcr_caps
{
    WORD                wClass;
    BOOL                bCompound;
    BOOL                bCanFilterSymbologies;
    LPWORD              lpwSymbologies;
    DWORD               dwGuidLights[WFS_BCR_GUIDLIGHTS_SIZE];
    LPSTR               lpszExtra;
    BOOL                bPowerSaveControl;
} WFSBCRCAPS, *LPWFSBCRCAPS;
```

wClass

Specifies the logical service class as WFS_SERVICE_CLASS_BCR.

bCompound

Specifies whether the logical device is part of a compound physical device.

bCanFilterSymbologies

Specifies whether the device is capable of discriminating between the presented barcode symbologies such that only the desired symbologies are recognized/reported.

lpwSymbologies

Pointer to an array of WORDs. This list specifies the barcode symbologies readable by the scanner. The array is terminated with a zero value. *lpwSymbologies* is a NULL pointer if the supported barcode symbologies can not be determined.

Value	Meaning
WFS_BCR_SYM_EAN128	GS1-128
WFS_BCR_SYM_EAN8	EAN-8
WFS_BCR_SYM_EAN8_2	EAN-8 with 2 digit add-on
WFS_BCR_SYM_EAN8_5	EAN-8 with 5 digit add-on
WFS_BCR_SYM_EAN13	EAN13
WFS_BCR_SYM_EAN13_2	EAN-13 with 2 digit add-on
WFS_BCR_SYM_EAN13_5	EAN-13 with 5 digit add-on
WFS_BCR_SYM_JAN13	JAN-13
WFS_BCR_SYM_UPCA	UPC-A
WFS_BCR_SYM_UPCE0	UPC-E
WFS_BCR_SYM_UPCE0_2	UPC-E with 2 digit add-on
WFS_BCR_SYM_UPCE0_5	UPC-E with 5 digit add-on
WFS_BCR_SYM_UPCE1	UPC-E with leading 1
WFS_BCR_SYM_UPCE1_2	UPC-E with leading 1 and 2 digit add-on
WFS_BCR_SYM_UPCE1_5	UPC-E with leading 1 and 5 digit add-on
WFS_BCR_SYM_UPCA_2	UPC-A with 2 digit add-on
WFS_BCR_SYM_UPCA_5	UPC-A with 5 digit add-on
WFS_BCR_SYM_CODABAR	CODABAR (NW-7)
WFS_BCR_SYM_ITF	Interleaved 2 of 5 (ITF)
WFS_BCR_SYM_11	CODE 11 (USD-8)
WFS_BCR_SYM_39	CODE 39
WFS_BCR_SYM_49	CODE 49
WFS_BCR_SYM_93	CODE 93
WFS_BCR_SYM_128	CODE 128
WFS_BCR_SYM_MSI	MSI
WFS_BCR_SYM_PLESSEY	PLESSEY
WFS_BCR_SYM_STD2OF5	STANDARD 2 of 5 (INDUSTRIAL 2 of 5 also)
WFS_BCR_SYM_STD2OF5_IATA	STANDARD 2 of 5 (IATA Version)
WFS_BCR_SYM_PDF_417	PDF-417

WFS_BCR_SYM_MICROPDF_417	MICROPDF-417
WFS_BCR_SYM_DATAMATRIX	GS1 DataMatrix
WFS_BCR_SYM_MAXICODE	MAXICODE
WFS_BCR_SYM_CODEONE	CODE ONE
WFS_BCR_SYM_CHANNELCODE	CHANNEL CODE
WFS_BCR_SYM_TELEPEN_ORIGINAL	Original TELEPEN
WFS_BCR_SYM_TELEPEN_AIM	AIM version of TELEPEN
WFS_BCR_SYM_RSS	GS1 DataBar™
WFS_BCR_SYM_RSS_EXPANDED	Expanded GS1 DataBar™
WFS_BCR_SYM_RSS_RESTRICTED	Restricted GS1 DataBar™
WFS_BCR_SYM_COMPOSITE_CODE_A	Composite Code A Component
WFS_BCR_SYM_COMPOSITE_CODE_B	Composite Code B Component
WFS_BCR_SYM_COMPOSITE_CODE_C	Composite Code C Component
WFS_BCR_SYM_POSICODE_A	Posicode Variation A
WFS_BCR_SYM_POSICODE_B	Posicode Variation B
WFS_BCR_SYM_TRIOPTIC_CODE_39	Trioptic Code 39
WFS_BCR_SYM_CODABLOCK_F	Codablock F
WFS_BCR_SYM_CODE_16K	Code 16K
WFS_BCR_SYM_QRCODE	QR Code
WFS_BCR_SYM_AZTEC	Aztec Codes
WFS_BCR_SYM_UKPOST	UK Post
WFS_BCR_SYM_PLANET	US Postal Planet
WFS_BCR_SYM_POSTNET	US Postal Postnet
WFS_BCR_SYM_CANADIANPOST	Canadian Post
WFS_BCR_SYM_NETHERLANDSPOST	Netherlands Post
WFS_BCR_SYM_AUSTRALIANPOST	Australian Post
WFS_BCR_SYM_JAPANESEPOST	Japanese Post
WFS_BCR_SYM_CHINESEPOST	Chinese Post
WFS_BCR_SYM_KOREANPOST	Korean Post

dwGuidLights [...]

Specifies which guidance lights are available. A number of guidance light types are defined below. Vendor specific guidance lights are defined starting from the end of the array. The maximum guidance light index is WFS_BCR_GUIDLIGHTS_MAX.

The elements of this array are specified as a combination of the following flags and indicate all of the possible flash rates (type B) and colors (type C) that the guidance light indicator is capable of handling. If the guidance light indicator only supports one color then no value of type C is returned. A value of WFS_BCR_GUIDANCE_NOT_AVAILABLE indicates that the device has no guidance light indicator or the device controls the light directly with no application control possible.

Value	Meaning	Type
WFS_BCR_GUIDANCE_NOT_AVAILABLE	There is no guidance light control available at this position.	A
WFS_BCR_GUIDANCE_OFF	The light can be off.	B
WFS_BCR_GUIDANCE_SLOW_FLASH	The light can blink slowly.	B
WFS_BCR_GUIDANCE_MEDIUM_FLASH	The light can blink medium frequency.	B
WFS_BCR_GUIDANCE_QUICK_FLASH	The light can blink quickly.	B
WFS_BCR_GUIDANCE_CONTINUOUS	The light can be continuous (steady).	B
WFS_BCR_GUIDANCE_RED	The light can be red.	C
WFS_BCR_GUIDANCE_GREEN	The light can be green.	C
WFS_BCR_GUIDANCE_YELLOW	The light can be yellow.	C
WFS_BCR_GUIDANCE_BLUE	The light can be blue.	C
WFS_BCR_GUIDANCE_CYAN	The light can be cyan.	C
WFS_BCR_GUIDANCE_MAGENTA	The light can be magenta.	C
WFS_BCR_GUIDANCE_WHITE	The light can be white.	C

dwGuidLights [WFS_BCR_GUIDANCE_BCR]

Specifies whether the guidance light indicator on the barcode reader unit is available.

lpzExtra

Pointer to a list of vendor-specific, or any other extended, information. The information is returned as a series of “*key=value*” strings so that it is easily extensible by Service Providers. Each string is null-terminated, with the final string terminating with two null characters. An empty list may be indicated by either a NULL pointer or a pointer to two consecutive null characters.

bPowerSaveControl

Specifies whether power saving control is available. This can either be TRUE if available or FALSE if not available.

Error Codes Only the generic error codes defined in [Ref. 1] can be generated by this command.

Comments Applications which require or expect specific information to be present in the *lpzExtra* parameter may not be device or vendor-independent.

5. Execute Commands

5.1 WFS_CMD_BCR_READ

Description This command enables the barcode reader. The barcode reader will scan for barcodes and when it successfully manages to read one or more barcodes the command will complete. The completion event for this command contains the scanned barcode data.

Input Param LPWFSBCRREADINPUT lpReadInput;

```
typedef struct _wfs_bcr_read_input
{
    LPWORD                lpwSymbologies;
} WFSBCRREADINPUT, *LPWFSBCRREADINPUT;
```

lpwSymbologies

Array specifying a list that contains the sub-set of bar code symbologies that the application wants to be accepted for this command. The array is terminated with a zero value.

In some cases the Service Provider can discriminate between barcode symbologies and return the data only if the presented symbology matches with one of the desired symbologies. See the *bCanFilterSymbologies* capability to determine if the Service Provider supports this feature. If the Service Provider does not support this feature then this parameter is ignored. If all symbologies should be accepted then *lpwSymbologies* should be set to NULL.

Output Param LPWFSBCRREADOUTPUT *lppReadOutput;

Pointer to a NULL terminated array of pointers to WFSBCRREADOUTPUT structures. There is one array element for each barcode read during the scan.

```
typedef struct _wfs_bcr_read_output
{
    WORD                wSymbology;
    LPWFSBCRXDATA      lpxBarcodeData;
    LPSTR               lpszSymbologyName;
} WFSBCRREADOUTPUT, *LPWFSBCRREADOUTPUT;
```

wSymbology

Specifies the barcode symbology recognized. This contains one of the values returned in the *lpwSymbologies* field of the WFS_INF_BCR_CAPABILITIES command. If the barcode reader is unable to recognize the symbology as one of the values reported via the device capabilities then the value for this field will be WFS_BCR_SYM_UNKNOWN.

lpxBarcodeData

Contains the barcode data read from the barcode reader. The format of the data will depend on the barcode symbology read. In most cases this will be an array of bytes containing ASCII numeric digits. However, the format of the data in this field depends entirely on the symbology read, e.g. it may contain 8 bit character values where the symbol is dependent on the codepage used to encode the barcode, may contain UNICODE data, or may be a binary block of data. The application is responsible for checking the completeness and validity of the data.

lpszSymbologyName

A vendor dependent symbology identifier for the symbology recognized.

Error Codes In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_BCR_BARCODEINVALID	The read operation could not be completed successfully. The barcode presented was defective or was wrongly read.

Events Only the generic events defined in [Ref. 1] can be generated by this command.

Comments The device waits for the period of time specified by the *dwTimeOut* parameter in the **WFSExecute** call for one of the enabled symbologies to be presented, unless the hardware has a fixed timeout period that is less than the value passed in the **WFSExecute** command.

The data type LPWFSBCRXDATA is used to return the barcode data.

```
typedef struct _wfs_bcr_hex_data
{
    USHORT          usLength;
    LPBYTE          lpbData;
} WFSBCRXDATA, *LPWFSBCRXDATA;
```

usLength

Length of the byte stream pointed to by *lpbData*.

lpbData

Pointer to the data stream.

5.2WFS_CMD_BCR_RESET

Description	This command is used to reset the device. The scanner returns to power-on initial status and remains disabled for any barcode label reading.
Input Param	None.
Output Param	None.
Error Codes	Only the generic errors codes defined in [Ref. 1] can be generated by this command.
Events	Only the generic events defined in [Ref. 1] can be generated by this command.
Comments	None.

5.3 WFS_CMD_BCR_SET_GUIDANCE_LIGHT

Description This command is used to set the status of the BCR guidance lights. This includes defining the flash rate and the color. When an application tries to use a color that is not supported then the Service Provider will return the generic error WFS_ERR_UNSUPP_DATA.

Input Param LPWFSBCRSETGUIDLIGHT lpSetGuidLight;

```
typedef struct _wfs_bcr_set_guidlight
{
    WORD                wGuidLight;
    DWORD              dwCommand;
} WFSBCRSETGUIDLIGHT, *LPWFSBCRSETGUIDLIGHT;
```

wGuidLight

Specifies the index of the guidance light to set as one of the values defined within the capabilities section.

dwCommand

Specifies the state of the guidance light indicator as WFS_BCR_GUIDANCE_OFF or a combination of the following flags consisting of one type B, and optionally one type C. If no value of type C is specified then the default color is used. The Service Provider determines which color is used as the default color.

Value	Meaning	Type
WFS_BCR_GUIDANCE_OFF	The light indicator is turned off.	A
WFS_BCR_GUIDANCE_SLOW_FLASH	The light indicator is set to flash slowly.	B
WFS_BCR_GUIDANCE_MEDIUM_FLASH	The light indicator is set to flash medium frequency.	B
WFS_BCR_GUIDANCE_QUICK_FLASH	The light indicator is set to flash quickly.	B
WFS_BCR_GUIDANCE_CONTINUOUS	The light indicator is turned on continuously (steady).	B
WFS_BCR_GUIDANCE_RED	The light indicator color is set to red.	C
WFS_BCR_GUIDANCE_GREEN	The light indicator color is set to green.	C
WFS_BCR_GUIDANCE_YELLOW	The light indicator color is set to yellow.	C
WFS_BCR_GUIDANCE_BLUE	The light indicator color is set to blue.	C
WFS_BCR_GUIDANCE_CYAN	The light indicator color is set to cyan.	C
WFS_BCR_GUIDANCE_MAGENTA	The light indicator color is set to magenta.	C
WFS_BCR_GUIDANCE_WHITE	The light indicator color is set to white.	C

Output Param None.

Error Codes In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_BCR_INVALID_PORT	An attempt to set a guidance light to a new value was invalid because the guidance light does not exist.

Events Only the generic events defined in [Ref. 1] can be generated by this command.

Comments None.

5.4 WFS_CMD_BCR_POWER_SAVE_CONTROL

Description This command activates or deactivates the power-saving mode.

If the Service Provider receives another execute command while in power saving mode, the Service Provider automatically exits the power saving mode, and executes the requested command. If the Service Provider receives an information command while in power saving mode, the Service Provider will not exit the power saving mode.

Input Param LPWFSBCRPOWERSAVECONTROL lpPowerSaveControl;

```
typedef struct _wfs_bcr_power_save_control
{
    USHORT                usMaxPowerSaveRecoveryTime;
} WFSBCRPOWERSAVECONTROL, *LPWFSBCRPOWERSAVECONTROL;
```

usMaxPowerSaveRecoveryTime

Specifies the maximum number of seconds in which the device must be able to return to its normal operating state when exiting power save mode. The device will be set to the highest possible power save mode within this constraint. If *usMaxPowerSaveRecoveryTime* is set to zero then the device will exit the power saving mode.

Output Param None.

Error Codes In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_BCR_POWERSAVETOOSHORT	The power saving mode has not been activated because the device is not able to resume from the power saving mode within the specified <i>usMaxPowerSaveRecoveryTime</i> value.

Events In addition to the generic events defined in [Ref. 1], the following events can be generated by this command:

Value	Meaning
WFS_SRVE_BCR_POWER_SAVE_CHANGE	The power save recovery time has changed.

Comments None.

6. Events

6.1 WFS_SRVE_BCR_DEVICEPOSITION

Description This service event reports that the device has changed its position status.

Event Param LPWFSBCRDEVICEPOSITION lpDevicePosition;

```
typedef struct _wfs_bcr_device_position
{
    WORD wPosition;
} WFSBCRDEVICEPOSITION, *LPWFSBCRDEVICEPOSITION;
```

wPosition

Position of the device as one of the following values:

Value	Meaning
WFS_BCR_DEVICEINPOSITION	The device is in its normal operating position.
WFS_BCR_DEVICENOTINPOSITION	The device has been removed from its normal operating position.
WFS_BCR_DEVICEPOSUNKNOWN	The position of the device cannot be determined.

Comments None.

6.2 WFS_SRVE_BCR_POWER_SAVE_CHANGE

Description	This service event specifies that the power save recovery time has changed.
Event Param	<p>LPWFSBCRPOWERSAVECHANGE lpPowerSaveChange;</p> <pre>typedef struct _wfs_bcr_power_save_change { USHORT usPowerSaveRecoveryTime; } WFSBCRPOWERSAVECHANGE, *LPWFSBCRPOWERSAVECHANGE;</pre> <p><i>usPowerSaveRecoveryTime</i> Specifies the actual number of seconds required by the device to resume its normal operational state. This value is zero if the device exited the power saving mode.</p>
Comments	None.

7. C - Header file

```

/*****
*
* xfsbcr.h XFS - Barcode Reader (BCR) definitions
*
* Included in the XFS Version 3.10 (29/11/2007)
*
*****/

#ifndef __INC_XFSBCR_H
#define __INC_XFSBCR_H

#ifdef __cplusplus
extern "C" {
#endif

#include <xfsapi.h>

/* be aware of alignment */
#pragma pack (push, 1)

/* values of WFSBCRCAPS.wClass */

#define WFS_SERVICE_CLASS_BCR (15)
#define WFS_SERVICE_CLASS_VERSION_BCR (0x0A03) /* Version 3.10 */
#define WFS_SERVICE_CLASS_NAME_BCR "BCR"

#define BCR_SERVICE_OFFSET (WFS_SERVICE_CLASS_BCR * 100)

/* BCR Info Commands */

#define WFS_INF_BCR_STATUS (BCR_SERVICE_OFFSET + 1)
#define WFS_INF_BCR_CAPABILITIES (BCR_SERVICE_OFFSET + 2)

/* BCR Execute Commands */

#define WFS_CMD_BCR_READ (BCR_SERVICE_OFFSET + 1)
#define WFS_CMD_BCR_RESET (BCR_SERVICE_OFFSET + 2)
#define WFS_CMD_BCR_SET_GUIDANCE_LIGHT (BCR_SERVICE_OFFSET + 3)
#define WFS_CMD_BCR_POWER_SAVE_CONTROL (BCR_SERVICE_OFFSET + 4)

/* BCR Messages */

#define WFS_SRVE_BCR_DEVICEPOSITION (BCR_SERVICE_OFFSET + 1)
#define WFS_SRVE_BCR_POWER_SAVE_CHANGE (BCR_SERVICE_OFFSET + 2)

/* values of WFSBCRSTATUS.fwDevice */

#define WFS_BCR_DEVONLINE WFS_STAT_DEVONLINE
#define WFS_BCR_DEVOFFLINE WFS_STAT_DEVOFFLINE
#define WFS_BCR_DEVPOWEROFF WFS_STAT_DEVPOWEROFF
#define WFS_BCR_DEVNODVICE WFS_STAT_DEVNODVICE
#define WFS_BCR_DEVHWERROR WFS_STAT_DEVHWERROR
#define WFS_BCR_DEVUSERERROR WFS_STAT_DEVUSERERROR
#define WFS_BCR_DEVBUSY WFS_STAT_DEVBUSY
#define WFS_BCR_DEVFRAUDATTEMPT WFS_STAT_DEVFRAUDATTEMPT

/* values of WFSBCRSTATUS.fwBCRScanner */

#define WFS_BCR_SCANNERON (0)
#define WFS_BCR_SCANNEROFF (1)
#define WFS_BCR_SCANNERINOP (2)
#define WFS_BCR_SCANNERUNKNOWN (3)

/* values of WFSBCRSTATUS.wDevicePosition
   WFSBCRDEVICEPOSITION.wPosition */

#define WFS_BCR_DEVICEINPOSITION (0)
#define WFS_BCR_DEVICEINNOTINPOSITION (1)

```

```

#define WFS_BCR_DEVICEPOSUNKNOWN (2)
#define WFS_BCR_DEVICEPOSNOTSUPP (3)

/* values of WFSBCRCAPS.lpwSymbologies
   WFSBCRREADINPUT.lpwSymbologies
   WFSBCRREADOUTPUT.wSymbology */

#define WFS_BCR_SYM_UNKNOWN (0)
#define WFS_BCR_SYM_EAN128 (1)
#define WFS_BCR_SYM_EAN8 (2)
#define WFS_BCR_SYM_EAN8_2 (3)
#define WFS_BCR_SYM_EAN8_5 (4)
#define WFS_BCR_SYM_EAN13 (5)
#define WFS_BCR_SYM_EAN13_2 (6)
#define WFS_BCR_SYM_EAN13_5 (7)
#define WFS_BCR_SYM_JAN13 (8)
#define WFS_BCR_SYM_UPCA (9)
#define WFS_BCR_SYM_UPCE0 (10)
#define WFS_BCR_SYM_UPCE0_2 (11)
#define WFS_BCR_SYM_UPCE0_5 (12)
#define WFS_BCR_SYM_UPCE1 (13)
#define WFS_BCR_SYM_UPCE1_2 (14)
#define WFS_BCR_SYM_UPCE1_5 (15)
#define WFS_BCR_SYM_UPCA_2 (16)
#define WFS_BCR_SYM_UPCA_5 (17)
#define WFS_BCR_SYM_CODABAR (18)
#define WFS_BCR_SYM_ITF (19)
#define WFS_BCR_SYM_11 (20)
#define WFS_BCR_SYM_39 (21)
#define WFS_BCR_SYM_49 (22)
#define WFS_BCR_SYM_93 (23)
#define WFS_BCR_SYM_128 (24)
#define WFS_BCR_SYM_MSI (25)
#define WFS_BCR_SYM_PLESSEY (26)
#define WFS_BCR_SYM_STD2OF5 (27)
#define WFS_BCR_SYM_STD2OF5_IATA (28)
#define WFS_BCR_SYM_PDF_417 (29)
#define WFS_BCR_SYM_MICROPDF_417 (30)
#define WFS_BCR_SYM_DATAMATRIX (31)
#define WFS_BCR_SYM_MAXICODE (32)
#define WFS_BCR_SYM_CODEONE (33)
#define WFS_BCR_SYM_CHANNELCODE (34)
#define WFS_BCR_SYM_TELEPEN_ORIGINAL (35)
#define WFS_BCR_SYM_TELEPEN_AIM (36)
#define WFS_BCR_SYM_RSS (37)
#define WFS_BCR_SYM_RSS_EXPANDED (38)
#define WFS_BCR_SYM_RSS_RESTRICTED (39)
#define WFS_BCR_SYM_COMPOSITE_CODE_A (40)
#define WFS_BCR_SYM_COMPOSITE_CODE_B (41)
#define WFS_BCR_SYM_COMPOSITE_CODE_C (42)
#define WFS_BCR_SYM_POSICODE_A (43)
#define WFS_BCR_SYM_POSICODE_B (44)
#define WFS_BCR_SYM_TRIOPTIC_CODE_39 (45)
#define WFS_BCR_SYM_CODABLOCK_F (46)
#define WFS_BCR_SYM_CODE_16K (47)
#define WFS_BCR_SYM_QRCODE (48)
#define WFS_BCR_SYM_AZTEC (49)
#define WFS_BCR_SYM_UKPOST (50)
#define WFS_BCR_SYM_PLANET (51)
#define WFS_BCR_SYM_POSTNET (52)
#define WFS_BCR_SYM_CANADIANPOST (53)
#define WFS_BCR_SYM_NETHERLANDSPOST (54)
#define WFS_BCR_SYM_AUSTRALIANPOST (55)
#define WFS_BCR_SYM_JAPANESEPOST (56)
#define WFS_BCR_SYM_CHINESEPOST (57)
#define WFS_BCR_SYM_KOREANPOST (58)

/* Size and max index of dwGuidLights array */

#define WFS_BCR_GUIDLIGHTS_SIZE (32)
#define WFS_BCR_GUIDLIGHTS_MAX (WFS_BCR_GUIDLIGHTS_SIZE - 1)

```

```

/* Indices of WFSBCRSTATUS.dwGuidLights [...]
   WFSBCRCAPS.dwGuidLights [...]
*/
#define WFS_BCR_GUIDANCE_BCR (0)

/* Values of WFSBCRSTATUS.dwGuidLights [...]
   WFSBCRCAPS.dwGuidLights [...],
   WFSBCRSETGUIDLIGHT.wGuidLight */

#define WFS_BCR_GUIDANCE_NOT_AVAILABLE (0x00000000)
#define WFS_BCR_GUIDANCE_OFF (0x00000001)
#define WFS_BCR_GUIDANCE_ON (0x00000002)
#define WFS_BCR_GUIDANCE_SLOW_FLASH (0x00000004)
#define WFS_BCR_GUIDANCE_MEDIUM_FLASH (0x00000008)
#define WFS_BCR_GUIDANCE_QUICK_FLASH (0x00000010)
#define WFS_BCR_GUIDANCE_CONTINUOUS (0x00000080)
#define WFS_BCR_GUIDANCE_RED (0x00000100)
#define WFS_BCR_GUIDANCE_GREEN (0x00000200)
#define WFS_BCR_GUIDANCE_YELLOW (0x00000400)
#define WFS_BCR_GUIDANCE_BLUE (0x00000800)
#define WFS_BCR_GUIDANCE_CYAN (0x00001000)
#define WFS_BCR_GUIDANCE_MAGENTA (0x00002000)
#define WFS_BCR_GUIDANCE_WHITE (0x00004000)

/* XFS BCR Errors */

#define WFS_ERR_BCR_BARCODEINVALID (- (BCR_SERVICE_OFFSET + 0))
#define WFS_ERR_BCR_INVALID_PORT (- (BCR_SERVICE_OFFSET + 1))
#define WFS_ERR_BCR_POWERSAVETOOSHORT (- (BCR_SERVICE_OFFSET + 2))

/*=====*/
/* BCR Info Command Structures */
/*=====*/
typedef struct _wfs_bcr_status
{
    WORD fwDevice;
    WORD fwBCRScanner;
    DWORD dwGuidLights[WFS_BCR_GUIDLIGHTS_SIZE];
    LPSTR lpszExtra;
    WORD wDevicePosition;
    USHORT usPowerSaveRecoveryTime;
} WFSBCRSTATUS, *LPWFSBCRSTATUS;

typedef struct _wfs_bcr_caps
{
    WORD wClass;
    BOOL bCompound;
    BOOL bCanFilterSymbologies;
    LPWORD lpwSymbologies;
    DWORD dwGuidLights[WFS_BCR_GUIDLIGHTS_SIZE];
    LPSTR lpszExtra;
    BOOL bPowerSaveControl;
} WFSBCRCAPS, *LPWFSBCRCAPS;

/*=====*/
/* BCR Execute Command Structures */
/*=====*/
typedef struct _wfs_bcr_hex_data
{
    USHORT usLength;
    LPBYTE lpbData;
} WFSBCRXDATA, * LPWFSBCRXDATA;

typedef struct _wfs_bcr_read_input
{
    LPWORD lpwSymbologies;

```

```
} WFSBCRREADINPUT, *LPWFSBCRREADINPUT;

typedef struct _wfs_bcr_read_output
{
    WORD                wSymbology;
    LPWFSBCRXDATA      lpxBarcodeData;
    LPSTR              lpszSymbologyName;
} WFSBCRREADOUTPUT, *LPWFSBCRREADOUTPUT;

typedef struct _wfs_bcr_set_guidlight
{
    WORD                wGuidLight;
    DWORD              dwCommand;
} WFSBCRSETGUIDLIGHT, *LPWFSBCRSETGUIDLIGHT;

typedef struct _wfs_bcr_power_save_control
{
    USHORT              usMaxPowerSaveRecoveryTime;
} WFSBCRPOWERSAVECONTROL, *LPWFSBCRPOWERSAVECONTROL;

/*=====*/
/* BCR Message Structures */
/*=====*/

typedef struct _wfs_bcr_device_position
{
    WORD                wPosition;
} WFSBCRDEVICEPOSITION, *LPWFSBCRDEVICEPOSITION;

typedef struct _wfs_bcr_power_save_change
{
    USHORT              usPowerSaveRecoveryTime;
} WFSBCRPOWERSAVECHANGE, *LPWFSBCRPOWERSAVECHANGE;

/* restore alignment */
#pragma pack(pop)
#ifdef __cplusplus
} /*extern "C"*/

#endif
#endif /* __INC_XFSBCR_H */
```