CEN

CWA 15748-73

WORKSHOP

July 2008

AGREEMENT

ICS 35.240.50

English version

Extensions for Financial Services (XFS) interface specification - Release 3.10 - Part 73: Card Embossing Unit Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

This CEN Workshop Agreement has been drafted and approved by a Workshop of representatives of interested parties, the constitution of which is indicated in the foreword of this Workshop Agreement.

The formal process followed by the Workshop in the development of this Workshop Agreement has been endorsed by the National Members of CEN but neither the National Members of CEN nor the CEN Management Centre can be held accountable for the technical content of this CEN Workshop Agreement or possible conflicts with standards or legislation.

This CEN Workshop Agreement can in no way be held as being an official standard developed by CEN and its Members.

This CEN Workshop Agreement is publicly available as a reference document from the CEN Members National Standard Bodies.

CEN members are the national standards bodies of Austria, Belgium, Bulgaria, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland and United Kingdom.



EUROPEAN COMMITTEE FOR STANDARDIZATION COMITÉ EUROPÉEN DE NORMALISATION EUROPÄISCHES KOMITEE FÜR NORMUNG

Management Centre: rue de Stassart, 36 B-1050 Brussels

Table of Contents

Fore	eword	3
1.	Migration Information	5
2.	Card Embossing Units	6
3.	References	7
4.	Info Commands	8
4.	1 WFS_INF_CEU_STATUS	8
4.2	2 WFS_INF_CEU_CAPABILITIES	11
4.3	3 WFS_INF_CEU_FORM_LIST	13
4.4	4 WFS_INF_CEU_MEDIA_LIST	14
4.	5 WFS_INF_CEU_QUERY_FORM	15
4.6	6 WFS_INF_CEU_QUERY_MEDIA	16
4.7	7 WFS_INF_CEU_QUERY_FIELD	18
5.	Execute Commands	19
5.	1 WFS_CMD_CEU_EMBOSS_CARD	19
5.2	2 WFS_CMD_CEU_RESET	22
5.3	3 WFS_CMD_CEU_POWER_SAVE_CONTROL	23
6.	Events	24
6. 6.		
•-	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	24
6.	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD2 WFS_SVRE_CEU_OUTPUTBINTHRESHOLD	24 25
6.2 6.2	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD2 2 WFS_SVRE_CEU_OUTPUTBINTHRESHOLD	24 25 26
6.2 6.3	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	24 25 26
6.2 6.3 6.4	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	24 25 26 27
6.2 6.3 6.4 6.4	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	24 25 26 27 28
6.4 6.4 6.4 6.4	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	24 25 26 27 28 29
6.4 6.4 6.4 6.4 6.6	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	24 25 27 28 29 30
6.2 6.2 6.4 6.4 6.6 6.7 6.6	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	24 25 26 27 29 30 31
6.2 6.2 6.4 6.4 6.6 6.7 6.6	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	24 25 26 27 28 30 31 32
6.4 6.3 6.4 6.4 6.5 6.5 6.5	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	2425272830313233
6.2 6.3 6.4 6.8 6.6 6.8 6.8 7.	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	242526283031323334
6.4 6.4 6.4 6.4 6.5 6.7 7.	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	2425262728303132333434
6.4 6.3 6.4 6.8 6.6 6.7 7.	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	242527293132333434
6.4 6.3 6.4 6.4 6.5 6.5 7.	1 WFS_SVRE_CEU_INPUTBINTHRESHOLD	24252627283031323334343435

Foreword

This CWA is revision 3.10 of the XFS interface specification.

The CEN/ISSS XFS Workshop gathers suppliers as well as banks and other financial service companies. A list of companies participating in this Workshop and in support of this CWA is available from the CEN/ISSS Secretariat.

This CWA was formally approved by the XFS Workshop meeting on 2007-11-29. The specification is continuously reviewed and commented in the CEN/ISSS Workshop on XFS. It is therefore expected that an update of the specification will be published in due time as a CWA, superseding this revision 3.10.

The CWA is published as a multi-part document, consisting of:

- Part 1: Application Programming Interface (API) Service Provider Interface (SPI) Programmer's Reference
- Part 2: Service Classes Definition Programmer's Reference
- Part 3: Printer and Scanning Device Class Interface Programmer's Reference
- Part 4: Identification Card Device Class Interface Programmer's Reference
- Part 5: Cash Dispenser Device Class Interface Programmer's Reference
- Part 6: PIN Keypad Device Class Interface Programmer's Reference
- Part 7: Check Reader/Scanner Device Class Interface Programmer's Reference
- Part 8: Depository Device Class Interface Programmer's Reference
- Part 9: Text Terminal Unit Device Class Interface Programmer's Reference
- Part 10: Sensors and Indicators Unit Device Class Interface Programmer's Reference
- Part 11: Vendor Dependent Mode Device Class Interface Programmer's Reference
- Part 12: Camera Device Class Interface Programmer's Reference
- Part 13: Alarm Device Class Interface Programmer's Reference
- Part 14: Card Embossing Unit Device Class Interface Programmer's Reference
- Part 15: Cash-In Module Device Class Interface Programmer's Reference
- Part 16: Card Dispenser Device Class Interface Programmer's Reference
- Part 17: Barcode Reader Device Class Interface Programmer's Reference
- Part 18: Item Processing Module Device Class Interface- Programmer's Reference
- Parts 19 28: Reserved for future use.
- Parts 29 through 47 constitute an optional addendum to this CWA. They define the integration between the SNMP standard and the set of status and statistical information exported by the Service Providers.
- Part 29: XFS MIB Architecture and SNMP Extensions Programmer's Reference
- Part 30: XFS MIB Device Specific Definitions Printer Device Class
- Part 31: XFS MIB Device Specific Definitions Identification Card Device Class
- Part 32: XFS MIB Device Specific Definitions Cash Dispenser Device Class
- Part 33: XFS MIB Device Specific Definitions PIN Keypad Device Class
- Part 34: XFS MIB Device Specific Definitions Check Reader/Scanner Device Class
- Part 35: XFS MIB Device Specific Definitions Depository Device Class
- Part 36: XFS MIB Device Specific Definitions Text Terminal Unit Device Class
- Part 37: XFS MIB Device Specific Definitions Sensors and Indicators Unit Device Class
- Part 38: XFS MIB Device Specific Definitions Camera Device Class
- Part 39: XFS MIB Device Specific Definitions Alarm Device Class
- Part 40: XFS MIB Device Specific Definitions Card Embossing Unit Class

CWA 15748-73:2008

Part 41: XFS MIB Device Specific Definitions - Cash-In Module Device Class

Part 42: Reserved for future use.

Part 43: XFS MIB Device Specific Definitions - Vendor Dependent Mode Device Class

Part 44: XFS MIB Application Management

Part 45: XFS MIB Device Specific Definitions - Card Dispenser Device Class

Part 46: XFS MIB Device Specific Definitions - Barcode Reader Device Class

Part 47: XFS MIB Device Specific Definitions - Item Processing Module Device Class

Parts 48 - 60 are reserved for future use.

Part 61: Application Programming Interface (API) - Service Provider Interface (SPI) - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 62: Printer Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 63: Identification Card Device Class Interface - Migration from Version 3.02 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 64: Cash Dispenser Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 65: PIN Keypad Device Class Interface - Migration from Version 3.03 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 66: Check Reader/Scanner Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 67: Depository Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 68: Text Terminal Unit Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 69: Sensors and Indicators Unit Device Class Interface - Migration from Version 3.01 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 70: Vendor Dependent Mode Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 71: Camera Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 72: Alarm Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 73: Card Embossing Unit Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 74: Cash-In Module Device Class Interface - Migration from Version 3.02 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

In addition to these Programmer's Reference specifications, the reader of this CWA is also referred to a complementary document, called Release Notes. The Release Notes contain clarifications and explanations on the CWA specifications, which are not requiring functional changes. The current version of the Release Notes is available online from http://www.cen.eu/isss/Workshop/XFS.

The information in this document represents the Workshop's current views on the issues discussed as of the date of publication. It is furnished for informational purposes only and is subject to change without notice. CEN/ISSS makes no warranty, express or implied, with respect to this document.

This CEN Workshop Agreement is publicly available as a reference document from the National Members of CEN: AENOR, AFNOR, ASRO, BDS, BSI, CSNI, CYS, DIN, DS, ELOT, EVS, IBN, IPQ, IST, LVS, LST, MSA, MSZT, NEN, NSAI, ON, PKN, SEE, SIS, SIST, SFS, SN, SNV, SUTN and UNI.

Comments or suggestions from the users of the CEN Workshop Agreement are welcome and should be addressed to the CEN Management Centre.

1. Migration Information

XFS 3.10 has been designed to minimize backwards compatibility issues. This document highlights the changes made to the CEU device class between version 3.0 and 3.10, by highlighting the additions and deletions to the text.

2. Card Embossing Units

This section describes the functions provided by a generic card embossing unit (CEU). These descriptions include definitions of the service-specific commands that can be issued, using the WFSAsyncExecute, WFSExecute, WFSGetInfo and WFSAsyncGetInfo functions.

Embossing card units are generally viewed by XFS as compound devices with the following capabilities and features:

- Embossing of magnetic stripe card/ smart card.
- Reading/encoding magnetic stripe tracks 1, 2, and 3.
- · Reading/writing smart card.
- LCD display/ keypad input.

The XFS services supporting the various embossing card unit components are outlined as follows:

- Embossing of magnetic stripe card/smart card Card Embossing Unit (CEU) service.
- Reading/encoding magnetic stripe tracks 1, 2, and 3 ID Card (IDC) service, however when combined
 encoding/ embossing is performed the CEU service class is used.
- Reading/writing smart cards ID Card (IDC) service, however when combined writing smart card/ embossing is performed the CEU service class is used.
- LCD display/ keypad input Text Terminal Unit (TTU) service.

3. References

 $1.\ XFS\ Application\ Programming\ Interface\ (API)/Service\ Provider\ Interface\ (\ SPI),\ Programmer's\ Reference\ Revision\ 3.10$

4. Info Commands

4.1 WFS_INF_CEU_STATUS

This command reports the full range of information available, including the information that is Description

provided either by the service provider or directly from the device.

Input Param

 ${\bf Output\ Param}\quad LPWFSCEUSTATUS\ lpStatus;$

```
typedef struct _wfs_ceu_status
     WORD
                           fwDevice;
     WORD
                           fwMedia:
     WORD
                           fwRetainBin;
     WORD
                           fwOutputBin;
     WORD
                           fwInputBin;
     USHORT
                           usTotalCards;
     USHORT
                           usOutputCards;
     USHORT
                           usRetainCards;
     LPSTR
                           lpszExtra;
                           wDevicePosition;
     WORD
                           usPowerSaveRecoveryTime;
     USHORT
     } WFSCEUSTATUS, *LPWFSCEUSTATUS;
```

Specifies the state of the ID card device as one of the following flags:

Value	Meaning
WFS_CEU_DEVONLINE	The device is present, powered on and online
	(i.e. operational, not busy processing a
	request and not in an error state).
WFS_CEU_DEVOFFLINE	The device is offline (e.g. the operator has
	taken the device offline by turning a switch or pulling out the device).
WFS CEU DEVPOWEROFF	The device is powered off or physically not
WIS_CEO_DEVIOWEROFI	connected.
WFS_CEU_DEVNODEVICE	There is no device intended to be there; e.g.
	this type of self service machine does not
	contain such a device or it is internally not
WEG CELL DEVILWEDDOD	configured.
WFS_CEU_DEVHWERROR	The device is present but inoperable due to a hardware fault that prevents it from being
	used.
WFS_CEU_DEVUSERERROR	The device is present but a person is
	preventing proper device operation. The
	application should suspend the device
	operation or remove the device from service
	until the service provider generates a device
	state change event indicating the condition of the device has changed e.g. the error is
	removed (WFS_CEU_DEVONLINE) or a
	permanent error condition has occurred
	(WFS CEU DEVHWERROR).
WFS_CEU_DEVBUSY	The device is busy and unable to process an
	execute command at this time.
WFS_CEU_DEVFRAUDATTEMPT	The device is present but has detected a
	<u>fraud attempt.</u>

fwMedia

Specifies the state of the ID card unit as one of the following flags:

Value	Meaning
WFS_CEU_MEDIAPRESENT	Media is present in the device, not in the
WFS_CEU_MEDIANOTPRESENT	entering position and not jammed. Media is not present in the device and not at the entering position.
WFS_CEU_MEDIAJAMMED	Media is jammed in the device; operator intervention is required.
WFS_CEU_MEDIANOTSUPP	Capability to report media position is not supported by the device.
WFS_CEU_MEDIAUNKNOWN	The media state cannot be determined with the device in its current state (e.g. the value of fwDevice is WFS_CEU_DEVNODEVICE, WFS_CEU_DEVPOWEROFF, WFS_CEU_DEVOFFLINE, or WFS_CEU_DEVHWERROR).
WFS_CEU_MEDIAENTERING	Media is at the entry/exit slot.
WFS_CEU_MEDIATOPPER	Topper failure.
WFS_CEU_MEDIAINHOPPER	Card is positioned in input bin.
WFS_CEU_MEDIAOUTHOPPER	Card is positioned in output bin.
WFS_CEU_MEDIAMSRE	Encoding failure.
WFS_CEU_MEDIARETAINED	Card is positioned in retain bin.

fwRetainBin

Specifies the state of the CEU retain bin as one of the following flags:

Value	Meaning
WFS_CEU_RETAINBINOK	The retain bin is not full.
WFS_CEU_RETAINBINFULL	The retain bin is full.
WFS_CEU_RETAINBINHIGH	The retain bin is nearly full.
WFS_CEU_RETAINBINNOTSUPP	The retain bin state can not be reported.

fwOutputBin

Specifies the state of the Embossing unit output bin as one of the flags:

Value	Meaning
WFS_CEU_OUTPUTBINOK	The output bin is not full.
WFS_CEU_OUTPUTBINFULL	The output bin is full.
WFS_CEU_OUTPUTBINHIGH	The output bin is nearly full.
WFS_CEU_OUTPUTNOTSUPP	The output bin state can not be reported.

fwInputBin

Specifies the state of the Embossing unit input bin as one of the flags:

Value	Meaning
WFS_CEU_INPUTBINOK	The input bin is not full.
WFS_CEU_INPUTBINEMPTY	The input bin is empty.
WFS_CEU_INPUTBINLOW	The input bin is nearly empty.
WFS CEU INPUTNOTSUPP	The input bin state can not be reported.

us Total Cards

The total number of cards, including those in input bin, output bin, and retain bin.

us Output Cards

The total number of output bin cards.

usRetainCards

The total number of retain bin cards.

lpszExtra

Pointer to a list of vendor-specific, or any other extended, information. The information is returned as a series of "key=value" strings so that it is easily extensible by Service Providers. Each string is null-terminated, with the final string terminating with two null characters. An empty list may be indicated by either a NULL pointer or a pointer to two consecutive null characters.

<u>wDevicePosition</u>

Specifies the device position. The device position value is independent of the *fwDevice* value, e.g. when the device position is reported as WFS_CEU_DEVICENOTINPOSITION, *fwDevice* can have any of the values defined above (including WFS_CEU_DEVONLINE or WFS_CEU_DEVOFFLINE). If the device is not in its normal operating position (i.e. WFS_CEU_DEVICENPOSITION) then media may not be presented through the normal customer interface. This value is one of the following values:

Value	Meaning
WFS_CEU_DEVICEINPOSITION	The device is in its normal operating
	position, or is fixed in place and cannot be
	moved.
WFS_CEU_DEVICENOTINPOSITION	The device has been removed from its
	normal operating position.
WFS_CEU_DEVICEPOSUNKNOWN	Due to a hardware error or other condition,
	the position of the device cannot be
	<u>determined.</u>
WFS_CEU_DEVICEPOSNOTSUPP	The physical device does not have the
	capability of detecting the position.

$\underline{usPowerSaveRecoveryTime}$

Specifies the actual number of seconds required by the device to resume its normal operational state from the current power saving mode. This value is zero if either the power saving mode has not been activated or no power save control is supported.

Error Codes

Only the generic error codes defined in [Ref. 1] can be generated by this command.

Comments

Applications which require or expect specific information to be present in the *lpszExtra* parameter may not be device or vendor-independent.

In the case where communications with the device has been lost, the *fwDevice* field will report WFS CEU DEVPOWEROFF when the device has been removed or WFS CEU DEVHWERROR if the communications are unexpectedly lost. All other fields should contain a value based on the following rules and priority:

- 1. Report the value as unknown.
- 2. Report the value as a general h/w error.
- 3. Report the value as the last known value.

4.2 WFS_INF_CEU_CAPABILITIES

Description This command is used to retrieve the capabilities of the Card Embossing Unit.

Input Param None

Output Param LPWFSCEUCAPS lpCaps;

```
typedef struct _wfs_ceu_caps
     WORD
                          wClass;
                          bCompound;
     BOOL
     BOOL
                          bCompareMagneticStripe;
     BOOL
                          bMagneticStripeRead;
     BOOL
                          bMagneticStripeWrite;
     BOOL
                          bChipIO;
     WORD
                          wChipProtocol;
     LPSTR
                          lpszExtra;
     BOOL
                          bPowerSaveControl;
     } WFSCEUCAPS, *LPWFSCEUCAPS;
```

wClass

Specifies the logical service class as WFS_SERVICE_CLASS_CEU.

bCompound

Specifies whether the logical device is part of a compound physical device.

bCompareMagneticStripe

Indicates whether CEU has capability of comparing magnetic stripe contents (TRUE) as a prerequisite for an encoding or embossing operation.

bMagneticStripeRead

Indicates whether CEU has magnetic stripe reading capability and is either TRUE or FALSE.

bMagneticStripeWrite

Indicates whether CEU has magnetic stripe writing capability and is either TRUE or FALSE.

bChipIC

Indicates whether CEU has smart card updating capability and is either TRUE or FALSE.

wChipProtocol

Specifies the chip card protocols that are supported by the service provider as a combination of the following flags:

Value	Meaning
WFS_CEU_NOTSUPP	The CEU card unit can not handle chip cards.
WFS_CEU_CHIPT0	The CEU card unit can handle the T=0 protocol.
WFS_CEU_CHIPT1	The CEU card unit can handle the T=1 protocol.
WFS_CEU_CHIPT2	The CEU card unit can handle the T=2 protocol.
WFS_CEU_CHIPT3	The CEU card unit can handle the T=3 protocol.
WFS_CEU_CHIPT4	The CEU card unit can handle the T=4 protocol.
WFS_CEU_CHIPT5	The CEU card unit can handle the T=5 protocol.
WFS_CEU_CHIPT6	The CEU card unit can handle the T=6 protocol.
WFS_CEU_CHIPT7	The CEU card unit can handle the T=7 protocol.
WFS_CEU_CHIPT8	The CEU card unit can handle the T=8
WFS_CEU_CHIPT9	protocol. The CEU card unit can handle the T=9 protocol.

	WFS CEU	CHIPT10	The CEU card unit can handle the T=10
--	---------	---------	---------------------------------------

protocol.

WFS_CEU_CHIPT11 The CEU card unit can handle the T=11

protocol.

WFS_CEU_CHIPT12 The CEU card unit can handle the T=12

protocol.

WFS_CEU_CHIPT13 The CEU card unit can handle the T=13

protocol.

WFS CEU CHIPT14 The CEU card unit can handle the T=14

protocol.

WFS_CEU_CHIPT15 The CEU card unit can handle the T=15

protocol.

Pointer to a list of vendor-specific, or any other extended, information. The information is returned as a series of "key=value" strings so that it is easily extensible by Service Providers. Each string is null-terminated, with the final string terminating with two null characters. An empty list may be indicated by either a NULL pointer or a pointer to two consecutive null characters.

<u>bPowerSaveControl</u>

Specifies whether power saving control is available. This can either be TRUE if available or

FALSE if not available.

Error Codes Only the generic error codes defined in [Ref. 1] can be generated by this command.

Applications which require or expect specific information to be present in the *lpszExtra* parameter **Comments**

may not be device or vendor-independent.

4.3 WFS_INF_CEU_FORM_LIST

Description This command is used to retrieve the list of forms available on the device.

Input Param None.

Output Param LPSTR lpszFormList;

lpszFormList

Pointer to a list of null-terminated form names, with the final name terminating with two null

characters.

Error Codes Only the generic error codes defined in [Ref. 1] can be generated by this command.

4.4 WFS_INF_CEU_MEDIA_LIST

Description This command is used to retrieve the list of media definitions available on the device.

Input Param None.

Output Param LPSTR lpszMediaList;

lpsz Media List

Pointer to a list of null-terminated media names, with the final name terminating with two null

characters.

Error Codes Only the generic error codes defined in [Ref. 1] can be generated by this command.

4.5 WFS_INF_CEU_QUERY_FORM

Description This command is used to retrieve details of the definition of a specified CEU form. The

WFS_INF_CEU_QUERY_FORM does not currently contain any form attributes, however it is

retained for future expansion.

Input Param LPSTR lpszFormName;

lpszFormName

Points to the null-terminated form name on which to retrieve details.

Output Param LPWFSCEUFORM lpForm;

lpszFormName

Specifies the null-terminated name of the form.

InszFields

Pointer to a list of null-terminated field names, with the final name terminating with two null

characters.

Error Codes In addition to the generic error codes defined in [Ref. 1], the following error codes can be

generated by this command:

Value	Meaning
WFS_ERR_CEU_FORMNOTFOUND	The specified form cannot be found.
WFS ERR CEU FORMINVALID	The specified form is invalid.

WFS_INF_CEU_QUERY_MEDIA

Description This command is used to retrieve details of the definition of a specified media.

Input Param LPSTR lpszMediaName;

lpszMediaName

Pointer to the null-terminated media name about which to retrieve details.

Output Param LPWFSCEUFRMMEDIA lpFormMedia;

```
typedef struct _wfs_ceu_frm_media
                           fwMediaType;
     WORD
     WORD
                           wBase:
     WORD
                           wUnitX:
     WORD
                           wUnitY;
                           wSizeWidth;
     WORD
     WORD
                           wSizeHeight;
     WORD
                           wEmbossAreaX;
     WORD
                           wEmbossAreaY;
     WORD
                            wEmbossAreaWidth;
     WORD
                            wEmbossAreaHeight;
                           wRestrictedAreaX;
     WORD
     WORD
                           wRestrictedAreaY;
     WORD
                           wRestrictedAreaWidth;
                           wRestrictedAreaHeight;
     WORD
     } WFSCEUFRMMEDIA, *LPWFSCEUFRMMEDIA;
```

fwMediaType

Specifies the type of media as one of the following flags:

Value	Meaning
WFS_CEU_MEDIAECARD	Embossible card media.

wBase.

Specifies the base unit of measurement of the form and can be one of the following:

Value	Meaning
WFS_CEU_INCH	The base unit is inches.
WFS_CEU_MM	The base unit is millimeters.
WFS_CEU_ROWCOLUMN	The base unit is rows and columns.

wUnitX

Specifies the horizontal resolution of the base units as a fraction of the wBase value. For example, a value of 16 applied to the base unit WFS_CEU_INCH means that the base horizontal resolution

wUnitY

Specifies the vertical resolution of the base units as a fraction of the wBase value. For example, a value of 10 applied to the base unit WFS_CEU_MM means that the base vertical resolution is 0.1

wSizeWidth

Specifies the width of the media in terms of the base horizontal resolution.

wSizeHeight

Specifies the height of the media in terms of the base vertical resolution.

wEmbossAreaX

Specifies the horizontal offset of the Card Emboss area relative to the top left corner of the media in terms of the base horizontal resolution.

wEmbossAreaY

Specifies the vertical offset of the Card Emboss area relative to the top left corner of the media in terms of the base vertical resolution.

wEmbossAreaWidth

Specifies the Card Emboss area width of the media in terms of the base horizontal resolution.

w Emboss Area Height

Specifies the Card Emboss area height of the media in terms of the base vertical resolution.

wRestrictedAreaX

Specifies the horizontal offset of the restricted area relative to the top left corner of the media in terms of the base horizontal resolution.

wRestrictedAreaY

Specifies the vertical offset of the restricted area relative to the top left corner of the media in terms of the base vertical resolution.

wRestrictedAreaWidth

Specifies the restricted area width of the media in terms of the base horizontal resolution.

w Restricted Area Height

Specifies the restricted area height of the media in terms of the base vertical resolution.

Error Codes

In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CEU_MEDIANOTFOUND	The specified media definition cannot be
	found.
WFS_ERR_CEU_MEDIAINVALID	The specified media definition is invalid.

4.7 WFS_INF_CEU_QUERY_FIELD

Description

This function is used to retrieve details on the definition of a single or all fields on a specified

Input Param

LPWFSCEUQUERYFIELD lpQueryField;

```
typedef struct _wfs_ceu_query_field
     LPSTR
                           lpszFormName;
     LPSTR
                          lpszFieldName;
     } WFSCEUQUERYFIELD, *LPWFSCEUQUERYFIELD;
```

lpszFormName

Points to the null-terminated form name.

lpszFieldName

Points to the null-terminated name of the field about which to retrieve details. If this value is NULL, then retrieve details for all fields on the form.

Output Param LPWFSFRMFIELD *lppFields;

lppFields

Pointer to a NULL-terminated array of pointers to WFSCEUFRMFIELD structures:

```
typedef struct _wfs_ceu_frm_field
     LPSTR
                           lpszFieldName;
     WORD
                           fwType;
     WORD
                           fwClass;
     LPSTR
                           lpszInitialValue;
     LPSTR
                           lpszFormat;
     } WFSCEUFRMFIELD, *LPWFSCEUFRMFIELD;
```

lpszFieldName

Pointer to the null-terminated field name.

Specifies the type of field and can be one of the following:

Value	Meaning
WFS_CEU_FIELDTEXT	A text field.
WFS_CEU_FIELDOCR	An Optical Character Recognition (OCR)
	field.

Specifies the class of the field and can be one of the following:

Value	Meaning
WFS_CEU_CLASSSTATIC	The field data cannot be set by the
	application.
WFS_CEU_CLASSOPTIONAL	The field data can be set by the application.
WFS CEU CLASSREQUIRED	The field data must be set by the application.

lpszInitialValue

The initial value of the field when the field is written as output.

Format string as defined in the form for this field.

Error Codes

In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CEU_FORMNOTFOUND	The specified form cannot be found.
WFS_ERR_CEU_FIELDNOTFOUND	The specified field cannot be found.

Comments

None.

5. Execute Commands

5.1 WFS_CMD_CEU_EMBOSS_CARD

Description

This command is used to emboss an identification card by merging the supplied variable field data with the defined form and field data specified in the form. Optionally the magnetic stripe can be read and verified before being encoded, or a smart card can be updated.

The ATR of the chip must be obtained before issuing this command by issuing the ID Card class WFS CMD IDC READ RAW DATA command.

Input Param

LPWFSCEUEMBOSSCARD lpEmbossCard;

```
typedef struct _wfs_ceu_emboss_card
     LPSTR
                           lpszFormName:
     LPSTR
                           lpszMediaName;
     LPSTR
                           lpszFields;
                           {\tt lpszCompareFormIOFormName;}
     LPSTR
     LPSTR
                            lpszCompareFormIOTrackData;
     LPSTR
                           lpszFormIOFormName;
     LPSTR
                            lpszFormIOTrackData;
     WORD
                            wChipProtocol;
     ULONG
                           ulChipDataLength;
                           lpbChipData;
     } WFSCEUEMBOSSCARD, *LPWFSCEUEMBOSSCARD;
```

lpszFormName

Pointer to the null-terminated form name.

lpszMediaName

Pointer to the null-terminated media name.

lpszFields

Pointer to a series of "<FieldName>=<FieldValue>" strings, where each string is null-terminated with the final string terminating with two null characters. If the field is an index field, then the syntax of the string is instead "<FieldName>[<index>]=<FieldValue>", where <index> specifies the zero-based element of the index field.

lpszCompareFormIOFormName

lpszCompareFormIOFormName and *lpszCompareFormIOTrackData* are used collectively when the contents of the magnetic stripe are being read and verified before the card is embossed or the magnetic stripe is encoded. Points to the name of the magnetic stripe form to be used, as defined in the IDC service class.

lpsz Compare Form IOT rack Data

Points to the data to be used in the form.

lpszFormIOFormName

lpszFormIOFormName and *lpszFormIOTrackData* are used collectively when the magnetic stripe is being encoded (after a successful magnetic stripe compare operation) and during the emboss operation. Points to the name of the form to be used, as defined in the IDC service class.

lpszFormIOTrackData

Points to the data to be used in the form.

wChipProtocol

wChipProtocol, *ulChipDataLength*, and *lpbChipData* are used collectively when the smart card is being updated during the emboss operation. If this parameter equals zero then the smart card should not be updated during the emboss operation. Possible other values are:

Value	Meaning
WFS_CEU_CHIPT0	Use the T=0 protocol to communicate with
	the chip.
WFS_CEU_CHIPT1	Use the T=1 protocol to communicate with
	the chip.

WFS_CEU_CHIPT2	Use the T=2 protocol to communicate with the chip.
WFS_CEU_CHIPT3	Use the T=3 protocol to communicate with the chip.
WFS_CEU_CHIPT4	Use the T=4 protocol to communicate with the chip.
WFS_CEU_CHIPT5	Use the T=5 protocol to communicate with the chip.
WFS_CEU_CHIPT6	Use the T=6 protocol to communicate with the chip.
WFS_CEU_CHIPT7	Use the T=7 protocol to communicate with the chip.
WFS_CEU_CHIPT8	Use the T=8 protocol to communicate with the chip.
WFS_CEU_CHIPT9	Use the T=9 protocol to communicate with the chip.
WFS_CEU_CHIPT10	Use the T=10 protocol to communicate with the chip.
WFS_CEU_CHIPT11	Use the T=11 protocol to communicate with the chip.
WFS_CEU_CHIPT12	Use the T=12 protocol to communicate with the chip.
WFS_CEU_CHIPT13	Use the T=13 protocol to communicate with the chip.
WFS_CEU_CHIPT14	Use the T=14 protocol to communicate with the chip.
WFS_CEU_CHIPT15	Use the T=15 protocol to communicate with the chip.

ulChipDataLength
Specifies the length of the following field lpbChipData.

None.

lpbChipData
Points to the data sent to the chip.

Output Param

Error Codes

In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CEU_FORMNOTFOUND	The specified form definition cannot be found.
WFS_ERR_CEU_FORMINVALID	The specified form definition is invalid.
WFS_ERR_CEU_MEDIANOTFOUND	The specified media definition cannot be found.
WFS_ERR_CEU_MEDIAINVALID	The specified media definition is invalid.
WFS_ERR_CEU_NOMEDIA	There is no card inside the device.
WFS_ERR_CEU_MEDIAOVERFLOW	The form overflowed the media.
WFS_ERR_CEU_IDC_FORMNOTFOUND	The specified IDC form definition cannot be found.
WFS_ERR_CEU_IDC_FORMINVALID	The specified IDC form definition is invalid.
WFS_ERR_CEU_INVALIDDATA	An error occurred while communicating with the chip.
WFS_ERR_CEU_PROTOCOLNOTSUPP	The protocol used was not supported by the service provider.
WFS_ERR_CEU_ATRNOTOBTAINED	The ATR was not obtained by issuing the IDC class
	WFS_CMD_CEU_READ_RAW_DATA command.
WFS_ERR_CEU_FIELDSPECFAILURE	The syntax of the <i>lpszFields</i> member is invalid.

Page 21 CWA 15748-73:2008

WFS_ERR_CEU_FIELDERROR An error occurred while processing a field,

causing termination of the emboss request.

An execute event WFS_EXEE_CEU_FIELDERROR is posted

with the details.

WFS_ERR_CEU_EMBOSSFAILURE A failure has occurred during Emboss

processing. A service event

WFS_EXEE_CEU_EMBOSS_FAILURE is

posted with details.

Events In addition to the generic events defined in [Ref. 1], the following events can be generated by this command:

Meaning WFS SRVE CEU INPUTBINTHRESHOLD Input bin is nearly empty. WFS_SRVE_CEU_OUTPUTBINTHRESHOLD Output bin is nearly full. WFS_SRVE_CEU_RETAINBINTHRESHOLD Retain bin is nearly full. WFS_EXEE_CEU_EMBOSS_FAILURE A card embossing failure A card embossing failure has occurred. WFS EXEE CEU FIELDERROR A fatal error occurred while processing a field. WFS_EXEE_CEU_FIELDWARNING A non-fatal error occurred while processing a field. WFS_EXEE_CEU_MEDIAREMOVED This event is generated when a card is removed before completion of a write operation.

WFS_CMD_CEU_RESET

Description

Sends a service reset to the Service Provider. Any media found in the device will be captured into the specified bin (depending on hardware). The WFS_SRVE_CEU_MEDIADETECTED event will indicate that media was found in the device on reset and will indicate the position and status of the media following completion of the command.

Input Param

LPWORD lpwCeuMediaControl;

lpwCeuMediaControl

Specifies the action that should be done if media is detected during the reset operation, as one of the following values:

Value	Meaning
WFS_CEU_CTRLTOINPUTBIN	Any media detected should be moved to the input bin.
WFS_CEU_CTRLTOOUTPUTBIN	Any media detected should be moved to the output bin.
WFS_CEU_CTRLTORETAINBIN	Any media detected should be moved to the retain bin.

Output Param None.

Error Codes

Only the generic error codes defined in [Ref. 1] can be generated by this command.

Events

In addition to the generic events defined in [Ref. 1], the following events can be generated by this command:

Value	Meaning
WFS_SRVE_CEU_OUTPUTBINTHRESHOLI	Output bin is nearly full.
WFS_SRVE_CEU_RETAINBINTHRESHOLD	Retain bin is nearly full.
WFS_SRVE_CEU_MEDIADETECTED	Media was detected in the device during a

reset.

Comments

This command is used by an application control program to cause a device to reset itself to a

If lpwCeuMediaControl is a NULL pointer the service provider will determine where to move any media found.

5.3 WFS CMD CEU POWER SAVE CONTROL

Description This command activates or deactivates the power-saving mode.

If the Service Provider receives another execute command while in power saving mode, the Service Provider automatically exits the power saving mode, and executes the requested command. If the Service Provider receives an information command while in power saving mode, the Service Provider will not exit the power saving mode.

Input Param LPWFSCEUPOWERSAVECONTROL lpPowerSaveControl;

$\underline{usMaxPowerSaveRecoveryTime}$

Specifies the maximum number of seconds in which the device must be able to return to its normal operating state when exiting power save mode. The device will be set to the highest possible power save mode within this constraint. If *usMaxPowerSaveRecoveryTime* is set to zero then the device will exit the power saving mode.

Output Param None.

Error Codes In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

 Value
 Meaning

 WFS_ERR_CEU_POWERSAVETOOSHORT
 The power saving mode has not been activated because the device is not able to resume from the power saving mode within the specified usMaxPowerSaveRecoveryTime value.

 WFS_ERR_CEU_POWERSAVEMEDIAPRESENT
 The power saving mode has not been.

The power saving mode has not been activated because media is present inside the device.

Events In addition to the generic events defined in [Ref. 1], the following events can be generated by this command:

WFS SRVE CEU POWER SAVE CHANGE The power save recovery time has changed.

6. Events

6.1 WFS_SVRE_CEU_INPUTBINTHRESHOLD

Description This service event specifies that the input bin holding the input cards is nearly empty, requiring

operator intervention soon.

Event Param LPWORD lpwInputBin;

lpwInputBin

Specifies the state of the CEU unit input bin as one of the following flags:

Value Meaning

WFS_CEU_INPUTBINOK The input bin of the CEU unit is full.

WFS_CEU_INPUTBINLOW The input bin of the CEU unit is low.

WFS_CEU_INPUTBINEMPTY The input bin of the CEU unit is empty.

6.2 WFS_SVRE_CEU_OUTPUTBINTHRESHOLD

Description This service event specifies that the output bin holding embossed cards is nearly full, requiring

operator intervention soon.

Event Param LPWORD lpwOutputBin;

lpwOutputBin

Specifies the state of the CEU unit output bin as one of the following flags:

Value	Meaning
WFS_CEU_OUTPUTBINOK	The output bin of the CEU unit was emptied.
WFS_CEU_OUTPUTBINFULL	The output bin of the CEU unit is full.
WFS_CEU_OUTPUTBINHIGH	The output bin of the CEU unit is nearly full.

6.3 WFS_SVRE_CEU_RETAINBINTHRESHOLD

This service event specifies that the retain bin is nearly full, requiring operator intervention soon. Description

LPWORD lpwRetainBin; **Event Param**

*lpwRetainBin*Specifies the state of the ID card unit retain bin as one of the following flags:

Value	Meaning
WFS_CEU_RETAINBINOK	The retain bin of the CEU unit was emptied.
WFS_CEU_RETAINBINFULL	The retain bin of the CEU unit is full.
WFS_CEU_RETAINBINHIGH	The retain bin of the CEU unit is nearly full.

6.4 WFS_EXEE_CEU_FIELDERROR

Description This event specifies that a fatal error has occurred while processing a field.

Event Param LPWFSCEUFIELDFAIL lpFieldFail;

lpszFormName

Points to the null-terminated form name.

lpszFieldName

Points to the null-terminated field name.

wFailure

Specifies the type of failure and can be one of the following:

Value	Meaning
WFS_CEU_FIELDREQUIRED	The specified field <i>must</i> be supplied by the application.
WFS_CEU_FIELDSTATICOVWR	The specified field is static and thus <i>cannot</i> be overwritten by the application.
WFS_CEU_FIELDOVERFLOW	The value supplied for the specified fields is too long.
WFS_CEU_FIELDNOTFOUND	The specified field does not exist.
WFS CEU_FIELDNOTREAD	The specified field is not an input field.
WFS_CEU_FIELDNOTWRITE	An attempt was made to write to an input field.
WFS_CEU_FIELDHWERROR	The specified field uses special hardware (e.g. OCR) and an error occurred.
WFS_CEU_FIELDTYPENOTSUPPORTED	The form field type is not supported with device.

6.5 WFS_EXEE_CEU_FIELDWARNING

Description This event is used to specify that a non-fatal error has occurred while processing a field.

Event Param LPWFSPTRFIELDFAIL lpFieldFail;

As defined in the section describing WFS_EXEE_CEU_FIELDERROR.

6.6 WFS_EXEE_CEU_MEDIAREMOVED

Description This event is generated when a card is removed before completion of a write operation.

Event Param None. **Comments** None.

6.7 WFS_SRVE_CEU_MEDIADETECTED

This event is generated when a media is detected in the device during a reset operation. Description

Event Param <u>LPWORD lp</u>wPosition; Deleted: WORD

<u>IpwPosition</u>
Specifies the media position after the reset operation, as one of the following values:

Value	Meaning
WFS_CEU_MEDIARETAINED	The media was successfully retained during
	the reset operation.
WFS_CEU_MEDIAREMOVED	The media was removed during the reset
	operation.
WFS_CEU_MEDIAJAMMED	The media is jammed in the device.
WFS_CEU_MEDIAUNKNOWN	The media is in an unknown position.

6.8 WFS_EXEE_CEU_EMBOSS_FAILURE

This service event is used to specify that an error has occurred during processing of a WFS_CMD_CEU_EMBOSS_CARD execute command. Description

Event Param $LPWORD\ lpwEmbossFailure;$

lpwEmbossFailure

Specified as one of the following flags:

Value	Meaning
WFS_CEU_STEPPER_ERROR	Stepper hardware error.
WFS_CEU_TOPPER_FOIL_BREAK	Topper foil has broken.
WFS_CEU_CARD_FEED_ERROR	Card feed failure.
WFS_CEU_MAGNETIC_STRIPE_ERROR	Magnetic stripe read/write error.
WFS_CEU_RETAIN_BIN_FULL	Retain bin is full.
WFS_CEU_OUTPUT_BIN_FULL	Output bin is full.
WFS_CEU_COVER_OPEN	Device cover is open.
WFS_CEU_TOPPER_JAM	Topper has jammed.
WFS_CEU_STACKER_ERROR	Stacker error either inside device or in output
	bin.
WFS_CEU_SYSTEM_ERROR	Unknown system error.
WFS_CEU_OCR_ERROR	OCR unit failure.
WFS_CEU_EMBOSS_LIMITS_EXCEEDED	Embossing limits exceeded.
WFS_CEU_COMMUNICATIONS_FAILURE	Communications failure.
WFS_CEU_DATA_FORMAT_ERROR	Communications data format error.
WFS_CEU_BUFFER_OVERRUN	Buffer overrun.
WFS_CEU_PRE_ENCODE_READ_ERROR	Pre-encode read error.
WFS_CEU_PRE_ENCODE_DATA_MATCH_	ERROR
	Data has failed to compare during pre-
	encode data match step.
WFS_CEU_INPUT_BIN_EMPTY	Input bin is empty.
WFS_CEU_DEVICE_BUSY	Device is busy, unable to emboss card.

6.9 WFS SRVE CEU DEVICEPOSITION

Description	This service event reports that the device has changed its position status.		
Event Param	LPWFSCEUDEVICEPOSITION lpDevicePosition;		
	typedef struct wfs ceu device posit { WORD		
	<u>wPosition</u> Position of the device as one of the following value	<u>.</u>	
	WFS CEU DEVICEINPOSITION	The device is in its normal operating	
	WFS_CEU_DEVICENOTINPOSITION	position. The device has been removed from its normal operating position.	
	WFS_CEU_DEVICEPOSUNKNOWN	The position of the device cannot be determined.	
Comments	None.		

6.10 WFS SRVE CEU POWER SAVE CHANGE

Description	This service event specifies that the power save recovery time has changed.		
Event Param	LPWFSCEUPOWERSAVECHANGE lpPowerSaveChange;		
	typedef struct wfs ceu power save change		
	<u>usPowerSaveRecoveryTime</u> Specifies the actual number of seconds required by the device to resume its normal operational state. This value is zero if the device exited the power saving mode.		
Comments	None.		

7. Embossing Form, Field and Media Definitions

This section outlines the format of the embossing definitions of forms and the fields within them.

7.1 Definition Syntax

The syntactic rules for form, field and media definitions are as follows:

White space space, tabLine continuation backslash (\)

Line termination CR, LF, CR/LF; line termination ends a "keyword section"

(a keyword and its value[s])

Keywords must be all upper case

Names (field/media/font names) any case; case is preserved;

Service Providers are case sensitive

Strings all strings must be enclosed in double quote characters (");

to include a double quote in a string, "escape" with a forward slash (/")

• Comments start with two forward slashes (//), end at line termination

Other notes:

If a keyword is present, all its values must be specified; default values are used only if the keyword is
absent

Values that are character strings are marked with asterisks in the definitions below, and must be quoted
as specified above.

7.2 Embossing Form and Media Measurements

The UNIT keyword sections of the form and media definitions specify the base horizontal and vertical resolution as follows:

- The *base* value specifies the base unit of measurement.
- The x and y values specify the horizontal and vertical resolution as fractions of the base value (e.g. an x value of 10 and a base value of MM means that the base horizontal resolution is 0.1mm).

The base resolutions thus defined by the UNIT keyword section of the *form* definition are used as the units of the form definition keyword sections:

- SIZE (width and height values)
- ALIGNMENT (xoffset and yoffset values)

and of the field definition keyword sections:

- POSITION (x and y values)
- SIZE (width and height values)

The base resolutions thus defined by the UNIT keyword section of the *media* definition are used as the units of the media definition keyword sections:

- SIZE (width and height values)
- EMBOSSAREA (x, y, width and height values)
- RESTRICTED (x, y, width and height values)

7.3 Embossing Form Definition

XFSFORM		formname	
BEGIN			
(required)	UNIT	base,	Base resolution unit for form definition MM INCH ROWCOLUMN Horizontal base unit fraction
		У	Vertical base unit fraction
(required)	SIZE	width, height	Width of form Height of form
	ALIGNMENT	alignment,	Alignment of the form on the physical medium: TOPLEFT (default) TOPRIGHT BOTTOMLEFT BOTTOMRIGHT
		xoffset, yoffset	Horizontal offset relative to the horizontal alignment specified by alignment. Always specified as a positive value (i.e. if aligned to the right side of the medium, means offset the form to the left). (default = 0) Vertical offset relative to the vertical alignment specified by alignment. Always specified as a positive value (i.e. if aligned to the bottom of the medium, means offset the form upward). (default = 0)
	VERSION	major, minor, date*, author*	Major version number Minor version number Creation/modification date Author of form
(required)	LANGUAGE	languageID	Language used in this form - a 16 bit value (LANGID) which is a combination of a primary (10 bits) and a secondary (6 bits) language ID (This is the standard language ID in the Win32 API; standard macros support construction and decomposition of this composite ID)
	COPYRIGHT	copyright*	Copyright entry
	TITLE	title*	Title of form
	COMMENT	comment*	Comment section
	USERPROMPT	prompt*	Prompt string for user interaction
	[XFSFIELD	fieldname	One field definition (as defined in the next section) for each field in the form
END	BEGIN END		
END			

7.4 Embossing Field Definition

XFSFIELD		fieldname	
BEGIN		jeeunume	
(required)	POSITION	x, y	Horizontal position (relative to left or right side of form, depending upon HPOSITION keyword) Vertical position (relative to top or bottom of form,
	HPOSITION		depending upon VPOSITION keyword) Horizontal field positioning relative to: LEFT (default) RIGHT
	VPOSITION		Vertical field positioning relative to: TOP BOTTOM (default)
	SIDE		Side of card: FRONT (default) BACK
(required)	SIZE	width, height	Field width Field height
	ТҮРЕ	fieldtype	Type of field: TEXT (default) OCR
	CLASS	class	Field class OPTIONAL (default) STATIC REQUIRED
	CASE	case	Convert field contents to NOCHANGE (default) UPPER LOWER
	HORIZONTAL	justify	Horizontal alignment of field contents LEFT (default) RIGHT CENTER JUSTIFY
	VERTICAL	justify	Vertical alignment of field contents BOTTOM (default) CENTER TOP
	FONT	fontname*	Font name; in some cases this predefines the following parameters:
	POINTSIZE	pointsize	Point size
	CPI	cpi	Characters per inch
<u> </u>	LPI	lpi	Lines per inch
	FORMAT	formatstring*	This is an application defined input field describing how the application should format the data. This may be interpreted by the service provider.
	INITIALVALUE	value*	Initial value
END			

7.5 Media Definition

The media definition determines those characteristics that result from the combination of a particular media type together with a particular vendor's identification card or smart card. The aim is to make it easy to move forms between different vendor's identification cards or smart cards which might have different constraints on how they handle a specific media type. It is the Service Provider's responsibility to ensure that the form definition does not specify the embossing of any fields that conflict with the media definition. An example of such a conflict might be that the form definition asks for a field to be embossed in an area that the media definition defines as a restricted area, such as on the chip of a smart card.

XFSMEDIA		medianame*	
BEGIN			
	TYPE	type	Predefined media types are:
			EMBOSSCARD
(required)	UNIT	base,	Base resolution unit for media definition
			MM
			INCH
			ROWCOLUMN
		х,	Horizontal base unit fraction
		y	Vertical base unit fraction
(required)	SIZE	width,	Width of physical media
		height	Height of physical media
	EMBOSSAREA	х,	Embossing area relative
		у,	to top left corner
		width,	of physical media
		height	(default = physical size of media)
	RESTRICTED	х,	Restricted area relative to
		у,	to top left corner
		width,	of physical media
		height	(default = no restricted area)
END			

8. C-Header file

```
XFS - Card Embossing Unit (CEU) definitions
              Version 3.10 (29/11/2007)
                                                                                                  Deleted: 00 (
Deleted: /18/00)
#ifndef __INC_XFSCEU__H
#define __INC_XFSCEU H
#ifdef __cpl
extern "C" {
        _cplusplus
#endif
#include <xfsapi.h>
   be aware of alignment
#pragma pack(push,1)
/* values of WFSCEUCAPS.wClass */
            WFS_SERVICE_CLASS_CEU
#define
                                                   (12)
            WFS_SERVICE_CLASS_NAME_CEU
#define
                                                   "CEII"
            WFS_SERVICE_CLASS_VERSION_CEU
                                                  ▼(0x0A03) /* Version 3.10 */
#define
                                                                                                 Deleted: 0x0003
            CEU_SERVICE_OFFSET
#define
                                                   (WFS_SERVICE_CLASS_CEU * 100)
/* CEU Info Commands */
#define
            WFS_INF_CEU_STATUS
                                                   (CEU_SERVICE_OFFSET + 1)
#define
            WFS INF CEU CAPABILITIES
                                                   (CEU SERVICE OFFSET + 2)
            WFS_INF_CEU_FORM_LIST
WFS_INF_CEU_QUERY_FORM
#define
                                                   (CEU SERVICE OFFSET + 3)
                                                   (CEU SERVICE OFFSET + 4)
#define
            WFS_INF_CEU_MEDIA_LIST
WFS_INF_CEU_QUERY_MEDIA
#define
                                                   (CEU_SERVICE_OFFSET + 5)
                                                   (CEU SERVICE OFFSET + 6)
#define
            WFS_INF_CEU_QUERY_FIELD
                                                   (CEU_SERVICE_OFFSET + 7)
#define
/* CEU Execute Commands */
            WFS_CMD_CEU_EMBOSS_CARD WFS_CMD_CEU_RESET
#define
                                                   (CEU_SERVICE_OFFSET + 1)
                                                   (CEU_SERVICE_OFFSET + 2)
#define
            WFS CMD CEU POWER SAVE CONTROL
                                                   (CEU SERVICE OFFSET + 3)
#define
/* CEU Messages */
            WFS_SRVE_CEU_INPUTBINTHRESHOLD WFS_SRVE_CEU_OUTPUTBINTHRESHOLD
                                                   (CEU_SERVICE_OFFSET + 1)
(CEU_SERVICE_OFFSET + 2)
#define
#define
            WFS_SRVE_CEU_RETAINBINTHRESHOLD
                                                   (CEU_SERVICE_OFFSET + 3)
#define
                                                   (CEU_SERVICE_OFFSET + 4)
#define
            WFS_EXEE_CEU_FIELDERROR
#define
            WFS_EXEE_CEU_FIELDWARNING
                                                   (CEU_SERVICE_OFFSET + 5)
#define
            WFS_EXEE_CEU_EMBOSS_FAILURE
                                                   (CEU_SERVICE_OFFSET + 6)
#define
            {\tt WFS\_SRVE\_CEU\_MEDIAREMOVED}
                                                   (CEU_SERVICE_OFFSET + 7)
#define
            WFS_SRVE_CEU_MEDIADETECTED
                                                   (CEU_SERVICE_OFFSET + 8)
            WFS SRVE CEU DEVICEPOSITION
                                                   (CEU SERVICE OFFSET + 9)
#define
            WFS_SRVE_CEU_POWER_SAVE_CHANGE
                                                   (CEU_SERVICE_OFFSET +
/* values of WFSCEUSTATUS.fwDevice */
            WFS CEU DEVONLINE
                                                  WFS_STAT_DEVONLINE
#define
                                                  WFS_STAT_DEVOFFLINE
WFS_STAT_DEVPOWEROFF
#define
            WFS CEU DEVOFFLINE
#define
            WFS_CEU_DEVPOWEROFF
            WFS_CEU_DEVNODEVICE
                                                  WFS_STAT_DEVNODEVICE
#define
#define
            WFS_CEU_DEVHWERROR
                                                  WFS_STAT_DEVHWERROR
```

```
#define
             WFS CEU DEVUSERERROR
                                                   WFS STAT DEVUSERERROR
                                                   WFS_STAT_DEVBUSY
WFS_STAT_DEVFRAUDATTEMPT
             WFS CEU DEVBUSY
#define
            WFS CEU DEVFRAUDATTEMPT
#define
/* values of WFSCEUSTATUS.fwMedia */
            WFS CEU MEDIAPRESENT
#define
                                                   (1)
            WFS CEU MEDIANOTPRESENT
#define
                                                   (2)
#define
            WFS CEU MEDIAJAMMED
                                                    (3)
#define
            WFS CEU MEDIANOTSUPP
                                                    (4)
#define
            WFS_CEU_MEDIAUNKNOWN
                                                    (5)
#define
             WFS CEU MEDIAENTERING
                                                    (6)
#define
             WFS CEU MEDIATOPPER
                                                    (7)
            WFS CEU MEDIAINHOPPER
#define
                                                   (8)
#define
             WFS CEU MEDIAOUTHOPPER
                                                    (9)
#define
            WFS CEU MEDIAMSRE
                                                   (10)
            WFS CEU MEDIARETAINED
#define
                                                    (11)
            WFS CEU MEDIAREMOVED
#define
                                                   (12)
/* values of WFSCEUSTATUS.fwRetainBin */
            WFS_CEU_RETAINBINOK
#define
                                                   (1)
#define
            WFS_CEU_RETAINBINFULL
                                                   (2)
#define
            WFS_CEU_RETAINBINHIGH
                                                    (3)
#define
             WFS_CEU_RETAINBINNOTSUPP
/* values of WFSCEUSTATUS.fwOutputBin */
#define
             WFS_CEU_OUTPUTBINOK
                                                   (1)
            WFS_CEU_OUTPUTBINFULL
WFS_CEU_OUTPUTBINHIGH
#define
                                                    (2)
#define
                                                    (3)
            WFS_CEU_OUTPUTNOTSUPP
#define
                                                   (4)
/* values of WFSCEUSTATUS.fwInputBin */
            WFS_CEU_INPUTBINOK
WFS_CEU_INPUTBINEMPTY
#define
                                                    (1)
#define
                                                    (2)
#define
            WFS CEU INPUTBINLOW
                                                    (3)
#define
            WFS_CEU_INPUTNOTSUPP
                                                    (4)
/* values of WFSCEUSTATUS.wDevicePosition
              WFSCEUDEVICEPOSITION.wPosition */
#define
            WFS CEU DEVICEINPOSITION
                                                    (0)
            WFS CEU DEVICENOTINPOSITION
#define
                                                    (1)
#define
            WFS CEU DEVICEPOSUNKNOWN
                                                    (2)
#define
            WFS CEU DEVICEPOSNOTSUPP
                                                    (3)
/* values of WFSCEUFRMMEDIA.wBase */
#define
            WFS CEU INCH
                                                    (1)
#define
            WFS CEU MM
                                                    (2)
            WFS CEU ROWCOLUMN
#define
                                                   (3)
/* values of WFSCEUFRMMEDIA.fwMediaType */
            WFS CEU MEDIAECARD
#define
                                                   (1)
/* values of WFSCEUFRMFIELD.fwType */
            WFS CEU FIELDTEXT
#define
                                                   (1)
#define
            WFS_CEU_FIELDOCR
                                                   (2)
/* values of WFSCEUFRMFIELD.fwClass */
            WFS CEU CLASSSTATIC
                                                   (1)
             WFS CEU CLASSOPTIONAL
#define
                                                    (2)
            WFS CEU CLASSREQUIRED
#define
                                                   (3)
/* values WFSCEUFIELDFAIL.wFailure */
```

```
WFS CEU FIELDREQUIRED
#define
                                                    (1)
#define
            WFS CEU FIELDSTATICOVWR
                                                    (2)
#define
             WFS CEU FIELDOVERFLOW
                                                    (3)
#define
            WFS CEU FIELDNOTFOUND
                                                    (4)
            WFS_CEU_FIELDNOTREAD
#define
                                                    (5)
#define
            WFS CEU FIELDNOTWRITE
                                                    (6)
            WFS_CEU_FIELDHWERROR
#define
                                                    (7)
#define
            WFS CEU FIELDTYPENOTSUPPORTED
                                                    (8)
/* values of WFSCEUEMBOSSCARD.fwChipProtocols */
            WFS CEU NOTSUPP
#define
                                                    (0x0000)
            WFS CEU CHIPTO
#define
                                                    (0x0001)
#define
            WFS CEU CHIPT1
                                                    (0x0002)
            WFS CEU CHIPT2
#define
                                                    (0x0004)
            WFS_CEU_CHIPT3
WFS_CEU_CHIPT4
                                                    (0x0008)
#define
#define
                                                    (0 \times 0.010)
            WFS_CEU_CHIPT5
#define
                                                    (0x0020)
                                                    (0x0040)
#define
            WFS_CEU_CHIPT6
            WFS_CEU_CHIPT7
#define
                                                    (0x0080)
#define
            WFS CEU CHIPT8
                                                    (0x0100)
#define
            WFS CEU CHIPT9
                                                    (0x0200)
#define
            WFS CEU CHIPT10
                                                    (0x0400)
#define
            WFS_CEU_CHIPT11
                                                    (0x0800)
#define
            WFS CEU CHIPT12
                                                    (0x1000)
#define
            WFS CEU CHIPT13
                                                    (0x2000)
#define
            WFS CEU CHIPT14
                                                    (0x4000)
            WFS_CEU_CHIPT15
#define
                                                    (0x8000)
/* WFS EXEE CEU EMBOSS FAILURE Flags */
#define
            WFS CEU STEPPER ERROR
                                                    (1)
            WFS_CEU_TOPPER_FOIL_BREAK
#define
                                                    (2)
            WFS_CEU_CARD_FEED_ERROR
#define
                                                    (3)
#define
            WFS CEU MAGNETIC STRIPE ERROR
                                                    (4)
#define
            WFS CEU RETAIN BIN FULL
                                                    (5)
#define
            WFS CEU OUTPUT BIN FULL
                                                    (6)
#define
            WFS_CEU_COVER_OPEN
                                                    (7)
#define
            WFS CEU TOPPER JAM
                                                    (8)
#define
             WFS CEU STACKER ERROR
                                                    (9)
            WFS CEU SYSTEM ERROR
#define
                                                    (10)
            WFS CEU OCR ERROR
#define
                                                    (11)
#define
            WFS_CEU_EMBOSS_LIMITS_EXCEEDED
                                                    (12)
            WFS_CEU_COMMUNICATIONS_FAILURE
#define
                                                    (13)
            WFS_CEU_DATA_FORMAT_ERROR
#define
                                                    (14)
#define
            WFS_CEU_BUFFER OVERRUN
                                                    (15)
            WFS_CEU_PRE_ENCODE_READ_ERROR
#define
                                                    (16)
#define
            WFS CEU PRE ENCODE DATA MATCH ERROR (17)
#define
            WFS_CEU_INPUT_BIN_EMPTY
                                                    (18)
            WFS CEU DEVICE BUSY
#define
/* values of lpwCeuMediacontrol paramater of WFS CMD CEU RESET command */
#define
             WFS CEU CTRLTOINPUTBIN
#define
             WFS CEU CTRLTOOUTPUTBIN
                                                    (2)
            WFS CEU CTRLTORETAINBIN
#define
                                                    (3)
/* WOSA/XFS CEU Errors */
#define WFS_ERR_CEU_FORMNOTFOUND
                                                   (-(CEU_SERVICE_OFFSET + 1))
#define WFS ERR CEU FORMINVALID
                                                    (-(CEU SERVICE OFFSET + 2))
#define WFS_ERR_CEU_MEDIANOTFOUND
                                                    (-(CEU_SERVICE_OFFSET + 3))
#define WFS ERR CEU MEDIAINVALID
                                                    (-(CEU SERVICE OFFSET + 4))
#define WFS ERR CEU NOMEDIA
                                                    (-(CEU_SERVICE_OFFSET + 5))
#define WFS ERR CEU MEDIAOVERFLOW
                                                    (-(CEU SERVICE OFFSET + 6))
#define WFS_ERR_CEU_IDC_FORMNOTFOUND
#define WFS_ERR_CEU_IDC_FORMINVALID
#define WFS_ERR_CEU_INVALIDDATA
                                                   (-(CEU SERVICE OFFSET + 7))
                                                   (-(CEU SERVICE OFFSET + 8))
                                                   (-(CEU_SERVICE_OFFSET + 9))
```

```
#define WFS ERR CEU PROTOCOLNOTSUPP
                                                (-(CEU SERVICE OFFSET + 10))
#define WFS_ERR_CEU_ATRNOTOBTAINED
#define WFS_ERR_CEU_FIELDSPECFAILURE
                                                (-(CEU_SERVICE_OFFSET + 11))
                                               (-(CEU SERVICE OFFSET + 12))
                                               (-(CEU_SERVICE_OFFSET + 13))
(-(CEU_SERVICE_OFFSET + 14))
#define WFS_ERR_CEU_FIELDERROR
#define WFS ERR CEU EMBOSSFAILURE
#define WFS_ERR_CEU_FIELDNOTFOUND
                                                (-(CEU_SERVICE_OFFSET + 15))
#define WFS_ERR_CEU_POWERSAVETOOSHORT
                                                (-(CEU SERVICE OFFSET + 16))
#define WFS ERR CEU POWERSAVEMEDIAPRESENT
                                                (-(CEU SERVICE OFFSET + 17))
/*----*/
/* CEU Info Command Structures and variables */
/*======*/
typedef struct _wfs_ceu_status
    WORD
                   fwDevice;
   WORD
                   fwMedia:
    WORD
                   fwRetainBin;
   WORD
                   fwOutputBin;
    WORD
                   fwInputBin;
   USHORT
                   usTotalCards;
    USHORT
                   usOutputCards;
   USHORT
                   usRetainCards;
   LPSTR
                   lpszExtra;
                   wDevicePosition;
    WORD
                   usPowerSaveRecoveryTime;
    USHORT
} WFSCEUSTATUS, *LPWFSCEUSTATUS;
typedef struct _wfs_ceu_caps
   WORD
                   wClass:
   BOOL
                   bCompound;
   BOOL
                   bCompareMagneticStripe;
   BOOL
                   bMagneticStripeRead;
   BOOL
                   bMagneticStripeWrite;
   BOOL
                   bChipIO;
   WORD
                   wChipProtocol;
    LPSTR
                   lpszExtra;
                   bPowerSaveControl;
} WFSCEUCAPS, *LPWFSCEUCAPS;
typedef struct _wfs_ceu_form
   LPSTR
                   lpszFormName;
   LPSTR
                   lpszFields;
} WFSCEUFORM, *LPWFSCEUFORM;
typedef struct _wfs_ceu_frm_media
    WORD
                   fwMediaType;
    WORD
                   wBase;
    WORD
                   wUnitX;
   WORD
                   wUnitY:
    WORD
                   wSizeWidth;
                   wSizeHeight;
   WORD
   WORD
                   wEmbossAreaX;
   WORD
                   wEmbossAreaY;
    WORD
                   wEmbossAreaWidth;
   WORD
                   wEmbossAreaHeight;
    WORD
                   wRestrictedAreaX;
   WORD
                   wRestrictedAreaY;
    WORD
                   wRestrictedAreaWidth;
                   wRestrictedAreaHeight;
} WFSCEUFRMMEDIA, *LPWFSCEUFRMMEDIA;
typedef struct _wfs_ceu_query_field
   LPSTR
                   lpszFormName;
```

```
Page 42
CWA 15748-73:2008
                lpszFieldName;
} WFSCEUQUERYFIELD, *LPWFSCEUQUERYFIELD;
typedef struct _wfs_ceu_frm_field
   LPSTR
                lpszFieldName;
   WORD
                 fwType;
   WORD
                 fwClass;
   LPSTR
                 lpszInitialValue;
   LPSTR
                lpszFormat;
} WFSCEUFRMFIELD, *LPWFSCEUFRMFIELD;
/*----*/
/* CEU Execute Command Structures */
/*=======*/
typedef struct _wfs_ceu_emboss_card
   LPSTR
                lpszFormName;
   LPSTR
                 lpszMediaName;
   LPSTR
                 lpszFields;
   LPSTR
                 lpszCompareFormIOFormName;
   LPSTR
                lpszCompareFormIOTrackData;
   LPSTR
                 lpszFormIOFormName;
   LPSTR
                lpszFormIOTrackData;
   WORD
                 wChipProtocol;
                ulChipDataLength;
   ULONG
   LPBYTE
                 lpbChipData;
} WFSCEUEMBOSSCARD, *LPWFSCEUEMBOSSCARD;
typedef struct _wfs_ceu_power_save_control
                usMaxPowerSaveRecoveryTime;
} WFSCEUPOWERSAVECONTROL, *LPWFSCEUPOWERSAVECONTROL;
/*=============*/
/* CEU Message Structures */
/*======*/
typedef struct _wfs_ceu_field_failure
                 lpszFormName;
   LPSTR
                 lpszFieldName;
   WORD
                 wFailure:
} WFSCEUFIELDFAIL, *LPWFSCEUFIELDFAIL;
typedef struct wfs ceu device position
                 wPosition;
} WFSCEUDEVICEPOSITION, *LPWFSCEUDEVICEPOSITION;
typedef struct wfs ceu power save change
                usPowerSaveRecoveryTime;
   USHORT
} WFSCEUPOWERSAVECHANGE, *LPWFSCEUPOWERSAVECHANGE;
/* restore alignment */
#pragma pack(pop)
#ifdef __cplusplus
       /*extern "C"*/
#endif
#endif /* __INC_XFSCEU__H */
```