

**CEN**

**CWA 15748-12**

**WORKSHOP**

July 2008

**AGREEMENT**

---

ICS 35.240.50

English version

**Extensions for Financial Services (XFS) interface specification -  
Release 3.10 - Part 12: Camera Device Class Interface -  
Programmer's Reference**

This CEN Workshop Agreement has been drafted and approved by a Workshop of representatives of interested parties, the constitution of which is indicated in the foreword of this Workshop Agreement.

The formal process followed by the Workshop in the development of this Workshop Agreement has been endorsed by the National Members of CEN but neither the National Members of CEN nor the CEN Management Centre can be held accountable for the technical content of this CEN Workshop Agreement or possible conflicts with standards or legislation.

This CEN Workshop Agreement can in no way be held as being an official standard developed by CEN and its Members.

This CEN Workshop Agreement is publicly available as a reference document from the CEN Members National Standard Bodies.

CEN members are the national standards bodies of Austria, Belgium, Bulgaria, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, Netherlands, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland and United Kingdom.



EUROPEAN COMMITTEE FOR STANDARDIZATION  
COMITÉ EUROPÉEN DE NORMALISATION  
EUROPÄISCHES KOMITEE FÜR NORMUNG

**Management Centre: rue de Stassart, 36 B-1050 Brussels**

---

© 2008 CEN All rights of exploitation in any form and by any means reserved worldwide for CEN national Members.

Ref. No.:CWA 15748-12:2008 D/E/F

## Table of Contents

---

<b>Foreword .....</b>	<b>3</b>
<b>1. Introduction.....</b>	<b>6</b>
1.1 Background to Release 3.10 .....	6
1.2 XFS Service-Specific Programming .....	6
<b>2. Banking Cameras .....</b>	<b>7</b>
<b>3. References .....</b>	<b>8</b>
<b>4. Info Commands .....</b>	<b>9</b>
4.1 WFS_INF_CAM_STATUS.....	9
4.2 WFS_INF_CAM_CAPABILITIES .....	12
<b>5. Execute Commands .....</b>	<b>14</b>
5.1 WFS_CMD_CAM_TAKE_PICTURE .....	14
5.2 WFS_CMD_CAM_RESET.....	15
<b>6. Events.....</b>	<b>16</b>
6.1 WFS_USRE_CAM_MEDIATHRESHOLD.....	16
6.2 WFS_EXEE_CAM_INVALIDDATA.....	17
<b>7. C - Header file .....</b>	<b>18</b>

## Foreword

---

This CWA is revision 3.10 of the XFS interface specification.

The CEN/ISSS XFS Workshop gathers suppliers as well as banks and other financial service companies. A list of companies participating in this Workshop and in support of this CWA is available from the CEN/ISSS Secretariat.

This CWA was formally approved by the XFS Workshop meeting on 2007-11-29. The specification is continuously reviewed and commented in the CEN/ISSS Workshop on XFS. It is therefore expected that an update of the specification will be published in due time as a CWA, superseding this revision 3.10.

The CWA is published as a multi-part document, consisting of:

Part 1: Application Programming Interface (API) - Service Provider Interface (SPI) - Programmer's Reference

Part 2: Service Classes Definition - Programmer's Reference

Part 3: Printer and Scanning Device Class Interface - Programmer's Reference

Part 4: Identification Card Device Class Interface - Programmer's Reference

Part 5: Cash Dispenser Device Class Interface - Programmer's Reference

Part 6: PIN Keypad Device Class Interface - Programmer's Reference

Part 7: Check Reader/Scanner Device Class Interface - Programmer's Reference

Part 8: Depository Device Class Interface - Programmer's Reference

Part 9: Text Terminal Unit Device Class Interface - Programmer's Reference

Part 10: Sensors and Indicators Unit Device Class Interface - Programmer's Reference

Part 11: Vendor Dependent Mode Device Class Interface - Programmer's Reference

Part 12: Camera Device Class Interface - Programmer's Reference

Part 13: Alarm Device Class Interface - Programmer's Reference

Part 14: Card Embossing Unit Device Class Interface - Programmer's Reference

Part 15: Cash-In Module Device Class Interface - Programmer's Reference

Part 16: Card Dispenser Device Class Interface - Programmer's Reference

Part 17: Barcode Reader Device Class Interface - Programmer's Reference

Part 18: Item Processing Module Device Class Interface - Programmer's Reference

Parts 19 - 28: Reserved for future use.

Parts 29 through 47 constitute an optional addendum to this CWA. They define the integration between the SNMP standard and the set of status and statistical information exported by the Service Providers.

Part 29: XFS MIB Architecture and SNMP Extensions - Programmer's Reference

Part 30: XFS MIB Device Specific Definitions - Printer Device Class

Part 31: XFS MIB Device Specific Definitions - Identification Card Device Class

Part 32: XFS MIB Device Specific Definitions - Cash Dispenser Device Class

Part 33: XFS MIB Device Specific Definitions - PIN Keypad Device Class

Part 34: XFS MIB Device Specific Definitions - Check Reader/Scanner Device Class

Part 35: XFS MIB Device Specific Definitions - Depository Device Class

Part 36: XFS MIB Device Specific Definitions - Text Terminal Unit Device Class

Part 37: XFS MIB Device Specific Definitions - Sensors and Indicators Unit Device Class

Part 38: XFS MIB Device Specific Definitions - Camera Device Class

Part 39: XFS MIB Device Specific Definitions - Alarm Device Class

Part 40: XFS MIB Device Specific Definitions - Card Embossing Unit Class

Part 41: XFS MIB Device Specific Definitions - Cash-In Module Device Class

Part 42: Reserved for future use.

Part 43: XFS MIB Device Specific Definitions - Vendor Dependent Mode Device Class

Part 44: XFS MIB Application Management

Part 45: XFS MIB Device Specific Definitions - Card Dispenser Device Class

Part 46: XFS MIB Device Specific Definitions - Barcode Reader Device Class

Part 47: XFS MIB Device Specific Definitions - Item Processing Module Device Class

Parts 48 - 60 are reserved for future use.

Part 61: Application Programming Interface (API) - Service Provider Interface (SPI) - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 62: Printer Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 63: Identification Card Device Class Interface - Migration from Version 3.02 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 64: Cash Dispenser Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 65: PIN Keypad Device Class Interface - Migration from Version 3.03 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 66: Check Reader/Scanner Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 67: Depository Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 68: Text Terminal Unit Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 69: Sensors and Indicators Unit Device Class Interface - Migration from Version 3.01 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 70: Vendor Dependent Mode Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 71: Camera Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 72: Alarm Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 73: Card Embossing Unit Device Class Interface - Migration from Version 3.0 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

Part 74: Cash-In Module Device Class Interface - Migration from Version 3.02 (CWA 14050) to Version 3.10 (this CWA) - Programmer's Reference

In addition to these Programmer's Reference specifications, the reader of this CWA is also referred to a complementary document, called Release Notes. The Release Notes contain clarifications and explanations on the CWA specifications, which are not requiring functional changes. The current version of the Release Notes is available online from <http://www.cen.eu/iss/Workshop/XFS>.

The information in this document represents the Workshop's current views on the issues discussed as of the date of publication. It is furnished for informational purposes only and is subject to change without notice. CEN/ISSS makes no warranty, express or implied, with respect to this document.

This CEN Workshop Agreement is publicly available as a reference document from the National Members of CEN : AENOR, AFNOR, ASRO, BDS, BSI, CSNI, CYS, DIN, DS, ELOT, EVS, IBN, IPQ, IST, LVS, LST, MSA, MSZT, NEN, NSAI, ON, PKN, SEE, SIS, SIST, SFS, SN, SNV, SUTN and UNI.

Comments or suggestions from the users of the CEN Workshop Agreement are welcome and should be addressed to the CEN Management Centre.

Revision History:

1.0	May 24, 1993	Initial release of API and SPI specification.
1.11	February 3, 1995	Separation of specification into separate documents for API/SPI and service class definitions.
2.0	November 11, 1996	Update release encompassing the self-service environment.
3.0	October 18, 2000	Update release encompassing: <ul style="list-style-type: none"><li>• Added WFS_CMD_CAM_RESET</li><li>• UNICODE support</li></ul> For a detailed description see CWA 14050-24 CAM migration document from version 2.0 to version 3.0, revision 1.0, October 18 <sup>th</sup> 2000.
3.10	November 29, 2007	For a description of changes see CWA 15748-71:2007 CAM Migration from Version 3.0 (see CWA 14050) to Version 3.10.

## 1. Introduction

---

### 1.1 Background to Release 3.10

---

The CEN/ISSS XFS Workshop aims to promote a clear and unambiguous specification defining a multi-vendor software interface to financial peripheral devices. The XFS (eXtensions for Financial Services) specifications are developed within the CEN/ISSS (European Committee for Standardization/Information Society Standardization System) Workshop environment. CEN/ISSS Workshops aim to arrive at a European consensus on an issue that can be published as a CEN Workshop Agreement (CWA).

The CEN/ISSS XFS Workshop encourages the participation of both banks and vendors in the deliberations required to create an industry standard. The CEN/ISSS XFS Workshop achieves its goals by focused sub-groups working electronically and meeting quarterly.

Release 3.10 of the XFS specification is based on a C API and is delivered with the continued promise for the protection of technical investment for existing applications. This release of the XFS specification has been prompted by a series of factors.

There has been a technical imperative to extend the scope of the existing specification to include new devices, such as the Barcode Reader, Card Dispenser and Item Processing Module.

Similarly, there has also been pressure, through implementation experience and additional requirements, to extend the functionality and capabilities of the existing devices covered by the specification.

### 1.2 XFS Service-Specific Programming

---

The service classes are defined by their service-specific commands and the associated data structures, error codes, messages, etc. These commands are used to request functions that are specific to one or more classes of Service Providers, but not all of them, and therefore are not included in the common API for basic or administration functions.

When a service-specific command is common among two or more classes of Service Providers, the syntax of the command is as similar as possible across all services, since a major objective of XFS is to standardize function codes and structures for the broadest variety of services. For example, using the **WFSExecute** function, the commands to read data from various services are as similar as possible to each other in their syntax and data structures.

In general, the specific command set for a service class is defined as a superset of the specific capabilities likely to be provided by the developers of the services of that class; thus any particular device will normally support only a subset of the defined command set.

There are three cases in which a Service Provider may receive a service-specific command that it does not support:

The requested capability is defined for the class of Service Providers by the XFS specification, the particular vendor implementation of that service does not support it, and the unsupported capability is *not* considered to be fundamental to the service. In this case, the Service Provider returns a successful completion, but does no operation. An example would be a request from an application to turn on a control indicator on a passbook printer; the Service Provider recognizes the command, but since the passbook printer it is managing does not include that indicator, the Service Provider does no operation and returns a successful completion to the application.

The requested capability is defined for the class of Service Providers by the XFS specification, the particular vendor implementation of that service does not support it, and the unsupported capability *is* considered to be fundamental to the service. In this case, a `WFS_ERR_UNSUPP_COMMAND` error is returned to the calling application. An example would be a request from an application to a cash dispenser to dispense coins; the Service Provider recognizes the command but, since the cash dispenser it is managing dispenses only notes, returns this error.

The requested capability is *not* defined for the class of Service Providers by the XFS specification. In this case, a `WFS_ERR_INVALID_COMMAND` error is returned to the calling application.

This design allows implementation of applications that can be used with a range of services that provide differing subsets of the functionalities that are defined for their service class. Applications may use the **WFSGetInfo** and **WFSAsyncGetInfo** commands to inquire about the capabilities of the service they are about to use, and modify their behavior accordingly, or they may use functions and then deal with `WFS_ERR_UNSUPP_COMMAND` error returns to make decisions as to how to use the service.

## 2. Banking Cameras

---

This specification describes the functionality of the services provided by the Camera (CAM) services under XFS, by defining the service-specific commands that can be issued, using the **WFSGetInfo**, **WFSAsyncGetInfo**, **WFSExecute** and **WFSAsyncExecute** functions.

Banking camera systems usually consist of a recorder, a video mixer and one or more cameras. If there are several cameras, each camera focuses a special place within the self-service area (e.g. the room, the customer or the cash tray). By using the video mixer it can be decided, which of the cameras should take the next photo. Furthermore data can be given to be inserted in the photo (e.g. date, time or bank code).

If there is only one camera that can switch to take photos from different positions, it is presented by the Service Provider as a set of cameras, one for each of its possible positions.

### **3. References**

---

---

- |  |
|--|
| 1. XFS Application Programming Interface (API)/Service Provider Interface (SPI), Programmer's Reference<br>Revision 3.10 |
|--|



## 4. Info Commands

### 4.1 WFS\_INF\_CAM\_STATUS

**Description** This command reports the full range of information available, including the information that is provided by the Service Provider.

**Input Param** None.

**Output Param** LPWFSCAMSTATUS lpStatus;

```
typedef struct _wfs_cam_status
{
    WORD          fwDevice;
    WORD          fwMedia[WFS_CAM_CAMERAS_SIZE];
    WORD          fwCameras[WFS_CAM_CAMERAS_SIZE];
    USHORT       usPictures[WFS_CAM_CAMERAS_SIZE];
    LPSTR        lpzExtra;
} WFS_CAM_STATUS, *LPWFSCAMSTATUS;
```

*fwDevice*

Specifies the state of the Camera device as one of the following flags:

Value	Meaning
WFS_CAM_DEVONLINE	The device is online (i.e. powered on and operable).
WFS_CAM_DEVOFFLINE	The device is offline (e.g., the operator has taken the device offline by turning a switch or pulling out the device).
WFS_CAM_DEVPOWEROFF	The device is powered off or physically not connected.
WFS_CAM_DEVNODEVICE	There is no device intended to be there; e.g. this type of self service machine does not contain such a device or it is internally not configured.
WFS_CAM_DEVHWERROR	The device is inoperable due to a hardware error.
WFS_CAM_DEVUSERERROR	The device is inoperable because a person is preventing proper operation.
WFS_CAM_DEVBUSY	The device is busy and not able to process an Execute command at this time.
WFS_CAM_DEVFRAUDATTEMPT	The device is present but has detected a fraud attempt.

*fwMedia [...]*

Specifies the state of the recording media of the cameras. A number of indexes are defined below. The maximum *fwMedia* index is WFS\_CAM\_CAMERAS\_MAX.

*fwMedia [WFS\_CAM\_ROOM]*

Specifies the state of the recording media of the camera that monitors the whole self-service area. Specified as one of the following flags:

Value	Meaning
WFS_CAM_MEDIAOK	The media is in a good state.
WFS_CAM_MEDIAHIGH	The media is almost full (threshold).
WFS_CAM_MEDIASFULL	The media is full.
WFS_CAM_MEDIANOTSUPP	The device does not support sensing the media level.
WFS_CAM_MEDIAUNKNOWN	Due to a hardware error or other condition, the state of the media cannot be determined.

*fwMedia [WFS\_CAM\_PERSON]*

Specifies the state of the recording media of the camera that monitors the person standing in front of the self-service machine. Specified as one of the following flags:

Value	Meaning
WFS_CAM_MEDIAOK	The media is in a good state.
WFS_CAM_MEDIAHIGH	The media is almost full (threshold).
WFS_CAM_MEDIAFULL	The media is full.
WFS_CAM_MEDIANOTSUPP	The device does not support sensing the media level.
WFS_CAM_MEDIAUNKNOWN	Due to a hardware error or other condition, the state of the media cannot be determined.

*fwMedia [WFS\_CAM\_EXITSLOT]*

Specifies the state of the recording media of the camera that monitors the exit slot(s) of the self-service machine. Specified as one of the following flags:

Value	Meaning
WFS_CAM_MEDIAOK	The media is in a good state.
WFS_CAM_MEDIAHIGH	The media is almost full (threshold).
WFS_CAM_MEDIAFULL	The media is full.
WFS_CAM_MEDIANOTSUPP	The device does not support sensing the media level.
WFS_CAM_MEDIAUNKNOWN	Due to a hardware error or other condition, the state of the media cannot be determined.

*fwCameras [...]*

Specifies the state of the cameras. A number of cameras are defined below. The maximum camera index is WFS\_CAM\_CAMERAS\_MAX.

*fwCameras [WFS\_CAM\_ROOM]*

Specifies the state of the camera that monitors the whole self-service area. Specified as one of the following flags:

Value	Meaning
WFS_CAM_CAMNOTSUPP	The camera is not supported.
WFS_CAM_CAMOK	The camera is in a good state.
WFS_CAM_CAMINOP	The camera is inoperative.
WFS_CAM_CAMUNKNOWN	Due to a hardware error or other condition, the state of the camera cannot be determined.

*fwCameras [WFS\_CAM\_PERSON]*

Specifies the state of the camera that monitors the person standing in front of the self-service machine. Specified as one of the following flags:

Value	Meaning
WFS_CAM_CAMNOTSUPP	The camera is not supported.
WFS_CAM_CAMOK	The camera is in a good state.
WFS_CAM_CAMINOP	The camera is inoperative.
WFS_CAM_CAMUNKNOWN	Due to a hardware error or other condition, the state of the camera cannot be determined.

*fwCameras [WFS\_CAM\_EXITSLOT]*

Specifies the state of the camera that monitors the exit slot(s) of the self-service machine. Specified as one of the following flags:

Value	Meaning
WFS_CAM_CAMNOTSUPP	The camera is not supported.
WFS_CAM_CAMOK	The camera is in a good state.
WFS_CAM_CAMINOP	The camera is inoperative.
WFS_CAM_CAMUNKNOWN	Due to a hardware error or other condition, the state of the camera cannot be determined.

*usPictures [...]*

Specifies the number of pictures stored on the recording media of the cameras. A number of indexes are defined below. The maximum *usPictures* index is WFS\_CAM\_CAMERAS\_MAX.

Index	Meaning
WFS_CAM_ROOM	The camera that monitors the whole self-service area.

WFS\_CAM\_PERSON

The camera that monitors the person standing in front of the self-service machine.

WFS\_CAM\_EXITSLOT

The camera that monitors the exit slot(s) of the self-service machine.

*lpszExtra*

Pointer to a list of vendor-specific, or any other extended, information. The information is returned as a series of “*key=value*” strings so that it is easily extensible by Service Providers. Each string is null-terminated, with the final string terminating with two null characters. An empty list may be indicated by either a NULL pointer or a pointer to two consecutive null characters.

**Error Codes** Only the generic error codes defined in [Ref. 1] can be generated by this command.

**Comments** Applications which require or expect specific information to be present in the *lpszExtra* parameter may not be device or vendor-independent.

In the case where communications with the device has been lost, the *fwDevice* field will report WFS\_CAM\_DEVPOWEROFF when the device has been removed or WFS\_CAM\_DEVHWERROR if the communications are unexpectedly lost. All other fields should contain a value based on the following rules and priority:

1. Report the value as unknown.
2. Report the value as a general h/w error.
3. Report the value as the last known value.

## 4.2 WFS\_INF\_CAM\_CAPABILITIES

---

**Description** This command is used to retrieve the capabilities of the Camera System.

**Input Param** None.

**Output Param** LPWFSCAMCAPS lpCaps;

```
typedef struct _wfs_cam_caps
{
    WORD          wClass;
    WORD          fwType;
    WORD          fwCameras[WFS_CAM_CAMERAS_SIZE];
    USHORT       usMaxPictures;
    WORD          fwCamData;
    USHORT       usMaxDataLength;
    WORD          fwCharSupport;
    LPSTR        lpszExtra;
} WFS_CAMCAPS, *LPWFSCAMCAPS;
```

*wClass*

Specifies the logical service class as WFS\_SERVICE\_CLASS\_CAM.

*fwType*

Specifies the type of the camera device; only current value is:

Value	Meaning
WFS_CAM_TYPE_CAM	Camera system.

*fwCameras [...]*

Specifies which cameras are available. A number of cameras are defined below. The maximum camera index is WFS\_CAM\_CAMERAS\_MAX.

*fwCameras [WFS\_CAM\_ROOM]*

Specifies whether the camera that monitors the whole self-service area is available. Specified as one of the following flags:

Value	Meaning
WFS_CAM_NOT_AVAILABLE	This camera is not available.
WFS_CAM_AVAILABLE	This camera is available.

*fwCameras [WFS\_CAM\_PERSON]*

Specifies whether the camera that monitors the person standing in front of the self-service machine is available. Specified as one of the following flags:

Value	Meaning
WFS_CAM_NOT_AVAILABLE	This camera is not available.
WFS_CAM_AVAILABLE	This camera is available.

*fwCameras [WFS\_CAM\_EXITSLOT]*

Specifies whether the camera that monitors the exit slot(s) of the self-service machine is available. Specified as one of the following flags:

Value	Meaning
WFS_CAM_NOT_AVAILABLE	This camera is not available.
WFS_CAM_AVAILABLE	This camera is available.

*usMaxPictures*

Specifies the maximum number of pictures that can be stored on the recording media.

*fwCamData*

Specifies, if data can be added to the picture. Specified as a combination of the following flags:

Value	Meaning
WFS_CAM_NOTADD	No data can be added to the picture.
WFS_CAM_AUTOADD	Data is added automatically to the picture.

WFS\_CAM\_MANADD

Data can be added manually to the picture using the filed *lpszCamData* in the WFS\_CMD\_CAM\_TAKE\_PICTURE command.

*usMaxDataLength*

Specifies the maximum length of the data that is displayed on the photo. Zero, if data cannot be manually added to the picture.

*fwCharSupport*

One or more flags specifying the Character Set supported by the Service Provider:

Value	Meaning
WFS_CAM_ASCII	ASCII is supported for execute command data values.
WFS_CAM_UNICODE	UNICODE is supported for execute command data values.

*lpszExtra*

Pointer to a list of vendor-specific, or any other extended, information. The information is returned as a series of "key=value" strings so that it is easily extensible by Service Providers. Each string is null-terminated, with the final string terminating with two null characters. An empty list may be indicated by either a NULL pointer or a pointer to two consecutive null characters.

**Error Codes** Only the generic error codes defined in [Ref. 1] can be generated by this command.

**Comments** Applications which require or expect specific information to be present in the *lpszExtra* parameter may not be device or vendor-independent.

## 5. Execute Commands

### 5.1 WFS\_CMD\_CAM\_TAKE\_PICTURE

**Description** This command is used to start the recording of the camera system. It is possible to select which camera or which camera position should be used to take a picture. Furthermore data can be sent to be displayed on the photo.

**Input Param** LPWFSCAMTAKEPICT lpTakePict;

```
typedef struct _wfs_cam_take_picture
{
    WORD          wCamera;
    LPSTR         lpszCamData;
    LPWSTR        lpszUNICODECamData;
} WFS_CAMTAKEPICT, *LPWFSCAMTAKEPICT;
```

*wCamera*

Specifies the camera that should take the photo as one of the following flags:

Value	Meaning
WFS_CAM_ROOM	Monitors the whole self-service area.
WFS_CAM_PERSON	Monitors the person standing in front of the self-service machine.
WFS_CAM_EXITSLOT	Monitors the exit slot(s) of the self-service machine.

*lpszCamData*

Specifies the text string to be displayed on the photo. If the maximum text length is exceeded it will be truncated. In this case or if the text given is invalid an execute event WFS\_EXEE\_CAM\_INVALIDDATA is generated. Nevertheless the picture is taken.

*lpszUNICODECamData*

Specifies the UNICODE text string to be displayed on the photo. If the maximum text length is exceeded, it will be truncated. In this case or if the text given is invalid an execute event WFS\_EXEE\_CAM\_INVALIDDATA is generated. Nevertheless the picture is taken.

The *lpszUNICODECamData* field should only be used if the Service Provider supports UNICODE. The *lpszCamData* and *lpszUNICODECamData* fields are mutually exclusive.

**Output Param** None.

**Error Codes** In addition to the generic error codes defined in [Ref. 1], the following error codes can be generated by this command:

Value	Meaning
WFS_ERR_CAM_CAMNOTSUPP	The specified camera is not supported.
WFS_ERR_CAM_MEDIAFULL	The recording media is full.
WFS_ERR_CAM_CAMINOP	The specified camera is inoperable.
WFS_ERR_CAM_CHARSETNOTSUPP	Character set(s) supported by Service Provider is inconsistent with use of <i>lpszCamData</i> or <i>lpszUNICODECamData</i> fields.

**Events** In addition to the generic events defined in [Ref. 1], the following events can be generated by this command:

Value	Meaning
WFS_USRE_CAM_MEDIATHRESHOLD	The state of the recording media reached a threshold.
WFS_EXEE_CAM_INVALIDDATA	The text string given is too long or in some other way invalid.

**Comments** None.

## 5.2 WFS\_CMD\_CAM\_RESET

---

<b>Description</b>	Sends a service reset to the Service Provider.
<b>Input Param</b>	None.
<b>Output Param</b>	None.
<b>Error Codes</b>	Only the generic error codes defined in [Ref. 1] can be generated by this command.
<b>Events</b>	Only the generic events defined in [Ref. 1] can be generated by this command.
<b>Comments</b>	This command is used by an application control program to cause a device to reset itself to a known good condition.

## 6. Events

---

### 6.1 WFS\_USRE\_CAM\_MEDIATHRESHOLD

---

**Description** This user event is used to specify that the state of the recording media reached a threshold.

**Event Param** LPWORD lpwMediaThreshold;

*lpwMediaThreshold*

Specified as one of the following flags:

Value	Meaning
WFS_CAM_MEDIAOK	The recording media is a good state.
WFS_CAM_MEDIAHIGH	The recording media is almost full.
WFS_CAM_MEDIAFULL	The recording media is full.

**Comments** None.



## 6.2 WFS\_EXEE\_CAM\_INVALIDDATA

---

<b>Description</b>	This execute event is used to specify that the text string given was too long or in some other way invalid.
<b>Event Param</b>	None.
<b>Comments</b>	None.

## 7. C - Header file

---

```
/*
 *
 * xfscam.h      XFS - Camera (CAM) definitions
 *
 *              Version 3.10 (29/11/2007)
 *
 */
*****/

#ifndef __INC_XFSCAM_H
#define __INC_XFSCAM_H

#ifdef __cplusplus
extern "C" {
#endif

#include <xfssapi.h>

/* be aware of alignment */
#pragma pack (push, 1)

/* values of WFSCAMCAPS.wClass */

#define WFS_SERVICE_CLASS_CAM (10)
#define WFS_SERVICE_VERSION_CAM (0x0A03) /* Version 3.10 */
#define WFS_SERVICE_NAME_CAM "CAM"

#define CAM_SERVICE_OFFSET (WFS_SERVICE_CLASS_CAM * 100)

/* CAM Info Commands */

#define WFS_INF_CAM_STATUS (CAM_SERVICE_OFFSET + 1)
#define WFS_INF_CAM_CAPABILITIES (CAM_SERVICE_OFFSET + 2)

/* CAM Execute Commands */

#define WFS_CMD_CAM_TAKE_PICTURE (CAM_SERVICE_OFFSET + 1)
#define WFS_CMD_CAM_RESET (CAM_SERVICE_OFFSET + 2)

/* CAM Messages */

#define WFS_USRE_CAM_MEDIATHRESHOLD (CAM_SERVICE_OFFSET + 1)
#define WFS_EXEE_CAM_INVALIDDATA (CAM_SERVICE_OFFSET + 2)

/* values of WFSCAMSTATUS.fwDevice */

#define WFS_CAM_DEVONLINE WFS_STAT_DEVONLINE
#define WFS_CAM_DEVOFFLINE WFS_STAT_DEVOFFLINE
#define WFS_CAM_DEVPPOWEROFF WFS_STAT_DEVPPOWEROFF
#define WFS_CAM_DEVNODEVICE WFS_STAT_DEVNODEVICE
#define WFS_CAM_DEVHWERROR WFS_STAT_DEVHWERROR
#define WFS_CAM_DEVUSERERROR WFS_STAT_DEVUSERERROR
#define WFS_CAM_DEVBUSY WFS_STAT_DEVBUSY
#define WFS_CAM_DEVFRAUDATTEMPT WFS_STAT_DEVFRAUDATTEMPT

/* number of cameras supported/length of WFSCAMSTATUS.fwCameras field */

#define WFS_CAM_CAMERAS_SIZE (8)
#define WFS_CAM_CAMERAS_MAX (WFS_CAM_CAMERAS_SIZE - 1)

/* indices of WFSCAMSTATUS.fwMedia[...]
   WFSCAMSTATUS.fwCameras [...]
   WFSCAMSTATUS.fwPictures[...]
   WFSCAMCAPS.fwCameras [...]
   WFSCAMTAKEPICT.wCamera */

#define WFS_CAM_ROOM (0)
#define WFS_CAM_PERSON (1)
```

```

#define      WFS_CAM_EXITSLOT                (2)

/* values of WFSCAMSTATUS.fwMedia */

#define      WFS_CAM_MEDIAOK                (0)
#define      WFS_CAM_MEDIAHIGH             (1)
#define      WFS_CAM_MEDIAFULL             (2)
#define      WFS_CAM_MEDIAUNKNOWN         (3)
#define      WFS_CAM_MEDIANOTSUPP         (4)

/* values of WFSCAMSTATUS.fwCameras */

#define      WFS_CAM_CAMNOTSUPP            (0)
#define      WFS_CAM_CAMOK                 (1)
#define      WFS_CAM_CAMINOP               (2)
#define      WFS_CAM_CAMUNKNOWN           (3)

/* values of WFSCAMCAPS.fwType */

#define      WFS_CAM_TYPE_CAM              (1)

/* values of WFSCAMCAPS.fwCameras */

#define      WFS_CAM_NOT_AVAILABLE         (0)
#define      WFS_CAM_AVAILABLE            (1)

/* values of WFSCAMCAPS.fwCamData */

#define      WFS_CAM_NOTADD                (0)
#define      WFS_CAM_AUTOADD               (1)
#define      WFS_CAM_MANADD                (2)

/* values of WFSCAMCAPS.fwCharSupport, WFSCAMTAKEPICT.fwCharSupport */

#define      WFS_CAM_ASCII                  (0x0001)
#define      WFS_CAM_UNICODE                (0x0002)

/* XFS CAM Errors */

#define WFS_ERR_CAM_CAMNOTSUPP              (- (CAM_SERVICE_OFFSET + 0))
#define WFS_ERR_CAM_MEDIAFULL              (- (CAM_SERVICE_OFFSET + 1))
#define WFS_ERR_CAM_CAMINOP                (- (CAM_SERVICE_OFFSET + 2))
#define WFS_ERR_CAM_CHARSETNOTSUPP        (- (CAM_SERVICE_OFFSET + 3))

/*=====*/
/* CAM Info Command Structures */
/*=====*/

typedef struct _wfs_cam_status
{
    WORD          fwDevice;
    WORD          fwMedia[WFS_CAM_CAMERAS_SIZE];
    WORD          fwCameras[WFS_CAM_CAMERAS_SIZE];
    USHORT        usPictures[WFS_CAM_CAMERAS_SIZE];
    LPSTR         lpszExtra;
} WFSCAMSTATUS, *LPWFSCAMSTATUS;

typedef struct _wfs_cam_caps
{
    WORD          wClass;
    WORD          fwType;
    WORD          fwCameras[WFS_CAM_CAMERAS_SIZE];
    USHORT        usMaxPictures;
    WORD          fwCamData;
    USHORT        usMaxDataLength;
    WORD          fwCharSupport;
    LPSTR         lpszExtra;
} WFSCAMCAPS, *LPWFSCAMCAPS;

```

```
/*=====*/  
/* CAM Execute Command Structures */  
/*=====*/  
  
typedef struct _wfs_cam_take_picture  
{  
    WORD            wCamera;  
    LPSTR           lpszCamData;  
    LPWSTR          lpszUNICODECamData;  
} WFSCAMTAKEPICT, *LPWFSCAMTAKEPICT;  
  
/* restore alignment */  
#pragma pack (pop)  
  
#ifdef __cplusplus  
} /*extern "C"*/  
#endif  
  
#endif /* __INC_XFSCAM__H */
```